

P/N	NSN	DESIGNATION	MANUFACTURER
100	7310-00-905-6212	OVEN, WARMING, ELECTRIC	SPERRY-FRANK
693	5965-00-755-4643	MICROPHONE, DYNAMIC	BOSCH SECURITY SYSTEMS
758	6605-00-663-8512	COMPASS, MAGNETIC, MOUNTED	KOLLSMAN
1000	7310-00-905-6212	OVEN, WARMING, ELECTRIC	SPERRY-FRANK
1010	6615-01-248-0835	GYROSCOPE, RATE OF TURN	KIRKOS ENGINEERING
1031	5930-00-615-7340	SWITCH, PRESSURE	HYDRA-ELECTRIC
1144	5826-00-188-5554	INDICATOR, BEARING	KOLLSMAN
1175	6625-01-412-3365	METER, ELECTRICAL FREQUENCY	JEWELL INSTRUMENTS
1553	5930-00-615-7340	SWITCH, PRESSURE	HAYDON KERK
4047	5945-00-628-6484	RELAY, HYBRID	DNE TECHNOLOGIES
4060		ALTIMETER, PRESSURE	WINTER INSTRUMENTS
4100	5945-00-075-4925	SWITCH, INSTRUMENT	DNE TECHNOLOGIES
4110		ALTIMETER, PRESSURE	WINTER INSTRUMENTS
4320	6610-12-392-5545	ALTIMETER, PRESSURE	WINTER INSTRUMENTS
4371	2925-01-483-3517	MAGNETO, IGNITION	UNISON INDUSTRIES
6316	6340-00-304-5556	DETECTOR, ICE	DNE TECHNOLOGIES
8348	1620-00-617-9123	GEARBOX, LANDING	CEF INDUSTRIES
8445	1680-01-004-2086	ACTUATOR, ELECTRO-MECHANICAL, LINEAR	CEF INDUSTRIES
8446	1680-00-615-1335	ACTUATOR, ELECTRO-MECHANICAL, LINEAR	CEF INDUSTRIES
8465	6685-00-526-7864	TRANSMITTER, PRESSURE	CEF INDUSTRIES
8544	1680-01-218-2079	ACTUATOR, ELECTRO-MECHANICAL, LINEAR	CEF INDUSTRIES
8545	1680-01-217-5837	ACTUATOR, ELECTRO-MECHANICAL, LINEAR	CEF INDUSTRIES
8546	1680-01-222-2551	ACTUATOR, ELECTRO-MECHANICAL, LINEAR	CEF INDUSTRIES
8656	1680-01-449-2870	ACTUATOR, ELECTRO-MECHANICAL, LINEAR, OIL COOLER DOOR	CEF INDUSTRIES
10118	5965-01-127-3890	HEADSET, MICROPHONE	ASTROCOM ELECTRONICS
10197	5965-00-755-4643	MICROPHONE, DYNAMIC	ASTROCOM ELECTRONICS
10557	5965-01-128-1410	HEADSET, MICROPHONE	ROANWELL
10558	5965-01-127-3890	HEADSET, MICROPHONE	ROANWELL
10689	5965-00-755-4643	MICROPHONE, DYNAMIC	ROANWELL
10706	5985-01-491-3998	ANTENNA	CEF INDUSTRIES
10950	5965-01-128-1410	HEADSET, MICROPHONE	ASTROCOM ELECTRONICS
10951	5965-01-128-1410	HEADSET, MICROPHONE	ASTROCOM ELECTRONICS
18000	5826-00-032-7024	INDICATOR, BEARING-DISTANCE-HEADING	AIRCO
22118	6645-00-814-1706	CLOCK, MECHANICAL, PANEL	AEROSONIC
22135	5985-00-673-5831	ANTENNA, DME/TACAN, BEACON	L3 TECHNOLOGIES
22630	5985-00-673-5831	ANTENNA, DME/TACAN, BEACON	L3 TECHNOLOGIES
22705	6610-00-006-5783	INDICATOR, MACH AND TRUE AIR SPEED	AEROSONIC
44143	2915-01-147-2644	PUMP, FUEL, FFP	EATON INDUSTRIAL
44910		LIGHT, EMERGENCY EXIT	GRIMES AEROSPACE
47680	4810-00-761-6225	VALVE, LINEAR, DIRECTIONAL CONTROL	EATON
49740	4810-00-612-2696	VALVE, LINEAR, DIRECTIONAL CONTROL	EATON
49930	2925-01-360-2734	EXCITER, IGNITION	UNISON INDUSTRIES
50150	4810-00-533-4097	VALVE, LINEAR, DIRECTIONAL CONTROL	WOODWARD
50313	4140-00-564-5980	FAN, CENTRIFUGAL	FREUND PRECISION
52760	4820-01-033-2869	VALVE, LINEAR, DIRECTIONAL CONTROL	EATON
62560	4320-01-224-9869	MOTOR, HYDRAULIC	EATON AEROSPACE
66039	4320-00-616-3812	PUMP, AXIAL PISTONS	PARKER HANNIFIN
76000	5826-MD-010-2363	INDICATOR, OMNI BEARING	ACTIA (THALES AVIONICS)
80550	5985-00-553-5867	ANTENNA, LOOP	BORG INSTRUMENTS
83308	1650-00-815-9387	MOTOR, HYDRAULIC	EATON AEROSPACE
89000	6620-00-901-7848	TRANSMITTER PRESSURE	S-TECH
93416	4320-01-224-9869	MOTOR, HYDRAULIC	EATON AEROSPACE

95023	5930-00-961-8507	SWITCH, PRESSURE	HYDRA-ELECTRIC
95024	5930-00-961-8506	SWITCH, PRESSURE	HYDRA-ELECTRIC
100266	6610-00-557-3030	INDICATOR, ATTITUDE DIRECTOR	L3 TECHNOLOGIES
100524	6605-00-034-2500	INDICATOR, HORIZONTAL SITUATION	ASTRONAUTICS
102150	1660-00-343-4692	REGULATOR, AIR PRESSURE, AIRCRAFT CABIN	HONEYWELL INTERNATIONAL
102217	6130-00-927-0415	BATTERY, POWER SUPPLY	DRS TECHNOLOGIES
102379	6610-00-939-5237	INDICATOR, ATTITUDE DIRECTOR	ASTRONAUTICS
104470	5826-00-089-7912	INDICATOR, BEARING DISTANCE HEADING	ASTRONAUTICS
109110	6610-33-G02-2895	INDICATOR, ATTITUDE DIRECTOR	MEGGIT
115385	4320-00-631-4859	PUMP, ROTARY	ASTRONAUTICS
115715	4320-00-631-4859	PUMP, ROTARY	MEGGIT
135244	6625-00-235-4782	VOLTMETER, D/C	WESTON ELECTRICAL INSTRUMENT
170998	1650-00-204-1703	MOTOR, HYDRAULIC	EATON AEROSPACE
171232	1650-00-204-1703	MOTOR, HYDRAULIC	EATON AEROSPACE
200261	5826-00-611-0951	MOUNTING BASE	RAYTHEON
280522	6930-01-112-3283	INDICATOR, POSITION	L3 TECHNOLOGIES
400086	6645-00-793-5794	CLOCK, MECHANICAL, PANEL	WALTHAM AIRCRAFT CLOCK
400161	6645-00-022-7479	CLOCK, MECHANICAL, PANEL	WALTHAM AIRCRAFT CLOCK
400164	6645-00-950-8599	CLOCK, MECHANICAL, PANEL	WALTHAM AIRCRAFT CLOCK
400191	6645-00-950-8599	CLOCK, MECHANICAL, PANEL	WALTHAM AIRCRAFT CLOCK
400192	6645-00-880-5927	CLOCK, MECHANICAL, PANEL	WALTHAM AIRCRAFT CLOCK
400196	6645-00-121-7551	CLOCK, MECHANICAL, PANEL	WALTHAM AIRCRAFT CLOCK
400201	6645-00-950-8599	CLOCK, MECHANICAL, PANEL	WALTHAM AIRCRAFT CLOCK
400202	6645-00-150-6526	CLOCK, MECHANICAL, PANEL	WALTHAM AIRCRAFT CLOCK
400240	6645-00-076-3050	CLOCK, MECHANICAL, PANEL	WALTHAM AIRCRAFT CLOCK
400252	6645-00-880-5927	CLOCK, MECHANICAL, PANEL	WALTHAM AIRCRAFT CLOCK
405968	5985-00-149-1451	ANTENNA, LOOP	KEARFOTT
433213	5965-01-128-1410	HEADSET, MICROPHONE	RAYTHEON TECHNICAL SERVICES
433220	6645-00-076-3050	CLOCK, MECHANICAL, PANEL	L3 TECHNOLOGIES
472475	6350-01-280-1671	CONTROL, ALARM FIRE DETECTION	KIDDE TECHNOLOGIES
472529	6620-01-063-9054	INDICATOR, TORQUEMETER	SIMMONDS PRECISION PRODUCTS
472740	6680-01-060-4248	INDICATOR, FUEL QUANTITY	SIMMONDS PRECISION PRODUCTS
472887	6680-01-060-4249	INDICATOR, FUEL QUANTITY	SIMMONDS PRECISION PRODUCTS
505968	5985-00-149-1451	ANTENNA, LOOP	KEARFOTT
519819	1610-00-622-7973	CONTROL, PROPELLER PHASE AND TRIM	HAMILTON SUNDSTRAND
534853	6685-00-887-1966	PROBE, TEMPERATURE	HONEYWELL INTERNATIONAL
535429	6610-00-887-9422	MOUNT ASSY, COMPUTER RESILIENT	HONEYWELL INTERNATIONAL
538088	6610-00-991-0770	INDICATOR, TRUE AIR SPEED	HONEYWELL INTERNATIONAL
546766	1610-00-938-9859	SERVO ASSEMBLY, SPEED	HAMILTON SUNDSTRAND
549722	2915-00-971-9130	PUMP, SUBMERGED, AIRCRAFT	HONEYWELL INTERNATIONAL
557915		SERVO ASSEMBLY, SPEED	HAMILTON SUNDSTRAND
560655	6645-00-887-0122	TIMER, SEQUENTIAL	HAMILTON SUNDSTRAND
585500	1610-00-764-5622	SYNCHROPHASER, PROPELLER	HAMILTON SUNDSTRAND
588584	1610-00-960-9885	SYNCHROPHASER, PROPELLER	HAMILTON SUNDSTRAND
597925	1610-00-909-1406	SERVO ASSEMBLY, SPEED	HAMILTON SUNDSTRAND
599461	1610-01-004-5385	SERVO ASSEMBLY, SPEED	HAMILTON SUNDSTRAND
600301	5841-00-805-7622	INDICATOR, RADAR, TARGET	LOCKHEED MARTIN
600326	5996-00-805-7621	AMPLIFIER, ELECTRONIC CONTROL, RADAR	LOCKHEED MARTIN
600328	5841-00-804-7159	CONTROL PANEL, RADAR SET	LOCKHEED MARTIN
600329	4140-00-289-4277	FAN, VANE, AXIAL	LOCKHEED MARTIN
658060	1650-00-858-0501	ACCUMULATOR, PNEUMATIC	LOCKHEED MARTIN
670752	1680-01-181-1374	ACTUATOR, ELECTRO-MECHANICAL, LINEAR	LOCKHEED MARTIN
670764	6680-00-923-8466	GENERATOR, TACHOMETER	LOCKHEED MARTIN

695197	4810-01-066-0321	VALVE, LINEAR, DIRECTIONAL CONTROL	LOCKHEED MARTIN
695261	6685-00-692-8341	INDICATOR, TEMPERATURE, ELECTRICAL RESISTANCE	LOCKHEED MARTIN
695316	4810-00-525-2445	VALVE, ENVIRONMENTAL AIR ,FLOW CONTROL	LOCKHEED MARTIN
695324	4140-00-564-5980	FAN, CENTRIFUGAL	LOCKHEED MARTIN
695455	6340-00-304-5556	DETECTOR, ICE	LOCKHEED MARTIN
695495	4810-00-761-6225	VALVE, LINEAR, DIRECTIONAL CONTROL	LOCKHEED MARTIN
695700	1680-00-672-8931	ACTUATOR, ELEVATOR TRIM TAB, ROTARY	LOCKHEED MARTIN
695715	5945-00-675-7413	RELAY, ELECTROMAGNETIC	LOCKHEED MARTIN
695795	5945-00-675-7412	RELAY, ELECTROMAGNETIC	LOCKHEED MARTIN
695807	1680-01-497-7142	ACTUATOR, ELECTRO-MECHANICAL, LINEAR, OIL COOLER DOOR	LOCKHEED MARTIN
695813	4820-00-006-5087	VALVE, ENGINE, BLEED AIR, CHECK	LOCKHEED MARTIN
695908	4320-00-616-3812	PUMP, AXIAL PISTONS	LOCKHEED MARTIN
697752	4810-00-575-7781	VALVE, TEMPERATURE CONTROL, BUTTERFLY	LOCKHEED MARTIN
697753	4810-01-039-0459	VALVE, BUTTERFLY	LOCKHEED MARTIN
707821	5826-00-241-1011	TRANSCEIVER, RADIO COMPASS	RAYTHEON
707874	5826-00-611-0951	MOUNTING BASE	RAYTHEON
707877	5895-00-228-3133	CONTROL BOX, RECEIVER	RAYTHEON
708268	5826-00-625-9201	TRANSCEIVER, RADIO COMPASS	RAYTHEON
731700	2915-00-074-1724	VALVE, FLOAT, FUEL TANK	TRANSDIGM
861195	4320-00-174-5811	PUMP, AUXILIAR	EATON AEROSPACE
891041	6350-01-280-1671	DETECTOR, HEAT	KIDDE TECHNOLOGIES
892541	6350-00-015-8049	DETECTOR, HEAT	KIDDE TECHNOLOGIES
917108	4140-01-041-4886	FAN, VANE, AXIAL	LITTON
1105123	1680-01-208-0174	ACTUATOR, OIL COOLER DOOR, ELECTRO-MECHANICAL	SMITH & SMITH AIRCRAFT
1503046	5841-00-659-4304	CONTROL PANEL, SYNCHRONIZER	LOCKHEED MARTIN
1505380	5841-00-845-4243	GENERATOR, RADAR, STABILIZATION DATA	LOCKHEED MARTIN
1505950	5841-00-805-7622	INDICATOR, RADAR, TARGET	LOCKHEED MARTIN
1510309	5841-00-983-8393	GENERATOR, ELECTRONIC MARKER, RADAR	LOCKHEED MARTIN
1510310	6110-00-984-1438	CONTROL PANEL, GENERATOR	NORTHROP GRUMMAN SYSTEMS
1510981	5985-01-371-9021	CONTROL PANEL, ANTENNA	NORTHROP GRUMMAN SYSTEMS
1689355	5965-01-128-1410	HEADSET, MICROPHONE	LOCKHEED MARTIN
1780109	6605-00-111-3645	TRANSMITTER, INDUCTION COMPASS	HONEYWELL INTERNATIONAL
1780595	6605-00-241-8996	COMPENSATOR, INDUCTION COMPASS	HONEYWELL INTERNATIONAL
1887851	5841-01-053-7874	INDICATOR, RADAR, TARGET	NORTHROP GRUMMAN SYSTEMS
1889514	5841-01-053-5763	RADAR SET	NORTHROP GRUMMAN SYSTEMS
1889519	5895-01-053-3579	SYNCHRONIZER, ELECTRICAL	NORTHROP GRUMMAN SYSTEMS
1889522	6130-01-056-8665	POWER SUPPLY, RADAR	NORTHROP GRUMMAN SYSTEMS
1889523	5841-01-053-7872	DISPLAY UNIT, RADAR	NORTHROP GRUMMAN SYSTEMS
1889525	5841-01-053-5762	TRANSCEIVER, RADAR	NORTHROP GRUMMAN SYSTEMS
1889526	5841-01-053-7894	TRANSCEIVER, RADAR	NORTHROP GRUMMAN SYSTEMS
1978371	5841-01-282-7093	TRANSCEIVER, RADAR	NORTHROP GRUMMAN SYSTEMS
2585289	5841-00-845-4243	GENERATOR, RADAR, STABILIZATION DATA	NORTHROP GRUMMAN SYSTEMS
2585726	6605-00-833-5087	TRANSMITTER, INDUCTION COMPASS	HONEYWELL INTERNATIONAL
3883028	6685-00-526-7864	TRANSMITTER, PRESSURE	GULFSTREAM AEROSPACE
3883029	6680-01-122-6960	GENERATOR, TACHOMETER	GULFSTREAM AEROSPACE
4006452	6680-01-020-5012	TRANSMITTER, OIL QUANTITY	SIMMONDS PRECISION PRODUCTS
4670064	5965-01-128-1410	HEADSET, MICROPHONE	ROHDE & SCHWARZ
6404486	2915-00-464-6946	CONTROL, SENSITIVE, SPEED	GENERAL MOTORS
6502251	6645-00-091-7107	TIMER, ELECTRICAL, STOP	ROLLS-ROYCE
6510376	5985-01-080-8452	ANTENNA, VHF	EMBRAER
6610273	6610-00-515-4600	INDICATOR, FLAP, POSITION	EMBRAER
6610328	6645-00-150-6526	CLOCK, MECHANICAL, PANEL	EMBRAER
6805769	5996-00-764-6258	AMPLIFIER, ELECTRONIC TEMPERATURE DATUM	ROLLS-ROYCE

6809573	2995-00-877-3666	VALVE, ANTI ICING	ROLLS-ROYCE
6809574	2915-00-877-3277	VALVE, TEMPERATURE DATUM	LOCKHEED MARTIN
6814762	2915-00-626-3123	VALVE, FUEL SYSTEM	HONEYWELL INTERNATIONAL
6815686	4810-00-627-4825	VALVE ASSY, SOLENOID, DRAIN	ROLLS-ROYCE
6821493	2995-00-876-9685	VALVE, SPEED SENSITIVE	ROLLS-ROYCE
6827995	5930-00-965-7111	SWITCH, FUEL FILTER, PRESSURE	ROLLS-ROYCE
6842553	5996-00-691-0174	AMPLIFIER, ELECTRONIC TEMPERATURE DATUM	ROLLS-ROYCE
6873465	2915-00-464-6946	CONTROL, SENSITIVE, SPEED	ROLLS-ROYCE
6876338	5996-01-096-4648	AMPLIFIER, ELECTRONIC TEMPERATURE DATUM	ROLLS-ROYCE
6894182	5996-01-114-8652	AMPLIFIER, ELECTRONIC CONTROL	ROLLS-ROYCE
7000066	6610-00-580-9690	INDICATOR, RUDDER, POSITION	AIRCRAFT INSTRUMENTS
7000070	6610-00-808-7038	INDICATOR, AILERON TRIM TAB, POSITION	AIRCRAFT INSTRUMENTS
7000073	6610-00-808-7037	INDICATOR, AILERON TRIM TAB, POSITION	AIRCRAFT INSTRUMENTS
7514060		ANTENNA, TCAS DIRECTIONAL ANTENNA	ACSS
7514081		ANTENNA, TCAS DIRECTIONAL ANTENNA	ACSS
8020042	5930-00-615-7340	SWITCH, PRESSURE	ELECTRO NATIONAL
8529935	2935-00-887-4267	COOLER, ENGINE OIL	PARKER HANNIFIN
8859877	4320-01-171-0452	PUMP, AXIAL PISTONS	GENERAL MOTORS
9260065		TRANSMITTER, EMERGENCY LOCATOR (ELT)	ELTA
9305700	1660-00-595-7773	SENSOR, CABIN TEMPERATURE	EDEL ENGINEERING DEVELOPMENT
9542662	1630-00-914-1329	WHEEL, NOSE LANDING GEAR	GOODYEAR
9560569	1630-01-482-8991	BRAKE, MULTIPLE DISK	MEGGITT AIRCRAFT BRAKING SYSTEMS
9560685	1630-00-825-4794	BRAKE, MULTIPLE DISK	MEGGITT AIRCRAFT BRAKING SYSTEMS
9746077	6130-00-958-9796	POWER SUPPLY, DC	MEGGITT AIRCRAFT BRAKING SYSTEMS
10006252	1650-00-288-9632	MOTOR, HYDRAULIC	EATON AEROSPACE
23711461	1650-00-858-0501	ACCUMULATOR, PNEUMATIC	TAVCO
26130010	4810-00-987-3948	VALVE, SOLENOID, SHUT-OFF	HAMILTON SUNDSTRAND
26130011	4810-00-987-3949	VALVE, SOLENOID, SHUT-OFF	HAMILTON SUNDSTRAND
27231294	1660-00-583-7106	SENSOR, DUCT, OVERHEAT	HAMILTON SUNDSTRAND
27231296	1660-00-595-7773	SENSOR, CABIN TEMPERATURE	HAMILTON SUNDSTRAND
27231318	1660-01-021-4981	CONTROL BOX, AIRCRAFT AIR TEMPERATURE	HAMILTON SUNDSTRAND
27241301	4820-00-006-5087	VALVE, ENGINE, BLEED AIR, CHECK	HAMILTON SUNDSTRAND
58057112		GYROSCOPE, COMPASS	SFIM INDUSTRIES
62707621	1660-00-351-3738	CONTROL BOX, AIR TEMPERATURE	HONEYWELL INTERNATIONAL
69580701	6685-01-119-6546	THERMOSTAT, FLOW CONTROL	PSG CONTROLS
1391041046	6620-00-514-5334	INDICATOR, PRESSURE	KOLLSMAN
1570041040	6620-00-514-5334	INDICATOR, PRESSURE	KOLLSMAN
8010000653	5841-01-301-4588	TRANSCEIVER, CARA	NAVCOM DEFENSE ELECTRONICS
8324020025	5826-12-361-9365	TACAN	THALES ELECTRONIC SYSTEMS
88415422001	6610-00-405-6461	ALTIMETER, ENCODER	KOLLSMAN
697749-1	6680-01-220-4090	INDICATOR, LIQUID QUANTITY	LOCKHEED MARTIN
00000C523	5895-01-128-7267	CONTROL, AMPLIFIER	L3 AVIATION PRODUCTS
001965	6685-00-526-7864	TRANSMITTER, PRESSURE	GOLEMAN
003013	5831-00-539-1471	CONTROL, INTERCOMMUNICATION SET	ANDREA SYSTEMS
003895-1	1680-00-888-3687	PUMP, WINDSHIELD	HAMILTON SUNDSTRAND
00558-503	1680-00-887-1908	GEARBOX, FLAP DRIVE	BFM ENERGY PRODUCTS
00558-505	1680-00-866-7187	GEARBOX, FLAP DRIVE	BFM ENERGY PRODUCTS
00558-507	1680-00-921-8698	GEARBOX, FLAP DRIVE	BFM ENERGY PRODUCTS
010006	4140-01-041-4886	FAN, VANE, AXIAL	ROTRON
010177	4140-01-041-4886	FAN, VANE, AXIAL	ROTRON
01-524795-1	5820-00-782-5308	RADIO SET	GENERAL DYNAMICS MISSION SYSTEMS
01-524860-1	5820-00-782-5308	RADIO SET	GENERAL DYNAMICS MISSION SYSTEMS
020-001-002	6680-00-869-9811	COMPENSATOR, FUEL QUANTITY	PARKER-HANNIFIN

020-001-003	6680-00-869-9812	COMPENSATOR, FUEL QUANITY	PARKER-HANNIFIN
020-001-004	6680-00-869-9813	COMPENSATOR, FUEL QUANITY	PARKER-HANNIFIN
020-001-005	6680-00-869-9814	COMPENSATOR, FUEL QUANITY	PARKER-HANNIFIN
020-061-001	6680-00-968-3227	COMPENSATOR, FUEL QUANITY	HONEYWELL INTERNATIONAL
020-061-002	6680-00-968-3226	COMPENSATOR, FUEL QUANITY	HONEYWELL INTERNATIONAL
020-061-003	6680-00-968-3225	COMPENSATOR, FUEL QUANITY	HONEYWELL INTERNATIONAL
020-061-004	6680-00-968-3260	COMPENSATOR, FUEL QUANITY	HONEYWELL INTERNATIONAL
020-061-005	6680-00-968-3261	COMPENSATOR, FUEL QUANITY	HONEYWELL INTERNATIONAL
020-061-006	6680-00-968-3263	COMPENSATOR, FUEL QUANITY	HONEYWELL INTERNATIONAL
020-061-007	6680-00-968-3266	COMPENSATOR, FUEL QUANITY	HONEYWELL INTERNATIONAL
020-061-008	6680-00-968-3269	COMPENSATOR, FUEL QUANITY	HONEYWELL INTERNATIONAL
020-061-009	6680-00-968-3271	COMPENSATOR, FUEL QUANITY	HONEYWELL INTERNATIONAL
020-061-010	6680-00-968-3270	COMPENSATOR, FUEL QUANITY	HONEYWELL INTERNATIONAL
020-061-011	6680-00-968-3253	COMPENSATOR, FUEL QUANITY	HONEYWELL INTERNATIONAL
020-061-012	6680-00-968-3228	COMPENSATOR, FUEL QUANITY	HONEYWELL INTERNATIONAL
020-061-013	6680-00-968-3229	COMPENSATOR, FUEL QUANITY	HONEYWELL INTERNATIONAL
020-061-014	6680-00-968-3230	COMPENSATOR, FUEL QUANITY	HONEYWELL INTERNATIONAL
020-061-015	6680-00-968-3242	COMPENSATOR, FUEL QUANITY	HONEYWELL INTERNATIONAL
020-061-016	6680-00-968-3243	COMPENSATOR, FUEL QUANITY	HONEYWELL INTERNATIONAL
020-061-017	6680-00-968-3244	COMPENSATOR, FUEL QUANITY	HONEYWELL INTERNATIONAL
020-061-018	6680-00-968-3251	COMPENSATOR, FUEL QUANITY	HONEYWELL INTERNATIONAL
020-061-019	6680-00-968-3252	COMPENSATOR, FUEL QUANITY	HONEYWELL INTERNATIONAL
020-061-020	6680-00-968-3255	COMPENSATOR, FUEL QUANITY	HONEYWELL INTERNATIONAL
020-061-021	6680-00-968-3258	COMPENSATOR, FUEL QUANITY	HONEYWELL INTERNATIONAL
020-061-022	6680-00-968-3197	COMPENSATOR, FUEL QUANITY	HONEYWELL INTERNATIONAL
020-061-023	6680-00-968-3213	COMPENSATOR, FUEL QUANITY	HONEYWELL INTERNATIONAL
020-061-024	6680-00-968-3223	COMPENSATOR, FUEL QUANITY	HONEYWELL INTERNATIONAL
020-061-025	6680-00-968-3212	COMPENSATOR, FUEL QUANITY	HONEYWELL INTERNATIONAL
03-1367606-101	5965-00-755-4643	MICROPHONE, DYNAMIC	GENERAL DYNAMICS MISSION SYSTEMS
051-000-001	6685-00-670-0895	THERMOSTAT, FLOW CONTROL	PSG CONTROLS
064-1052-70	5821-MD-010-2079	TRANSCEIVER, RADIO	HONEYWELL INTERNATIONAL
066-01153-0202	5841-01-561-2819	TRANSCEIVER, RADIO ALTIMETER	HONEYWELL INTERNATIONAL
066-1062-00	5895-01-269-4441	TRANSCEIVER, ATC	HONEYWELL INTERNATIONAL
066-1062-10	5895-01-269-4441	TRANSCEIVER, ATC	HONEYWELL INTERNATIONAL
066-3062-00		ALTIMETER, SERVO-ENCODER	BENDIX KING
066-3062-01		ALTIMETER, SERVO-ENCODER	BENDIX KING
066-3062-02		ALTIMETER, SERVO-ENCODER	BENDIX KING
066-3062-03		ALTIMETER, SERVO-ENCODER	BENDIX KING
066-3062-04		ALTIMETER, SERVO-ENCODER	BENDIX KING
066-3062-05		ALTIMETER, SERVO-ENCODER	BENDIX KING
066-3062-06		ALTIMETER, SERVO-ENCODER	BENDIX KING
066-3062-07		ALTIMETER, SERVO-ENCODER	BENDIX KING
066-3062-08		ALTIMETER, SERVO-ENCODER	BENDIX KING
066-3062-09		ALTIMETER, SERVO-ENCODER	BENDIX KING
066-3062-10		ALTIMETER, SERVO-ENCODER	BENDIX KING
066-3062-11		ALTIMETER, SERVO-ENCODER	BENDIX KING
066-3062-12		ALTIMETER, SERVO-ENCODER	BENDIX KING
066-3062-13		ALTIMETER, SERVO-ENCODER	BENDIX KING
066-3062-14		ALTIMETER, SERVO-ENCODER	BENDIX KING
066-3062-15		ALTIMETER, SERVO-ENCODER	BENDIX KING
066-3062-16		ALTIMETER, SERVO-ENCODER	BENDIX KING
066-50000-2930	5841-01-470-8036	PROCESSOR, TCAS	HONEYWELL INTERNATIONAL
071-01519-0101	5841-01-538-8074	RECEIVER-EXCITER, RADAR	HONEYWELL INTERNATIONAL

08-60170-001	1650-01-151-0619	ACCUMULATOR ASSY, HYDRAULIC	TACTAIR
08-8424-001	1650-01-151-0619	ACCUMULATOR ASSY, HYDRAULIC	TACTAIR
08-8424-0011	1650-01-151-0619	ACCUMULATOR ASSY, HYDRAULIC	TACTAIR
088424010	1650-00-640-8486	ACCUMULATOR ASSY, HYDRAULIC	TACTAIR
09168P-18	5965-00-755-4643	MICROPHONE, DYNAMIC	DAVID CLARK
092-000-001	6340-00-304-5556	DETECTOR, ICE	MACK ELECTRIC DEVICES
OR00268-1	5826-00-241-1011	TRANSCEIVER, RADIO COMPASS	RAYTHEON
OR20026-1	5826-00-241-1011	TRANSCEIVER, RADIO COMPASS	RAYTHEON
OR200268-1	5826-00-241-1011	TRANSCEIVER, RADIO COMPASS	RAYTHEON
OR200268-4	5821-00-503-4903	TRANSCEIVER, RADIO COMPASS	RAYTHEON
OR200343-1	5826-00-969-9542	MOUNTING BASE ASSEMBLY	RAYTHEON
OR200343-2	5826-00-333-9867	MOUNTING BASE ASSEMBLY	RAYTHEON
OR200343-4	5826-00-522-3428	MOUNTING BASE ASSEMBLY	RAYTHEON
OR200343B	5826-00-969-9542	MOUNTING BASE ASSEMBLY	RAYTHEON
100-0034-01		INDICATOR, ELECTRICAL TACHOMETER	SPERRY-FRANK
100-0034-03		INDICATOR, ELECTRICAL TACHOMETER	KELLY MANUFACTURING
100-0034-06		INDICATOR, ELECTRICAL TACHOMETER	KELLY MANUFACTURING
100-0034-16		INDICATOR, ELECTRICAL TACHOMETER	KELLY MANUFACTURING
100-0034-20		INDICATOR, ELECTRICAL TACHOMETER	KELLY MANUFACTURING
100-0034-22		INDICATOR, ELECTRICAL TACHOMETER	KELLY MANUFACTURING
100-0034-28		INDICATOR, ELECTRICAL TACHOMETER	KELLY MANUFACTURING
100-0034-29	6620-01-322-7678	INDICATOR, ELECTRICAL TACHOMETER	KELLY MANUFACTURING
100-0034-57		INDICATOR, ELECTRICAL TACHOMETER	KELLY MANUFACTURING
100-0034-58		INDICATOR, ELECTRICAL TACHOMETER	KELLY MANUFACTURING
100-0043-01	5841-00-189-9436	INDICATOR, ELECTRICAL TACHOMETER	KELLY MANUFACTURING
100-0043-02		INDICATOR, ELECTRICAL TACHOMETER	KELLY MANUFACTURING
100-0043-03		INDICATOR, ELECTRICAL TACHOMETER	KELLY MANUFACTURING
100-0043-04		INDICATOR, ELECTRICAL TACHOMETER	KELLY MANUFACTURING
100-0043-05		INDICATOR, ELECTRICAL TACHOMETER	KELLY MANUFACTURING
100-0051-01		INDICATOR, ELECTRICAL TACHOMETER	KELLY MANUFACTURING
100-0051-02		INDICATOR, ELECTRICAL TACHOMETER	KELLY MANUFACTURING
100-0051-03		INDICATOR, ELECTRICAL TACHOMETER	KELLY MANUFACTURING
100-0051-04		INDICATOR, ELECTRICAL TACHOMETER	KELLY MANUFACTURING
100-0051-05		INDICATOR, ELECTRICAL TACHOMETER	KELLY MANUFACTURING
100-0051-06		INDICATOR, ELECTRICAL TACHOMETER	KELLY MANUFACTURING
1000-1	7310-00-905-6212	OVEN, WARMING, ELECTRIC	KELLY MANUFACTURING
10040-1000-0101	6680-01-220-4090	INDICATOR, FUEL QUANTITY	SIMMONDS PRECISION PRODUCTS
10040-3000-0101	6680-01-220-4091	INDICATOR, FUEL QUANTITY	SIMMONDS PRECISION PRODUCTS
10040-5000-0101	6680-01-224-7271	INDICATOR, FUEL QUANTITY	SIMMONDS PRECISION PRODUCTS
10073-0101	6680-01-350-8049	INDICATOR, FUEL QUANTITY	SIMMONDS PRECISION PRODUCTS
10074-0101	6680-01-350-8048	INDICATOR, FUEL QUANTITY	SIMMONDS PRECISION PRODUCTS
10075-0101	6680-01-350-9120	INDICATOR, FUEL QUANTITY	SIMMONDS PRECISION PRODUCTS
1008700-4	1650-00-633-6250	ACCUMULATOR ASSY, HYDRAULIC	HONEYWELL INTERNATIONAL
10095-0101	6620-01-394-4018	INDICATOR, FUEL QUANTITY	SIMMONDS PRECISION PRODUCTS
10097-0101	6680-01-394-2555	INDICATOR, FUEL QUANTITY	SIMMONDS PRECISION PRODUCTS
1010530-4	1650-00-395-2599	ACCUMULATOR ASSY, HYDRAULIC	HONEYWELL INTERNATIONAL
10-1326-1		LIGHT, EMERGENCY EXIT	GRIMES AEROSPACE
102150-0	1660-00-343-4692	REGULATOR, AIR PRESSURE, AIRCRAFT CABIN	HONEYWELL INTERNATIONAL
102150-0-12		REGULATOR, AIR PRESSURE, AIRCRAFT CABIN	HONEYWELL INTERNATIONAL
102150-0-13	1660-00-343-4692	REGULATOR, AIR PRESSURE, AIRCRAFT CABIN	HONEYWELL INTERNATIONAL
102150-0-14	1660-00-343-4692	REGULATOR, AIR PRESSURE, AIRCRAFT CABIN	HONEYWELL INTERNATIONAL
102150-0-15	1660-00-343-4692	REGULATOR, AIR PRESSURE, AIRCRAFT CABIN	HONEYWELL INTERNATIONAL
102210-14-1	1660-01-067-0390	REGULATOR, AIR PRESSURE, AIRCRAFT CABIN	HONEYWELL INTERNATIONAL

102210-14-2	1660-01-159-9078	REGULATOR, AIR PRESSURE, AIRCRAFT CABIN	HONEYWELL INTERNATIONAL
102210-14-2A	1660-01-159-9078	REGULATOR, AIR PRESSURE, AIRCRAFT CABIN	HONEYWELL INTERNATIONAL
102210-16-1	1660-01-311-9984	REGULATOR, AIR PRESSURE, AIRCRAFT CABIN	HONEYWELL INTERNATIONAL
102210-9	1660-00-887-6728	REGULATOR, AIR PRESSURE, AIRCRAFT CABIN	HONEYWELL INTERNATIONAL
102210-9A	1660-00-887-6728	REGULATOR, AIR PRESSURE, AIRCRAFT CABIN	HONEYWELL INTERNATIONAL
102226-3	1660-00-887-6729	VALVE, CABIN AIR PRESSURE, OUTFLOW	HONEYWELL INTERNATIONAL
102538-2-1	1660-00-062-0301	CONTROLLER, AIR PRESSURE, AIRCRAFT CABIN	HONEYWELL INTERNATIONAL
102538-5-1	1660-01-391-8408	CONTROLLER, AIR PRESSURE, AIRCRAFT CABIN	HONEYWELL INTERNATIONAL
103036-3	1660-00-783-6159	REGULATOR, AIR PRESSURE, AIRCRAFT CABIN	HONEYWELL INTERNATIONAL
10-3068-5	4810-01-015-1980	VALVE, FUEL SYSTEM, GATE	BOEING
10-3068-6	4810-01-015-1979	VALVE, FUEL SYSTEM, GATE	BOEING
10-3206-2	6680-00-472-6348	TRANSMITTER, OIL QUANTITY	BOEING
10-3206-9	6680-01-020-5012	TRANSMITTER, OIL QUANTITY	BOEING
10-3212-3	1650-01-021-2865	SERVOVALVE, HYDRAULIC	BOEING
10322A	6620-00-189-2381	INDICATOR, TRIPLE	LIFTEC
10345E	5965-00-755-4643	MICROPHONE, DYNAMIC	ASTROCOM ELECTRONICS
10-381550-4	2925-01-360-2734	EXCITER, IGNITION	UNISON INDUSTRIES
10450-31105	6610-00-160-3226	ALTIMETER PRESSURE	AEROSONIC
10450-31327	6610-01-091-3702	ALTIMETER PRESSURE	AEROSONIC
1050-225	6645-00-950-8599	CLOCK, MECHANICAL, PANEL	WALTHAM AIRCRAFT CLOCK
1051R300	1620-00-406-5828	GEARBOX, LANDING	TRIUMPH GEAR SYSTEMS
106462-1	4810-00-887-1914	VALVE, BUTTERFLY	HONEYWELL INTERNATIONAL
106462-3-1	4810-00-884-7571	VALVE, BUTTERFLY	HONEYWELL INTERNATIONAL
10-682560-13	2920-01-222-2581	MAGNETO, DUAL	TELEDYNE INDUSTRIES
107996-X		THERMOSTAT, PNEUMATIC	HONEYWELL INTERNATIONAL
108032-X		REGULATOR, FILTER, PRESSURE	HONEYWELL INTERNATIONAL
10-821614-6R	6150-MD-040-3654	HARNES, DUAL IGNITION	TELEDYNE INDUSTRIES
109382-5	4810-00-903-0840	VALVE, SHUTTOFF	HONEYWELL INTERNATIONAL
109382-5-1	4810-00-903-0840	VALVE, SHUTTOFF	HONEYWELL INTERNATIONAL
10951A	5965-01-127-3890	HEADSET, MICROPHONE	ASTROCOM ELECTRONICS
109710-1-1	4810-00-299-7847	VALVE, APU, SHUT-OFF, BUTTERFLY	HONEYWELL INTERNATIONAL
109710-2	4810-01-014-2632	VALVE, APU, SHUT-OFF, BUTTERFLY	HONEYWELL INTERNATIONAL
109710-2-1	4810-01-014-2632	VALVE, APU, SHUT-OFF, BUTTERFLY	HONEYWELL INTERNATIONAL
109710-3-1		VALVE, APU, SHUT-OFF, BUTTERFLY	HONEYWELL INTERNATIONAL
109710-4-1		VALVE, APU, SHUT-OFF, BUTTERFLY	HONEYWELL INTERNATIONAL
109710-5-1	4820-01-459-2243	VALVE, APU, SHUT-OFF, BUTTERFLY	HONEYWELL INTERNATIONAL
109710-6	4810-01-229-3584	VALVE, APU, SHUT-OFF, BUTTERFLY	HONEYWELL INTERNATIONAL
109710-6-1	4810-01-229-3584	VALVE, APU, SHUT-OFF, BUTTERFLY	HONEYWELL INTERNATIONAL
109710-7-1		VALVE, APU, SHUT-OFF, BUTTERFLY	HONEYWELL INTERNATIONAL
109710-8-1		VALVE, APU, SHUT-OFF, BUTTERFLY	HONEYWELL INTERNATIONAL
109710-9	4810-01-393-3991	VALVE, APU, SHUT-OFF, BUTTERFLY	HONEYWELL INTERNATIONAL
109710-9-1	4810-01-229-3584	VALVE, APU, SHUT-OFF, BUTTERFLY	HONEYWELL INTERNATIONAL
10D014-1	5820-00-782-5308	RADIO SET	OAI ELECTRONICS
110-340	5985-01-562-0815	ANTENNA	CHELTON AVIONIC
1105123-1	1680-01-254-6893	ACTUATOR, OIL COOLER DOOR, ELECTRO-MECHANICAL	SMITH & SMITH AIRCRAFT
1117-02	4320-14-449-6817	PUMP, HYDRAULIC	IN-LHC
1117-03	1650-14-434-8822	PUMP, HYDRAULIC	IN-LHC
1121-8-9-00	4820-00-810-2061	VALVE, FLUID, REGULATING	PARKER-HANNIFIN
1121F8-2-0	4820-00-622-2446	VALVE, FLUID, REGULATING	PARKER-HANNIFIN
1121F8-9-0	4820-00-810-2061	VALVE, FLUID, REGULATING	PARKER-HANNIFIN
1121F8-9-00	4820-00-810-2061	VALVE, FLUID, REGULATING	PARKER-HANNIFIN
11221-7	1660-01-236-1136	CONTROL BOX, TEMPERATURE	HAMILTON SUNDSTRAND
112-383	2915-00-887-1915	PUMP, FUEL	HAMILTON SUNDSTRAND

113-10105	5831-00-106-2733	CONTROL, PUBLIC ADDRESS SET	RANDAM ELECTRONICS
1144-041030	5826-00-505-0968	INDICATOR, BEARING	KOLLSMAN
11568-000	2935-01-170-8386	COOLER, ENGINE OIL	GE AVIATION SYSTEMS
116595-01	6610-00-557-3030	INDICATOR, ATTITUDE DIRECTOR	GE AVIATION SYSTEMS
11700	6615-01-059-7909	GYROSCOPE, RATE OF TURN	ATLANTIC INERTIAL SYSTEMS
117-384019-3	6625-01-294-5627	INDICATOR, FUEL QUANTITY	BEECHCRAFT
1184R125	1680-00-733-3491	WINCH, AIRCRAFT MOUNTED	GOODRICH
119415-2	5895-01-096-3727	TRANSCEIVER, RADIO	BAE SYSTEMS
121000-1	4810-01-220-6060	VALVE, SOLENOID	ROCKER SOLENOID
12-10001-01	6680-01-419-1995	TRANSMITTER, OIL QUANTITY	STRUBE
12-10001-10	6680-01-419-1995	TRANSMITTER, OIL QUANTITY	STRUBE
121000-2	4810-01-220-6060	VALVE, SOLENOID	ROCKER SOLENOID
121672-01	6615-00-550-6628	GYROSCOPE, DISPLACEMENT	GE AVIATION SYSTEMS
121672-01-15	6615-00-973-2218	GYROSCOPE, DISPLACEMENT	GE AVIATION SYSTEMS
121672-01-16	6615-00-074-4036	GYROSCOPE, DISPLACEMENT	GE AVIATION SYSTEMS
121672-01-17	6615-00-900-5959	GYROSCOPE, DISPLACEMENT	GE AVIATION SYSTEMS
1228-041040	6620-00-553-8988	TRANSMITTER, PRESSURE	KOLLSMAN
123488-010-01	4320-01-471-3415	PUMP, ROTARY	ONTIC
124236-1	6645-00-091-7107	TIMER, ELECTRICAL, STOP	ROLLS-ROYCE
124536-22	2910-00-420-1277	CONTROL, TURBINE ENGINE, FUEL	HONEYWELL INTERNATIONAL
124536-31	2910-01-034-9473	CONTROL, TURBINE ENGINE, FUEL	HONEYWELL INTERNATIONAL
124623-01	6615-00-581-2265	GYROSCOPE, DISPLACEMENT	GE AVIATION SYSTEMS
124623-01-09	6615-00-852-1611	GYROSCOPE, DISPLACEMENT	GE AVIATION SYSTEMS
124623-01-10	6615-00-951-9140	GYROSCOPE, DISPLACEMENT	GE AVIATION SYSTEMS
124623-01-12	6615-00-994-8940	GYROSCOPE, DISPLACEMENT	GE AVIATION SYSTEMS
12-514069-22	5965-00-755-4643	MICROPHONE, DYNAMIC	GENERAL DYNAMICS MISSION SYSTEMS
12677G-01 ITEM 16	5965-00-755-4643	MICROPHONE, DYNAMIC	DAVID CLARK
128C000	5965-00-755-4643	MICROPHONE, DYNAMIC	TELEPHONICS
128D000-1	5965-00-755-4643	MICROPHONE, DYNAMIC	TELEPHONICS
128D000-2	5965-00-755-4643	MICROPHONE, DYNAMIC	TELEPHONICS
128D003-1	5965-00-755-4643	MICROPHONE, DYNAMIC	TELEPHONICS
12DB-0594	4140-00-564-5980	FAN, CENTRIFUGAL	MOTOR MAGNETICS
1316940-1	6615-00-887-6721	GYROSCOPE, RATE OF TURN	HONEYWELL INTERNATIONAL
1320E3189-2	4320-00-930-5414	MOTOR, HYDRAULIC	EATON AEROSPACE
133258-2-1	1660-00-757-7908	TRANSDUCER, GAGE	HONEYWELL INTERNATIONAL
135070	6610-01-132-1898	INDICATOR, ATTITUDE DIRECTOR	ASTRONAUTICS
1356-512471	1650-00-516-6914	ACCUMULATOR ASSY, HYDRAULIC	PARKER-HANNIFIN
1356-542903	1650-00-584-9343	ACCUMULATOR ASSY, HYDRAULIC	PARKER-HANNIFIN
1356-552094	1650-00-516-6914	ACCUMULATOR ASSY, HYDRAULIC	PARKER-HANNIFIN
1356-552235	1650-00-516-6914	ACCUMULATOR ASSY, HYDRAULIC	PARKER-HANNIFIN
1356-563317	1650-00-767-2241	ACCUMULATOR ASSY, HYDRAULIC	PARKER-HANNIFIN
1356-583317	1650-00-877-6095	ACCUMULATOR ASSY, HYDRAULIC	PARKER-HANNIFIN
1356-633002	1650-00-767-2241	ACCUMULATOR ASSY, HYDRAULIC	PARKER-HANNIFIN
136601-01-03	6610-00-866-3234	INDICATOR, ATTITUDE DIRECTOR	GE AVIATION SYSTEMS
1374-598497	4810-00-887-4337	VALVE, SOLENOID, SHUTOFF	ROCKWELL COLLINS
137A-11	5985-01-092-5595	ANTENNA, LOOP, ADF	ROCKWELL COLLINS
137A-4	5985-00-985-9173	ANTENNA, LOOP, ADF	ROCKWELL COLLINS
137A-4A	5985-00-269-5364	ANTENNA, LOOP, ADF	ROCKWELL COLLINS
137A-5	5985-00-312-4577	ANTENNA, LOOP, ADF	ROCKWELL COLLINS
137A-5A	5985-01-144-6797	ANTENNA, LOOP, ADF	ROCKWELL COLLINS
137A6	5985-00-689-6576	ANTENNA, ADF	ROCKWELL COLLINS
137A-6	5985-00-689-6576	ANTENNA, LOOP, ADF	ROCKWELL COLLINS
137A-6A	5985-01-105-8719	ANTENNA, LOOP, ADF	ROCKWELL COLLINS



137A-6B	5985-00-617-7123	ANTENNA, LOOP, ADF	ROCKWELL COLLINS
137A-6C		ANTENNA, LOOP, ADF	ROCKWELL COLLINS
137A-6D		ANTENNA, LOOP, ADF	ROCKWELL COLLINS
1391-041046	6620-00-514-5334	INDICATOR, PRESSURE	KOLLSMAN
139602-01-01	6610-00-068-3464	INDICATOR, ATTITUDE DIRECTOR	GE AVIATION SYSTEMS
13V600-6	4820-00-978-8886	VALVE, NLG, SHUTTLE	HONEYWELL INTERNATIONAL
1426-1AE1	6610-00-230-8656	INDICATOR, AIR SPEED	CARLETON
1426-1AEA1	6610-00-230-8656	INDICATOR, AIR SPEED	CARLETON
1426-1BA1	6610-00-230-8669	INDICATOR, AIR SPEED	CARLETON
1426-1ZA1	6610-00-263-3076	INDICATOR, AIR SPEED	CARLETON
1426-2JA1	6610-00-190-1407	INDICATOR, AIR SPEED	CARLETON
1426-37AA6		INDICATOR, AIR SPEED	CARLETON
1426-37EA6		INDICATOR, AIR SPEED	CARLETON
1426-37FA6		INDICATOR, AIR SPEED	CARLETON
1426-37GA6		INDICATOR, AIR SPEED	CARLETON
1426-AEA1	6610-00-230-8656	INDICATOR, AIR SPEED	CARLETON
1432-22BAA1	6610-00-864-9966	INDICATOR, AIR SPEED	CARLETON
1432-22DBA1	6610-00-222-8956	INDICATOR, AIR SPEED	CARLETON
1463-55F-B55-1	6610-01-010-1746	INDICATOR, MACH AND TRUE AIR SPEED	CARLETON LIFE SUPPORT SYSTEMS
1463-55F-B55-4	6610-01-109-5605	INDICATOR, MACH AND TRUE AIR SPEED	CARLETON LIFE SUPPORT SYSTEMS
1463-55K-B55-1	6610-01-008-1653	INDICATOR, MACH AND TRUE AIR SPEED	CARLETON LIFE SUPPORT SYSTEMS
1463-55K-B55-2	6610-01-109-4841	INDICATOR, MACH AND TRUE AIR SPEED	CARLETON LIFE SUPPORT SYSTEMS
14711-200	1670-00-989-6799	LATCH ASSY, CONVEYOR	TELAIR
147930-01-01	6615-00-880-5033	GYROSCOPE, SWITCHING RATE	GE AVIATION SYSTEMS
147B13	6685-00-526-4559	INDICATOR, TEMPERATURE, ELECTRICAL RESISTANCE	HORIZON AEROSPACE
147B13A	6685-00-526-4559	INDICATOR, TEMPERATURE, ELECTRICAL RESISTANCE	HORIZON AEROSPACE
147B30	6685-00-557-0372	INDICATOR, TEMPERATURE, ELECTRICAL RESISTANCE	HORIZON AEROSPACE
147B30A	6685-00-526-7730	INDICATOR, TEMPERATURE, ELECTRICAL RESISTANCE	HORIZON AEROSPACE
147B31	6685-00-557-0370	INDICATOR, TEMPERATURE, ELECTRICAL RESISTANCE	HORIZON AEROSPACE
147B31A	6685-00-557-0370	INDICATOR, TEMPERATURE, ELECTRICAL RESISTANCE	HORIZON AEROSPACE
147B31A2	6685-00-557-0370	INDICATOR, TEMPERATURE, ELECTRICAL RESISTANCE	HORIZON AEROSPACE
147B31A3	6685-00-005-9025	INDICATOR, TEMPERATURE, ELECTRICAL RESISTANCE	HORIZON AEROSPACE
147B31A3-1	6685-00-005-9025	INDICATOR, TEMPERATURE, ELECTRICAL RESISTANCE	HORIZON AEROSPACE
147B31A4	6685-00-557-0370	INDICATOR, TEMPERATURE, ELECTRICAL RESISTANCE	HORIZON AEROSPACE
147B31B	6685-00-692-8341	INDICATOR, TEMPERATURE, ELECTRICAL RESISTANCE	HORIZON AEROSPACE
147B31C	6685-00-530-3321	INDICATOR, TEMPERATURE, ELECTRICAL RESISTANCE	HORIZON AEROSPACE
147B31F	6685-00-557-0370	INDICATOR, TEMPERATURE, ELECTRICAL RESISTANCE	HORIZON AEROSPACE
147B31G	6685-00-557-0370	INDICATOR, TEMPERATURE, ELECTRICAL RESISTANCE	HORIZON AEROSPACE
147B7	6685-00-553-4726	INDICATOR, TEMPERATURE, ELECTRICAL RESISTANCE	HORIZON AEROSPACE
147B7A	6685-00-553-4726	INDICATOR, TEMPERATURE, ELECTRICAL RESISTANCE	HORIZON AEROSPACE
147B8	6685-00-557-0370	INDICATOR, TEMPERATURE, ELECTRICAL RESISTANCE	HORIZON AEROSPACE
149452-01-01	6615-00-181-1879	GYROSCOPE, SWITCHING RATE	GE AVIATION SYSTEMS
15-0069-25	6220-01-304-4054	SPOTLIGHT	GRIMES AEROSPACE
1510309-901	5841-00-983-8393	GENERATOR, ELECTRONIC MARKER, RADAR	LOCKHEED MARTIN
1510310-901	6110-00-984-1438	CONTROL PANEL, GENERATOR	NORTHROP GRUMMAN SYSTEMS
1510310-910	6110-00-984-1438	CONTROL PANEL, GENERATOR	NORTHROP GRUMMAN SYSTEMS
15120-4	1630-00-887-4268	VALVE, BRAKE ACTUATOR	MOOG
1521BU4-02	6685-00-514-5061	INDICATOR, PRESSURE	KOLLSMAN
1521U4-02	6685-00-514-5061	INDICATOR, PRESSURE	KOLLSMAN
152B2	6685-00-557-5910	INDICATOR, ENGINE EXHAUST, TEMPERATURE	HORIZON AEROSPACE
152B22	6685-00-557-5910	INDICATOR, ENGINE EXHAUST, TEMPERATURE	HORIZON AEROSPACE
152B2A	6685-00-557-5910	INDICATOR, ENGINE EXHAUST, TEMPERATURE	HORIZON AEROSPACE
152B3		INDICATOR, ENGINE EXHAUST, TEMPERATURE	HORIZON AEROSPACE

152B4	6685-00-530-3614	INDICATOR, ENGINE EXHAUST, TEMPERATURE	HORIZON AEROSPACE
152B44	6685-00-530-3614	INDICATOR, ENGINE EXHAUST, TEMPERATURE	HORIZON AEROSPACE
152B5	6625-00-578-5584	INDICATOR, ENGINE EXHAUST, TEMPERATURE	HORIZON AEROSPACE
152B55	6625-00-578-5584	INDICATOR, ENGINE EXHAUST, TEMPERATURE	HORIZON AEROSPACE
1559-4-03	6620-00-526-5003	INDICATOR, ELECTRICAL TACHOMETER	KOLLSMAN
1559B4-05	6680-00-663-4206	INDICATOR, ELECTRICAL TACHOMETER	KOLLSMAN
1559C4-06	6620-00-556-1976	INDICATOR, ELECTRICAL TACHOMETER	KOLLSMAN
15647-1A	6615-00-800-2544	ACTUATOR, ELECTRO-MECHANICAL, ROTARY	KOLLSMAN
1570-041040	6620-00-514-5334	INDICATOR, PRESSURE	HONEYWELL INTERNATIONAL
1570B041040	6620-00-514-5334	INDICATOR, PRESSURE	KOLLSMAN
1570B-041040	6620-00-514-5334	INDICATOR, PRESSURE	KOLLSMAN
1570C041041	6620-00-514-5334	INDICATOR, PRESSURE	KOLLSMAN
1570C-041041	6620-00-514-5334	INDICATOR, PRESSURE	KOLLSMAN
15720-5	1630-00-887-1916	VALVE, BRAKE	MOOG
15868-1A	6615-00-887-6721	GYROSCOPE, RATE OF TURN	HONEYWELL INTERNATIONAL
15885-1B	6615-00-986-8995	GYROSCOPE, DISPLACEMENT	HONEYWELL INTERNATIONAL
15885-1C	6615-00-182-7698	GYROSCOPE, DISPLACEMENT	HONEYWELL INTERNATIONAL
15885-4C	6615-01-454-1463	GYROSCOPE, DISPLACEMENT	HONEYWELL INTERNATIONAL
1593-503	6220-00-299-4621	LIGHT, LANDING, AIRCRAFT	SPECIALTY LIGHTING
162B11		INDICATOR, TEMPERATURE, ELECTRICAL RESISTANCE	HORIZON AEROSPACE
162B2	6685-00-553-4726	INDICATOR, TEMPERATURE, ELECTRICAL RESISTANCE	HORIZON AEROSPACE
162B202	6250-00-299-5129	INDICATOR, TEMPERATURE, ELECTRICAL RESISTANCE	HORIZON AEROSPACE
162B202A	6685-00-553-4726	INDICATOR, TEMPERATURE, ELECTRICAL RESISTANCE	HORIZON AEROSPACE
162B203	6685-00-514-5327	INDICATOR, TEMPERATURE, ELECTRICAL RESISTANCE	HORIZON AEROSPACE
162B2A	6685-00-838-7429	INDICATOR, TEMPERATURE, ELECTRICAL RESISTANCE	HORIZON AEROSPACE
162B2G	6685-00-005-9024	INDICATOR, TEMPERATURE, ELECTRICAL RESISTANCE	HORIZON AEROSPACE
162B3	6685-01-484-9826	INDICATOR, TEMPERATURE, ELECTRICAL RESISTANCE	HORIZON AEROSPACE
162B3F	6685-00-514-5327	INDICATOR, TEMPERATURE, ELECTRICAL RESISTANCE	HORIZON AEROSPACE
162B4	6685-00-514-5328	INDICATOR, TEMPERATURE, ELECTRICAL RESISTANCE	HORIZON AEROSPACE
162B7	6685-00-553-4726	INDICATOR, TEMPERATURE, ELECTRICAL RESISTANCE	HORIZON AEROSPACE
162C007-1	5965-00-755-4643	MICROPHONE, DYNAMIC	TELEPHONICS
1630BU4-02	6605-00-551-8187	COMPASS, MAGNETIC, MOUNTED	KOLLSMAN
1630U4-03	6605-00-526-7253	COMPASS, MAGNETIC, MOUNTED	KOLLSMAN
1630U4-04	6605-00-514-3851	COMPASS, MAGNETIC, MOUNTED	KOLLSMAN
1630X4-03	6605-00-526-7252	COMPASS, MAGNETIC, MOUNTED	KOLLSMAN
164-1	6680-00-753-8932	INDICATOR, LIQUID QUANTITY	TRANSICOIL
16VC002-3	6610-01-222-6439	TRANSMITTER, ANGLE OF ATTACK	LOCKHEED MARTIN
16VE002001-1	6680-01-060-4248	INDICATOR, FUEL QUANTITY	LOCKHEED MARTIN
16VE002001-3	6680-01-060-4249	INDICATOR, FUEL QUANTITY	LOCKHEED MARTIN
16VF002-1	6610-01-114-6817	INDICATOR, ANGLE OF ATTACK	LOCKHEED MARTIN
16VF003-2	6620-01-060-3086	INDICATOR, ELECTRICAL, TACHOMETER	LOCKHEED MARTIN
16VF041-2	6610-01-395-3510	INDICATOR, VERTICAL VELOCITY	LOCKHEED MARTIN
16VF5004-1	6610-01-132-1898	INDICATOR, ATTITUDE DIRECTOR	LOCKHEED MARTIN
16VLO14001-4	1630-01-217-3141	SENSOR, WHEEL SPEED	LOCKHEED MARTIN
16VP009-3	4810-01-123-7254	VALVE, FLUID PRESSURE, REGULATING	LOCKHEED MARTIN
16VY007001-9	4810-01-154-3200	VALVE, REGULATING, FLUID PRESSURE	LOCKHEED MARTIN
16VY100-10	4810-01-130-7379	VALVE, REGULATING	LOCKHEED MARTIN
16VY103002-1	1660-01-057-5182	CONTROL BOX, AIR TEMPERATURE	LOCKHEED MARTIN
16VZ001-55	6615-00-137-6038	GYROSCOPE, RATE OF TURN	LOCKHEED MARTIN
16VZ001-8	6610-01-040-4430	INDICATOR, ANGLE OF ATTACK	LOCKHEED MARTIN
172-1704	6685-00-526-7864	TRANSMITTER, PRESSURE	HONEYWELL
172937-001	5930-01-113-3970	SWITCH, STEPPING	TELEDYNE CONTROLS
17861-7	4810-00-018-3826	VALVE, BUTTERFLY	SAIA-BURGESS

17862-7	4810-00-018-3825	VALVE, BUTTERFLY	TELEDYNE CONTROLS
179727-2	5996-00-764-6258	AMPLIFIER, ELECTRONIC TEMPERATURE DATUM	HONEYWELL INTERNATIONAL
179822-1	5996-00-691-0174	AMPLIFIER, ELECTRONIC TEMPERATURE DATUM	HONEYWELL INTERNATIONAL
18000-2	5826-00-032-7024	INDICATOR, BEARING-DISTANCE-HEADING	AIRCO
1801-1-A		COMPASS, MAGNETIC, MOUNTED	BE AEROSPACE
180-147	7330-00-532-5867	JUG, INSULATED	HONEYWELL AEROSPATIALE
1802529-1	6615-00-986-8995	GYROSCOPE, DISPLACEMENT	HONEYWELL INTERNATIONAL
18-1033	6695-00-628-8990	INDICATOR, POSITION	HONEYWELL INTERNATIONAL
18-1101	6620-00-514-5334	INDICATOR, PRESSURE	HONEYWELL INTERNATIONAL
1813-1-A		COMPASS, MAGNETIC, MOUNTED	HONEYWELL INTERNATIONAL
1813-1-B		COMPASS, MAGNETIC, MOUNTED	HONEYWELL AEROSPATIALE
18-1497	6620-00-999-2222	TRANSMITTER, PRESSURE	HONEYWELL INTERNATIONAL
18-1497-2	6620-00-999-2222	TRANSMITTER, PRESSURE	HONEYWELL INTERNATIONAL
18-1497-3	6620-00-999-2222	TRANSMITTER, PRESSURE	HONEYWELL INTERNATIONAL
18-1498	6620-00-999-2424	TRANSMITTER, PRESSURE	HONEYWELL INTERNATIONAL
18-1498-02	6620-00-999-2424	TRANSMITTER, PRESSURE	HONEYWELL INTERNATIONAL
18-1498-2	6620-00-999-2424	TRANSMITTER, PRESSURE	HONEYWELL INTERNATIONAL
18-1498-4	6620-00-999-2424	TRANSMITTER, PRESSURE	HONEYWELL INTERNATIONAL
18-1499	6620-00-999-2425	TRANSMITTER, PRESSURE	HONEYWELL INTERNATIONAL
18-1499-02	6620-00-999-2425	TRANSMITTER, PRESSURE	HONEYWELL INTERNATIONAL
18-1499-2	6620-00-999-2425	TRANSMITTER, PRESSURE	HONEYWELL INTERNATIONAL
18-1499-4	6620-00-999-2425	TRANSMITTER, PRESSURE	HONEYWELL INTERNATIONAL
18-1499-5		TRANSMITTER, PRESSURE	HONEYWELL INTERNATIONAL
18-1683	6685-00-133-7890	TRANSMITTER, PRESSURE	HONEYWELL INTERNATIONAL
18-1683-3	6620-00-754-7494	TRANSMITTER, PRESSURE	HONEYWELL INTERNATIONAL
18-1686-2	5826-00-032-7024	INDICATOR, BEARING-DISTANCE-HEADING	HONEYWELL INTERNATIONAL
18-1699	6620-00-553-8988	TRANSMITTER, PRESSURE	HONEYWELL INTERNATIONAL
181700-1	1660-00-909-4310	HEAT EXCHANGER, AIR TO AIR	HONEYWELL INTERNATIONAL
181700-1-1	1660-00-909-4310	HEAT EXCHANGER, AIR TO AIR	HONEYWELL INTERNATIONAL
181700-2-1	1660-01-437-8166	HEAT EXCHANGER, AIR TO AIR	HONEYWELL INTERNATIONAL
18-1704	6685-00-526-7864	TRANSMITTER, PRESSURE	HONEYWELL INTERNATIONAL
18-1718	6620-00-902-3688	TRANSMITTER, PRESSURE	HONEYWELL INTERNATIONAL
18-1718-2	6620-01-106-1311	TRANSMITTER, PRESSURE	HONEYWELL INTERNATIONAL
18-1718-3		TRANSMITTER, PRESSURE	HONEYWELL INTERNATIONAL
18-1718-3A	6620-01-067-8336	TRANSMITTER, PRESSURE	HONEYWELL INTERNATIONAL
18-1724	6620-00-901-7848	TRANSMITTER PRESSURE	HONEYWELL INTERNATIONAL
18-1724-2		TRANSMITTER, PRESSURE	HONEYWELL INTERNATIONAL
18-1724-3	6620-00-901-7848	TRANSMITTER PRESSURE	HONEYWELL INTERNATIONAL
18-1750-2		TRANSMITTER, PRESSURE	HONEYWELL INTERNATIONAL
18-1765	6685-00-615-9904	TRANSMITTER, PRESSURE	HONEYWELL INTERNATIONAL
18-1796	6620-00-115-2501	TRANSMITTER, PRESSURE	HONEYWELL INTERNATIONAL
18-18-14	6620-00-588-3576	TRANSMITTER, PRESSURE	HONEYWELL INTERNATIONAL
18-1814-2		TRANSMITTER, PRESSURE	HONEYWELL INTERNATIONAL
18-1815	6620-00-415-2768	TRANSMITTER, PRESSURE	HONEYWELL INTERNATIONAL
18-1815-2		TRANSMITTER, PRESSURE	HONEYWELL INTERNATIONAL
18181A	6605-00-663-5933	COMPASS, MAGNETIC, MOUNTED	HONEYWELL INTERNATIONAL
1818-1A	6605-00-663-5933	COMPASS, MAGNETIC, MOUNTED	HONEYWELL INTERNATIONAL
1818-1-A	6605-00-342-0799	COMPASS, MAGNETIC, MOUNTED	HONEYWELL INTERNATIONAL
18-1842-2		TRANSMITTER, PRESSURE	HONEYWELL INTERNATIONAL
18-1842-3	6620-01-029-5299	TRANSMITTER, PRESSURE	HONEYWELL INTERNATIONAL
18-1842-4		TRANSMITTER, PRESSURE	HONEYWELL INTERNATIONAL
18-1842-5	6620-01-096-5037	TRANSMITTER, PRESSURE	HONEYWELL INTERNATIONAL
18-1842-6	6620-01-130-2626	TRANSMITTER, PRESSURE	HONEYWELL INTERNATIONAL

18-1842-7		TRANSMITTER, PRESSURE	HONEYWELL INTERNATIONAL
18184A	6605-00-663-8511	COMPASS, MAGNETIC, MOUNTED	HONEYWELL INTERNATIONAL
1818-4-A	6605-00-663-8511	COMPASS, MAGNETIC, MOUNTED	HONEYWELL INTERNATIONAL
181880-1	1660-00-909-4309	HEAT EXCHANGER, AIR TO AIR	HONEYWELL AEROSPATIALE
181880-1-1	1660-00-909-4309	HEAT EXCHANGER, AIR TO AIR	HONEYWELL INTERNATIONAL
181880-2-1	1660-01-446-9327	HEAT EXCHANGER, AIR TO AIR	LOCKHEED MARTIN
18-1887	6620-01-034-0888	TRANSMITTER, PRESSURE	HONEYWELL INTERNATIONAL
18-1894		TRANSMITTER, PRESSURE	HONEYWELL INTERNATIONAL
18-2021	6620-00-514-5334	INDICATOR, PRESSURE	HONEYWELL INTERNATIONAL
18212A	6605-00-663-8523	COMPASS, MAGNETIC, MOUNTED	HONEYWELL INTERNATIONAL
1821-2A	6605-00-663-8523	COMPASS, MAGNETIC, MOUNTED	HONEYWELL INTERNATIONAL
1821-2-A	6605-00-663-8523	COMPASS, MAGNETIC, MOUNTED	HONEYWELL INTERNATIONAL
1822-1-A		COMPASS, MAGNETIC, MOUNTED	HONEYWELL AEROSPATIALE
1822-1-B		COMPASS, MAGNETIC, MOUNTED	HONEYWELL AEROSPATIALE
1822-1-C		COMPASS, MAGNETIC, MOUNTED	HONEYWELL AEROSPATIALE
18234A	6605-00-551-8187	COMPASS, MAGNETIC, MOUNTED	HONEYWELL AEROSPATIALE
1823-4A	6605-00-551-8187	COMPASS, MAGNETIC, MOUNTED	HONEYWELL INTERNATIONAL
1826-1-A		COMPASS, MAGNETIC, MOUNTED	HONEYWELL INTERNATIONAL
18282A	6605-00-348-5744	COMPASS, MAGNETIC, MOUNTED	HONEYWELL AEROSPATIALE
1828-2A	6605-00-348-5744	COMPASS, MAGNETIC, MOUNTED	HONEYWELL INTERNATIONAL
18-3106		TRANSMITTER, PRESSURE	HONEYWELL INTERNATIONAL
18-3106-2	6620-00-999-2222	TRANSMITTER, PRESSURE	HONEYWELL INTERNATIONAL
18-3108		TRANSMITTER, PRESSURE	HONEYWELL INTERNATIONAL
18-3108-2	6620-00-999-2424	TRANSMITTER, PRESSURE	HONEYWELL INTERNATIONAL
18-3110-2	6620-00-065-3235	TRANSMITTER, PRESSURE	HONEYWELL INTERNATIONAL
18-3112-2	6620-00-999-2425	TRANSMITTER, PRESSURE	HONEYWELL INTERNATIONAL
18-3114-2	6620-01-256-9703	TRANSMITTER, PRESSURE	HONEYWELL INTERNATIONAL
1831-1-A		COMPASS, MAGNETIC, MOUNTED	HONEYWELL INTERNATIONAL
1832-1-A		COMPASS, MAGNETIC, MOUNTED	HONEYWELL AEROSPATIALE
1832-3-A	6605-00-663-5950	COMPASS, MAGNETIC, MOUNTED	HONEYWELL AEROSPATIALE
1833-1-A	6605-00-663-5946	COMPASS, MAGNETIC, MOUNTED	HONEYWELL AEROSPATIALE
18401A	6605-00-514-5746	COMPASS, MAGNETIC, MOUNTED	HONEYWELL AEROSPATIALE
1840-1A	6605-00-514-5746	COMPASS, MAGNETIC, MOUNTED	HONEYWELL INTERNATIONAL
18402A	6605-00-514-5746	COMPASS, MAGNETIC, MOUNTED	HONEYWELL INTERNATIONAL
1840-2A	6605-00-514-5746	COMPASS, MAGNETIC, MOUNTED	HONEYWELL INTERNATIONAL
18412A	6605-00-551-8187	COMPASS, MAGNETIC, MOUNTED	HONEYWELL INTERNATIONAL
1841-2A	6605-00-551-8187	COMPASS, MAGNETIC, MOUNTED	HONEYWELL INTERNATIONAL
18412B	6605-00-551-8187	COMPASS, MAGNETIC, MOUNTED	HONEYWELL INTERNATIONAL
1841-2B	6605-00-551-8187	COMPASS, MAGNETIC, MOUNTED	HONEYWELL INTERNATIONAL
1845X4-03	6610-00-388-0030	ALTIMETER, PRESSURE	KOLLSMAN
1845X4-03D	6610-00-526-6081	ALTIMETER, PRESSURE	KOLLSMAN
1845X4-03DF	6610-00-179-2197	ALTIMETER, PRESSURE	KOLLSMAN
18-4797-3		TRANSMITTER, PRESSURE	HONEYWELL INTERNATIONAL
18923G-01	5965-00-755-4643	MICROPHONE, DYNAMIC	M/A-COM PRIVATE RADIO SYSTEMS
190772-2	2915-00-626-3123	VALVE, FUEL SYSTEM	HONEYWELL INTERNATIONAL
19-20-281	6610-00-580-9690	INDICATOR, RUDDER, POSITION	PENN KEYSTONE
19-20-9	6610-00-515-4600	INDICATOR, FLAP, POSITION	PENN KEYSTONE
19A513	4140-00-564-5980	FAN, CENTRIFUGAL	GLOBE MOTORS
1G107	5930-00-615-7340	SWITCH, PRESSURE	CUSTOM CONTROL SENSORS
1U028-005-047	6620-01-143-2180	GAGE, FUEL FLOW	SIGMA TEK
1VC1001-1L	1680-00-671-3837	SEAT, AIRCRAFT, TROOPS	NEWGARD INDUSTRIES
1VC1001-1R	1680-00-671-2101	SEAT, AIRCRAFT, TROOPS	NEWGARD INDUSTRIES
20000500289-003	1660-01-408-7708	CONTROLLER, AIR PRESSURE, AIRCRAFT CABIN	BOEING

200-069-002	6620-01-060-3086	INDICATOR, ELECTRICAL, TACHOMETER	PARKER-HANNIFIN
200-069-003	6620-01-178-7838	INDICATOR, ELECTRICAL, TACHOMETER	PARKER-HANNIFIN
200F-5003	2915-MD-003-2382	PUMP, FUEL	HARTZELL ENGINE TECHNOLOGIES
200F-5003R	2915-MD-003-2382	PUMP, FUEL	HARTZELL ENGINE TECHNOLOGIES
201-004-001	6620-01-038-5801	INDICATOR, TORQUEMETER	PARKER-HANNIFIN
2012273-01	6645-00-950-8599	CLOCK, MECHANICAL, PANEL	L3 TECHNOLOGIES
20140-0351	6610-00-006-5783	INDICATOR, MACH AND TRUE AIR SPEED	AEROSONIC
2015-10-01	6605-00-390-8429	COMPASS, MAGNETIC, MOUNTED	KOLLSMAN
201F-5007	2915-MD-040-3652	PUMP, FUEL	HARTZELL ENGINE TECHNOLOGIES
201F-5007R	2915-01-520-7874	PUMP, FUEL	HARTZELL ENGINE TECHNOLOGIES
20-224-01	6680-01-290-5920	INDICATOR, PRIMARY, FUEL QUANTITY	GE AVIATION SYSTEMS
20-225-01	6680-01-290-7552	INDICATOR, REPEATER, FUEL QUANTITY	GE AVIATION SYSTEMS
20-226-01	6680-01-291-4271	INDICATOR, TOTALIZER, FUEL QUANTITY	GE AVIATION SYSTEMS
2039287-01	5965-00-755-4643	MICROPHONE, DYNAMIC	RAYTHEON TECHNICAL SERVICES
2041232-1104	6210-01-408-7389	INDICATOR, WEATHER, RADAR	HONEYWELL INTERNATIONAL
2041440-0101	5985-01-089-0737	ANTENNA, WEATHER, RADAR	HONEYWELL INTERNATIONAL
2041440-0102		ANTENNA, WEATHER, RADAR	HONEYWELL INTERNATIONAL
2041440-0104	5985-01-194-2321	ANTENNA, WEATHER, RADAR	HONEYWELL INTERNATIONAL
2041440-0106	5985-01-315-0315	ANTENNA, WEATHER, RADAR	HONEYWELL INTERNATIONAL
206400-7-1	4310-01-296-0634	COMPRESSOR, ROTARY	HONEYWELL INTERNATIONAL
206400-7-1A	4310-01-296-0634	COMPRESSOR, ROTARY	HONEYWELL INTERNATIONAL
206400-7-2	4310-01-296-0634	COMPRESSOR, ROTARY	HONEYWELL INTERNATIONAL
2070409-0101	5985-01-408-7393	ANTENNA, WEATHER, RADAR	HONEYWELL INTERNATIONAL
2070409-0103		ANTENNA, WEATHER, RADAR	HONEYWELL INTERNATIONAL
2070409-0108		ANTENNA, WEATHER, RADAR	HONEYWELL INTERNATIONAL
2070410-0101	5821-01-408-7392	TRANSCEIVER, WEATHER, RADAR	HONEYWELL INTERNATIONAL
2070410-0102		TRANSCEIVER, WEATHER, RADAR	HONEYWELL INTERNATIONAL
2070410-0103		TRANSCEIVER, WEATHER, RADAR	HONEYWELL INTERNATIONAL
2070410-0105		TRANSCEIVER, WEATHER, RADAR	HONEYWELL INTERNATIONAL
2070410-0106		TRANSCEIVER, WEATHER, RADAR	HONEYWELL INTERNATIONAL
2070410-0108		TRANSCEIVER, WEATHER, RADAR	HONEYWELL INTERNATIONAL
2070410-0110		TRANSCEIVER, WEATHER, RADAR	HONEYWELL INTERNATIONAL
2070410-0111		TRANSCEIVER, WEATHER, RADAR	HONEYWELL INTERNATIONAL
2070410-0112		TRANSCEIVER, WEATHER, RADAR	HONEYWELL INTERNATIONAL
2070410-0113		TRANSCEIVER, WEATHER, RADAR	HONEYWELL INTERNATIONAL
2070410-0151		TRANSCEIVER, WEATHER, RADAR	HONEYWELL INTERNATIONAL
2070410-0152		TRANSCEIVER, WEATHER, RADAR	HONEYWELL INTERNATIONAL
2070410-0153		TRANSCEIVER, WEATHER, RADAR	HONEYWELL INTERNATIONAL
2070410-0156		TRANSCEIVER, WEATHER, RADAR	HONEYWELL INTERNATIONAL
2070410-0158		TRANSCEIVER, WEATHER, RADAR	HONEYWELL INTERNATIONAL
2070410-0163		TRANSCEIVER, WEATHER, RADAR	HONEYWELL INTERNATIONAL
2070963-0101	5841-01-305-1921	TRANSCEIVER, WEATHER, RADAR	HONEYWELL INTERNATIONAL
2070963-0102	5841-01-091-8929	TRANSCEIVER, WEATHER, RADAR	HONEYWELL INTERNATIONAL
2070963-0103		TRANSCEIVER, WEATHER, RADAR	HONEYWELL INTERNATIONAL
2070963-0104	5841-01-194-2452	TRANSCEIVER, WEATHER, RADAR	HONEYWELL INTERNATIONAL
2070963-0105	5841-01-314-9947	TRANSCEIVER, WEATHER, RADAR	HONEYWELL INTERNATIONAL
2070964-0106	5841-01-193-6436	INDICATOR, WEATHER, RADAR	HONEYWELL INTERNATIONAL
2070964-0107	5841-01-314-9991	INDICATOR, WEATHER, RADAR	HONEYWELL INTERNATIONAL
208-013-005	6620-01-276-9825	INDICATOR, TEMPERATURE, FAN TURBINE INLET	PARKER-HANNIFIN
20B95-4A	6110-01-109-5099	REGULATOR, VOLTAGE	ALLIED SIGNAL
2109-5	6685-01-112-9094	ALTIMETER, PRESSURIZED COMPARTMENT	KEARFLEX ENGINEERING
211-009-005	6680-01-342-7698	INDICATOR, FUEL QUANTITY	PARKER HANNIFIN
2-1109	1630-00-927-1773	BRAKE, MULTIPLE DISK	GOODRICH

2118-364	6610-01-391-9062	ACCELEROMETER, MECHANICAL	Q.E.D.
2119-001	6610-00-585-5929	ACCELEROMETER, MECHANICAL	BURTON MEDICAL PRODUCTS
2119-001-1		ACCELEROMETER, MECHANICAL	BURTON MEDICAL PRODUCTS
2119-001-2	6610-00-585-1355	ACCELEROMETER, MECHANICAL	BURTON MEDICAL PRODUCTS
2119-001-3	6610-00-684-1666	ACCELEROMETER, MECHANICAL	BURTON MEDICAL PRODUCTS
2119-500	6610-00-007-1030	ACCELEROMETER, MECHANICAL	Q.E.D.
21-545	5945-00-628-6484	RELAY, HYBRID	TE CONNECTIVITY
2159K	6615-00-880-5033	GYROSCOPE, SWITCHING RATE	GE AVIATION SYSTEMS
2159T	6615-00-181-1879	GYROSCOPE, SWITCHING RATE	GE AVIATION SYSTEMS
216-080-001	5965-00-755-4643	MICROPHONE, DYNAMIC	ROANWELL
219A967	1630-00-914-1329	WHEEL, NOSE LANDING GEAR	JAY-EM AEROSPACE
219A967-1	1630-00-914-1329	WHEEL, NOSE LANDING GEAR	JAY-EM AEROSPACE
21B18-1B	6110-00-060-6811	REGULATOR, VOLTAGE	HONEYWELL INTERNATIONAL
21B18-1C	6110-00-060-6811	REGULATOR, VOLTAGE	HONEYWELL INTERNATIONAL
21B18-5-A	6110-01-017-5428	REGULATOR, VOLTAGE	HONEYWELL INTERNATIONAL
21C1577-46	6680-00-959-7632	GENERATOR, TACHOMETER	AMETEK
2200440-7-3	1660-01-275-5646	REFRIGERATOR, AIR CYCLE	HONEYWELL INTERNATIONAL
22055-1FAP.CN1	5826-MD-010-2387	INDICATOR, RADIO MAGNETIC	CINAVE
2221-1	6605-00-663-5630	COMPASS, MAGNETIC, MOUNTED	AMETEK
224.000.000	5965-00-755-4643	MICROPHONE, DYNAMIC	ELNO
229255-3		VALVE, REGULATING	MEGGITT
229255-4	4810-01-130-7379	VALVE, REGULATING	MEGGITT
2311M-135-2	6105-00-601-6426	MOTOR, DIRECT CURRENT	ROSEMOUNT AEROSPACE
2311M-28-1	6105-00-630-5828	MOTOR, DIRECT CURRENT	ROSEMOUNT AEROSPACE
23410-3	1630-00-998-7897	VALVE, BRAKE CONTROL	EATON
239-001	6625-01-412-3365	METER, ELECTRICAL FREQUENCY	JEWELL INSTRUMENTS
23932-001		ALTIMETER, PRESSURE	EDO
23932-002		ALTIMETER, PRESSURE	KOLLSMAN
23932-003	6610-01-009-8021	ALTIMETER, PRESSURE	KOLLSMAN
23932-004	6660-01-020-3765	ALTIMETER, PRESSURE	KOLLSMAN
23932-005	6660-01-020-3765	ALTIMETER, PRESSURE	KOLLSMAN
23932-006		ALTIMETER, PRESSURE	KOLLSMAN
23932-008		ALTIMETER, PRESSURE	KOLLSMAN
23932-011		ALTIMETER, PRESSURE	KOLLSMAN
23932-012	6610-01-074-2819	ALTIMETER, PRESSURE	KOLLSMAN
23932-013		ALTIMETER, PRESSURE	KOLLSMAN
23932-014		ALTIMETER, PRESSURE	KOLLSMAN
23932-021		ALTIMETER, PRESSURE	KOLLSMAN
23932-022		ALTIMETER, PRESSURE	KOLLSMAN
23932-023		ALTIMETER, PRESSURE	KOLLSMAN
23932-024		ALTIMETER, PRESSURE	KOLLSMAN
23932-031		ALTIMETER, PRESSURE	KOLLSMAN
23932-032		ALTIMETER, PRESSURE	KOLLSMAN
23932-033		ALTIMETER, PRESSURE	KOLLSMAN
23932-034		ALTIMETER, PRESSURE	KOLLSMAN
23932-201		ALTIMETER, PRESSURE	KOLLSMAN
23932-202		ALTIMETER, PRESSURE	KOLLSMAN
23932-203		ALTIMETER, PRESSURE	KOLLSMAN
23932-204		ALTIMETER, PRESSURE	KOLLSMAN
23932-211		ALTIMETER, PRESSURE	KOLLSMAN
23932-212		ALTIMETER, PRESSURE	KOLLSMAN
23932-213		ALTIMETER, PRESSURE	KOLLSMAN
23932-214		ALTIMETER, PRESSURE	KOLLSMAN

23932-301		ALTIMETER, PRESSURE	KOLLSMAN
23932-302		ALTIMETER, PRESSURE	KOLLSMAN
23932-303		ALTIMETER, PRESSURE	KOLLSMAN
23932-304		ALTIMETER, PRESSURE	KOLLSMAN
23932-311		ALTIMETER, PRESSURE	KOLLSMAN
23932-312		ALTIMETER, PRESSURE	KOLLSMAN
23932-313		ALTIMETER, PRESSURE	KOLLSMAN
23932-314		ALTIMETER, PRESSURE	KOLLSMAN
23932-401		ALTIMETER, PRESSURE	KOLLSMAN
23932-402		ALTIMETER, PRESSURE	KOLLSMAN
23932-403		ALTIMETER, PRESSURE	KOLLSMAN
23932-404		ALTIMETER, PRESSURE	KOLLSMAN
23932-411		ALTIMETER, PRESSURE	KOLLSMAN
23932-412		ALTIMETER, PRESSURE	KOLLSMAN
23932-413		ALTIMETER, PRESSURE	KOLLSMAN
23932-414	6610-01-294-5633	ALTIMETER, PRESSURE	KOLLSMAN
23932-901	6610-01-329-9067	ALTIMETER, PRESSURE	KOLLSMAN
23932-902		ALTIMETER, PRESSURE	KOLLSMAN
2430-87-00	5985-01-324-6246	ANTENNA	KOLLSMAN
250A200	1630-01-188-6735	WHEEL, MAIN LANDING GEAR	JAY-EM AEROSPACE
250A2001LC	1630-01-188-6735	WHEEL, MAIN LANDING GEAR	JAY-EM AEROSPACE
250A200-1LC	1630-01-188-6735	WHEEL, MAIN LANDING GEAR	JAY-EM AEROSPACE
25100A15A1B1	6620-00-514-5334	INDICATOR, PRESSURE	HONEYWELL INTERNATIONAL
25200A15A1-1A1	6620-00-514-5334	INDICATOR, PRESSURE	HONEYWELL INTERNATIONAL
25200A15B1-1A1	6620-00-514-5334	INDICATOR, PRESSURE	HONEYWELL INTERNATIONAL
25201A15B2-1A1	6620-00-514-5334	INDICATOR, PRESSURE	HONEYWELL INTERNATIONAL
25201A15B4-1A1	6620-00-514-5334	INDICATOR, PRESSURE	HONEYWELL INTERNATIONAL
25201-A15B-4-1C2	6620-00-514-5334	INDICATOR, PRESSURE	HONEYWELL INTERNATIONAL
25201A15C7-2B2	6620-00-514-5334	INDICATOR, PRESSURE	HONEYWELL INTERNATIONAL
25530562-01	6685-01-119-6546	THERMOSTAT, FLOW CONTROL	VAPOR CORP
25530562-02	6685-00-670-0895	THERMOSTAT, FLOW CONTROL	VAPOR CORP
25615-C27A-26-A1	6685-00-868-5858	INDICATOR, PRESSURE	HONEYWELL INTERNATIONAL
25730032-02		VALVE, SOLENOID CONTROLLED, SHUT-OFF	MEGGITT
25730032-03		VALVE, SOLENOID CONTROLLED, SHUT-OFF	MEGGITT
25730032-04	4810-00-730-2852	VALVE, SOLENOID CONTROLLED, SHUT-OFF	MEGGITT
25730043-02		VALVE, SOLENOID CONTROLLED, SHUT-OFF	MEGGITT
25730043-03	4810-00-730-3551	VALVE, SOLENOID CONTROLLED, SHUT-OFF	MEGGITT
257C000	5965-00-765-4643	MICROPHONE, DYNAMIC	TELEPHONICS
2586261-1	6605-00-447-9665	CONTROLLER, DIGITAL	HONEYWELL INTERNATIONAL
2586261-2		CONTROLLER, DIGITAL	HONEYWELL INTERNATIONAL
2586333-1	6615-00-447-9683	GYROSCOPE, DIRECCIONAL	HONEYWELL INTERNATIONAL
2586333-2	6615-00-180-0895	GYROSCOPE, DIRECCIONAL	HONEYWELL INTERNATIONAL
2586333-3	6615-01-065-7226	GYROSCOPE, DIRECCIONAL	HONEYWELL INTERNATIONAL
2586384-1	5895-00-447-9688	AMPLIFIER, POWER SUPPLY	HONEYWELL INTERNATIONAL
2586384-2		AMPLIFIER, POWER SUPPLY	HONEYWELL INTERNATIONAL
2589226-1	6605-00-999-2411	AMPLIFIER, POWER SUPPLY	HONEYWELL INTERNATIONAL
26130010-01	4810-00-987-3948	VALVE, SOLENOID, SHUT-OFF	HAMILTON SUNDSTRAND
26130010-01A		VALVE, SOLENOID, SHUT-OFF	HAMILTON SUNDSTRAND
26130011-01	4810-01-206-6309	VALVE, SOLENOID, SHUT-OFF	HAMILTON SUNDSTRAND
261D1644	5985-01-015-0737	ANTENNA	EDO
270-2261-010	6685-00-526-7864	TRANSMITTER, PRESSURE	ROCKWELL COLLINS
270-2494-010		GYROSCOPE, ROTATING	ROCKWELL COLLINS
270-2494-020		GYROSCOPE, ROTATING	ROCKWELL COLLINS

27231317		CONTROL BOX, TEMPERATURE	HAMILTON SUNDSTRAND
27231317-01	1660-01-014-4509	CONTROL BOX, TEMPERATURE	HAMILTON SUNDSTRAND
27231318	1660-01-021-4981	CONTROL BOX, TEMPERATURE	HAMILTON SUNDSTRAND
27231318-01	1660-01-021-4981	CONTROL BOX, TEMPERATURE	VAPOR BRUNSWICK
272-41-301	4820-00-006-5087	VALVE, ENGINE, BLEED AIR, CHECK	VAPOR
272B308042	6220-00-299-4621	LIGHT, LANDING, AIRCRAFT	MARTIN AIRCRAFT TOOL
273-0013-00	5965-01-127-3890	HEADSET, MICROPHONE	ROANWELL
273-0013-000	5965-01-127-3890	HEADSET, MICROPHONE	ROANWELL
27431466-01	1660-01-003-6297	CONTROL BOX, TEMPERATURE	VAPOR BRUNSWICK
275540-003	6655-01-283-0303	INDICATOR, MAGNETIC VARIATION	B V R TECHNOLOGIES
276-5324-002	6615-01-038-8080	LIGHT ASSY, INDICATOR	KORRY ELECTRONICS
28002-001	6140-00-283-7855	BATTERY, INU, STORAGE	MARATHONNORCO AEROSPACE
28007-001		ALTIMETER, ENCODING	KOLLSMAN
28007-002	6610-01-121-9627	ALTIMETER, ENCODING	KOLLSMAN
28007-003		ALTIMETER, ENCODING	KOLLSMAN
28007-004		ALTIMETER, ENCODING	KOLLSMAN
28007-005		ALTIMETER, ENCODING	KOLLSMAN
28007-006		ALTIMETER, ENCODING	KOLLSMAN
28007-007		ALTIMETER, ENCODING	KOLLSMAN
28007-008		ALTIMETER, ENCODING	KOLLSMAN
28007-009		ALTIMETER, ENCODING	KOLLSMAN
28007-010		ALTIMETER, ENCODING	KOLLSMAN
28007-011		ALTIMETER, ENCODING	KOLLSMAN
28007-012		ALTIMETER, ENCODING	KOLLSMAN
28007-013		ALTIMETER, ENCODING	KOLLSMAN
28007-014		ALTIMETER, ENCODING	KOLLSMAN
28007-015		ALTIMETER, ENCODING	KOLLSMAN
28007-016		ALTIMETER, ENCODING	KOLLSMAN
28007-017		ALTIMETER, ENCODING	KOLLSMAN
28007-018		ALTIMETER, ENCODING	KOLLSMAN
28007-019		ALTIMETER, ENCODING	KOLLSMAN
28007-020		ALTIMETER, ENCODING	KOLLSMAN
28007-021		ALTIMETER, ENCODING	KOLLSMAN
28007-022		ALTIMETER, ENCODING	KOLLSMAN
28007-023		ALTIMETER, ENCODING	KOLLSMAN
28007-024		ALTIMETER, ENCODING	KOLLSMAN
28007-025		ALTIMETER, ENCODING	KOLLSMAN
28007-026		ALTIMETER, ENCODING	KOLLSMAN
28007-027		ALTIMETER, ENCODING	KOLLSMAN
28007-028		ALTIMETER, ENCODING	KOLLSMAN
28007-029		ALTIMETER, ENCODING	KOLLSMAN
28007-030		ALTIMETER, ENCODING	KOLLSMAN
28007-171		ALTIMETER, ENCODING	KOLLSMAN
28007-172		ALTIMETER, ENCODING	KOLLSMAN
28007-173		ALTIMETER, ENCODING	KOLLSMAN
28007-174	6610-01-346-5592	ALTIMETER, ENCODING	KOLLSMAN
28007-175		ALTIMETER, ENCODING	KOLLSMAN
28007-176		ALTIMETER, ENCODING	KOLLSMAN
28007-177		ALTIMETER, ENCODING	KOLLSMAN
28007-178		ALTIMETER, ENCODING	KOLLSMAN
28007-201		ALTIMETER, ENCODING	KOLLSMAN
28007-202		ALTIMETER, ENCODING	KOLLSMAN
28007-203		ALTIMETER, ENCODING	KOLLSMAN



## CAPABILITY LIST

28007-204	6610-01-259-0251	ALTIMETER, ENCODING	KOLLSMAN
28007-205		ALTIMETER, ENCODING	KOLLSMAN
28007-206		ALTIMETER, ENCODING	KOLLSMAN
28007-207		ALTIMETER, ENCODING	KOLLSMAN
28007-208		ALTIMETER, ENCODING	KOLLSMAN
28007-209		ALTIMETER, ENCODING	KOLLSMAN
28007-210		ALTIMETER, ENCODING	KOLLSMAN
28007-211		ALTIMETER, ENCODING	KOLLSMAN
28007-212		ALTIMETER, ENCODING	KOLLSMAN
28007-213		ALTIMETER, ENCODING	KOLLSMAN
28007-214		ALTIMETER, ENCODING	KOLLSMAN
28007-215		ALTIMETER, ENCODING	KOLLSMAN
28007-216		ALTIMETER, ENCODING	KOLLSMAN
28007-217		ALTIMETER, ENCODING	KOLLSMAN
28007-218		ALTIMETER, ENCODING	KOLLSMAN
28007-223		ALTIMETER, ENCODING	KOLLSMAN
28007-224		ALTIMETER, ENCODING	KOLLSMAN
28007-225		ALTIMETER, ENCODING	KOLLSMAN
28007-226		ALTIMETER, ENCODING	KOLLSMAN
28007-227		ALTIMETER, ENCODING	KOLLSMAN
28007-228		ALTIMETER, ENCODING	KOLLSMAN
28007-229		ALTIMETER, ENCODING	KOLLSMAN
28007-230		ALTIMETER, ENCODING	KOLLSMAN
28007-231		ALTIMETER, ENCODING	KOLLSMAN
28007-232		ALTIMETER, ENCODING	KOLLSMAN
28007-233		ALTIMETER, ENCODING	KOLLSMAN
28007-234		ALTIMETER, ENCODING	KOLLSMAN
28007-235		ALTIMETER, ENCODING	KOLLSMAN
28007-261		ALTIMETER, ENCODING	KOLLSMAN
28007-262		ALTIMETER, ENCODING	KOLLSMAN
28007-263		ALTIMETER, ENCODING	KOLLSMAN
28007-264		ALTIMETER, ENCODING	KOLLSMAN
28007-265		ALTIMETER, ENCODING	KOLLSMAN
28007-266		ALTIMETER, ENCODING	KOLLSMAN
28007-267		ALTIMETER, ENCODING	KOLLSMAN
28007-268		ALTIMETER, ENCODING	KOLLSMAN
28007-269		ALTIMETER, ENCODING	KOLLSMAN
28007-270		ALTIMETER, ENCODING	KOLLSMAN
28007-271		ALTIMETER, ENCODING	KOLLSMAN
28007-272		ALTIMETER, ENCODING	KOLLSMAN
28007-301		ALTIMETER, ENCODING	KOLLSMAN
28007-302		ALTIMETER, ENCODING	KOLLSMAN
28007-303		ALTIMETER, ENCODING	KOLLSMAN
28007-304		ALTIMETER, ENCODING	KOLLSMAN
28007-305		ALTIMETER, ENCODING	KOLLSMAN
28007-306		ALTIMETER, ENCODING	KOLLSMAN
28007-307		ALTIMETER, ENCODING	KOLLSMAN
28007-308		ALTIMETER, ENCODING	KOLLSMAN
28007-309		ALTIMETER, ENCODING	KOLLSMAN
28007-310		ALTIMETER, ENCODING	KOLLSMAN
28007-311		ALTIMETER, ENCODING	KOLLSMAN
28007-312		ALTIMETER, ENCODING	KOLLSMAN
28007-313		ALTIMETER, ENCODING	KOLLSMAN

28007-314		ALTIMETER, ENCODING	KOLLSMAN
28007-315		ALTIMETER, ENCODING	KOLLSMAN
28007-316		ALTIMETER, ENCODING	KOLLSMAN
28007-317		ALTIMETER, ENCODING	KOLLSMAN
28007-318		ALTIMETER, ENCODING	KOLLSMAN
28007-319		ALTIMETER, ENCODING	KOLLSMAN
28007-320		ALTIMETER, ENCODING	KOLLSMAN
28007-321		ALTIMETER, ENCODING	KOLLSMAN
28007-322		ALTIMETER, ENCODING	KOLLSMAN
28007-323		ALTIMETER, ENCODING	KOLLSMAN
28007-324		ALTIMETER, ENCODING	KOLLSMAN
28007-325		ALTIMETER, ENCODING	KOLLSMAN
28007-326		ALTIMETER, ENCODING	KOLLSMAN
28007-327		ALTIMETER, ENCODING	KOLLSMAN
28007-328		ALTIMETER, ENCODING	KOLLSMAN
28007-329		ALTIMETER, ENCODING	KOLLSMAN
28007-330		ALTIMETER, ENCODING	KOLLSMAN
28007-331		ALTIMETER, ENCODING	KOLLSMAN
28007-332		ALTIMETER, ENCODING	KOLLSMAN
28007-333		ALTIMETER, ENCODING	KOLLSMAN
28007-334		ALTIMETER, ENCODING	KOLLSMAN
28007-335		ALTIMETER, ENCODING	KOLLSMAN
28007-336		ALTIMETER, ENCODING	KOLLSMAN
28007-337		ALTIMETER, ENCODING	KOLLSMAN
28007-338		ALTIMETER, ENCODING	KOLLSMAN
28007-339		ALTIMETER, ENCODING	KOLLSMAN
28007-340		ALTIMETER, ENCODING	KOLLSMAN
28007-341		ALTIMETER, ENCODING	KOLLSMAN
28007-342		ALTIMETER, ENCODING	KOLLSMAN
28007-343		ALTIMETER, ENCODING	KOLLSMAN
28007-344		ALTIMETER, ENCODING	KOLLSMAN
28007-345		ALTIMETER, ENCODING	KOLLSMAN
28007-346		ALTIMETER, ENCODING	KOLLSMAN
28007-347		ALTIMETER, ENCODING	KOLLSMAN
28007-700		ALTIMETER, ENCODING	KOLLSMAN
28007-800		ALTIMETER, ENCODING	KOLLSMAN
28007-906		ALTIMETER, ENCODING	KOLLSMAN
28007-907		ALTIMETER, ENCODING	KOLLSMAN
28007-921		ALTIMETER, ENCODING	KOLLSMAN
28007-922		ALTIMETER, ENCODING	KOLLSMAN
28B95-65A	6115-01-053-7272	GENERATOR, A/C	COOPER INDUSTRIES
28VS200Y4	6130-00-566-0347	POWER CONVERTER, AC/DC	HONEYWELL INTERNATIONAL
28VS200Y-4	6130-00-566-0347	POWER CONVERTER, AC/DC	COOPER INDUSTRIES
28VS200Y4A	6130-00-164-4224	POWER CONVERTER, AC/DC	COOPER INDUSTRIES
28VS200Y-4A	6120-01-591-0842	POWER CONVERTER, AC/DC	COOPER INDUSTRIES
28YBL100A1	6130-00-314-0050	POWER CONVERTER, AC/DC	COOPER INDUSTRIES
28YBL100A-1	6130-00-314-0050	POWER CONVERTER, AC/DC	COOPER INDUSTRIES
28YBL100A1A	6130-00-314-0050	POWER CONVERTER, AC/DC	CHAMPION AEROSPACE
28YBL100A-1A	6130-00-314-0050	POWER CONVERTER, AC/DC	CHAMPION AEROSPACE
2A1991-313	5985-00-588-2822	ANTENNA, LOOP	KEARFOTT
2B6-6	2910-01-143-0195	PUMP, FUEL, ELECTRICAL	PARKER HANNIFIN
2C1565-91A	5826-00-234-6315	INDICATOR, BEARING	KEARFOTT
2C1565-92	5826-00-505-0968	INDICATOR, BEARING	KOLLSMAN

2C666-149	5895-00-247-3004	CONTROL BOX, RECEIVER	BAE SYSTEMS
2CM9AAA1	6680-00-815-1905	GENERATOR, TACHOMETER	AMETEK
2CM9AAA2	6680-00-815-1905	GENERATOR, TACHOMETER	AMETEK
2CM9AAA6	6680-00-815-1905	GENERATOR, TACHOMETER	AMETEK
2CM9AAC6	6680-00-959-7632	GENERATOR, TACHOMETER	AMETEK
2CM9AAH4	6680-00-445-1246	GENERATOR, TACHOMETER	AMETEK
2CM9AAV6		GENERATOR, TACHOMETER	AMETEK
2CM9AAZ6	6680-00-034-0505	GENERATOR, TACHOMETER	AMETEK
2CM9ABE6	6680-01-122-6960	GENERATOR, TACHOMETER	AMETEK
2CM9ABH7		GENERATOR, TACHOMETER	AMETEK
2CM9ABK7	6680-01-358-9820	GENERATOR, TACHOMETER	AMETEK
2CM9ABY7	6680-00-920-9213	GENERATOR, TACHOMETER	AMETEK
2CM9ABZ7	6680-01-397-6175	GENERATOR, TACHOMETER	AMETEK
2CM9ACE7	6680-00-406-4280	GENERATOR, TACHOMETER	AMETEK
2CM9ACF8	6680-00-923-8466	GENERATOR, TACHOMETER	AMETEK
2CM9ACH7		GENERATOR, TACHOMETER	AMETEK
2CM9ADB9		GENERATOR, TACHOMETER	AMETEK
2CM9ADE8	6680-00-008-4544	GENERATOR, TACHOMETER	AMETEK
2CM9ADT6		GENERATOR, TACHOMETER	AMETEK
2VC1002-1C	1680-00-782-5861	SEAT, AIRCRAFT, TROOPS	NEWGARD INDUSTRIES
2VC1002-1L	1680-00-913-4840	SEAT, AIRCRAFT, TROOPS	NEWGARD INDUSTRIES
2VC1002-1R	1680-00-913-4841	SEAT, AIRCRAFT, TROOPS	NEWGARD INDUSTRIES
2Z6763-275	5826-00-611-0951	MOUNTING BASE	RAYTHEON
3-00001	5985-00-106-0906	ANTENNA	EDO
3000-10		TRANSMITTER, EMERGENCY LOCATOR (ELT)	POINTER
3000-11	5821-01-480-0975	TRANSMITTER, EMERGENCY LOCATOR (ELT)	POINTER
3000-8	5826-01-307-7380	TRANSMITTER, EMERGENCY LOCATOR (ELT)	POINTER
3000-9	5826-01-307-7380	TRANSMITTER, EMERGENCY LOCATOR (ELT)	POINTER
30-1037-1	6220-01-020-2550	LIGHT, NAVIGATIONAL, AIRCRAFT	GRIMES AEROSPACE
301110-1	1680-01-464-4953	SEAT, AIRCRAFT, TROOPS	SIMULA SAFETY SYSTEMS
301120-1	1680-01-464-4939	SEAT, AIRCRAFT, TROOPS	SIMULA SAFETY SYSTEMS
301-3000		EMERGENCY POWER SUPPLY UNIT	COHBAM AVIONICS (NEC AERO)
301-3017		BATTERY PACK	COHBAM AVIONICS (NEC AERO)
301-3100	6130-14-545-4006	EMERGENCY POWER SUPPLY UNIT	COHBAM AVIONICS (NEC AERO)
301660-1	5985-00-217-0463	ANTENNA, LOOP	KEARFOTT
3053593-1-1	1650-00-566-0335	VALVE, BOMB BAY, HYDRAULIC, CONTROL	MOOG
305J001-1	1560-01-208-0460	TANK, FUEL, AIRCRAFT	SARGENT FLETCHER
3078-1	5930-00-615-7340	SWITCH, PRESSURE	ITT AEROSPACE CONTROLS
30A8-690	4820-00-089-3256	VALVE, FLUID, REGULATING	PARKER-HANNIFIN
30-Y-1001		INDICATOR, ELECTRICAL TACHOMETER	ROCKWELL COLLINS
3-1267-1	1630-01-115-1715	WHEEL, AIRCRAFT, MLG	KELLY MANUFACTURING
3-1284	1630-00-075-1976	WHEEL, AIRCRAFT, NLG	GOODRICH
313N-2		CONTROL, NAVIGATION	ROCKWELL COLLINS
313N-2D		CONTROL, NAVIGATION	ROCKWELL COLLINS
31400-1	1650-00-566-0331	VALVE, TRANSFER, AUTOMATIC PILOT	CMC ELECTRONIQUE
3158-700	5841-00-892-1070	INDICATOR, DRIFT ANGLE-GROUND SPEED	PARKER-HANNIFIN
3214-30		BATTERY, EMERGENCY	DIEHL
3214-31		BATTERY, EMERGENCY	DIEHL
321502-4-1	4810-00-796-1672	VALVE, BUTTERFLY, SHUT-OFF	HONEYWELL INTERNATIONAL
32164-009	6680-00-923-8466	GENERATOR TACHOMETER	LUCAS AEROSPACE
3236K13	6680-00-920-9213	GENERATOR, TACHOMETER	AMETEK
3252022-0101	6610-01-035-0673	ALTIMETER, SERVO CONTROLLED	CARLETON
3301-31		BATTERY, EMERGENCY	DIEHL

330508-1	2915-00-877-3277	VALVE, TEMPERATURE DATUM	HONEYWELL INTERNATIONAL
3318488-1	1660-01-130-4645	CONTROL BOX, TEMPERATURE	LOCKHEED MARTIN
331A-8G	5826-01-065-9189	INDICATOR, COURSE	ROCKWELL COLLINS
331C-4		INDICATOR, BEARING DISTANCE HEADING	ROCKWELL COLLINS
331C-4A	5826-00-679-3205	INDICATOR, BEARING DISTANCE HEADING	ROCKWELL COLLINS
331C-4E		INDICATOR, BEARING DISTANCE HEADING	ROCKWELL COLLINS
331C-4F	5826-00-953-9298	INDICATOR, BEARING DISTANCE HEADING	ROCKWELL COLLINS
331D-2	6610-00-799-8315	INDICATOR, HORIZONTAL SITUATION	ROCKWELL COLLINS
331D-2A		INDICATOR, HORIZONTAL SITUATION	ROCKWELL COLLINS
331D-2B		INDICATOR, HORIZONTAL SITUATION	ROCKWELL COLLINS
331D-2D	6610-00-975-1699	INDICATOR, HORIZONTAL SITUATION	ROCKWELL COLLINS
331H-3G	5826-01-131-6622	INDICATOR, OMNI BEARING	ROCKWELL COLLINS
331H-3GB	5826-00-404-0245	INDICATOR, OMNI BEARING	ROCKWELL COLLINS
3320218P2	6680-00-445-1246	GENERATOR, TACHOMETER	AMETEK
332C-4	5826-01-040-0109	INDICATOR, RADIO MAGNETIC	ROCKWELL COLLINS
332D-11		GYROSCOPE, VERTICAL	ROCKWELL COLLINS
332D-11A	5826-00-348-3874	GYROSCOPE, VERTICAL	ROCKWELL COLLINS
332D-11B		GYROSCOPE, VERTICAL	ROCKWELL COLLINS
332D-11T		GYROSCOPE, VERTICAL	ROCKWELL COLLINS
332D-11V	6615-01-134-8914	GYROSCOPE, VERTICAL	ROCKWELL COLLINS
333F-1	5996-00-617-0426	AMPLIFIER, HSI, ELECTRONIC CONTROL	ROCKWELL COLLINS
334C-6		SERVO, AUTO-PILOT, PRIMARY	ROCKWELL COLLINS
334C-6A		SERVO, AUTO-PILOT, PRIMARY	ROCKWELL COLLINS
334C-6B		SERVO, AUTO-PILOT, PRIMARY	ROCKWELL COLLINS
334C-6C		SERVO, AUTO-PILOT, PRIMARY	ROCKWELL COLLINS
3-34D15	6130-01-178-7850	POWER SUPPLY	PACIFIC ELECTRONIC ENTERPRISES
339242-13	1630-01-408-3685	WHEEL, NOSE LANDING GEAR	LOCKHEED MARTIN
339H-1	5841-00-758-4547	INDICATOR, RADIO ALTIMETER	ROCKWELL COLLINS
339H-1A		INDICATOR, RADIO ALTIMETER	ROCKWELL COLLINS
339H-1B		INDICATOR, RADIO ALTIMETER	ROCKWELL COLLINS
3410201C4-1C1	6620-00-959-6614	INDICATOR, ELECTRICAL TACHOMETER	HONEYWELL INTERNATIONAL
3-43512-3	6685-00-526-7864	TRANSMITTER, PRESSURE	NORTHROP GRUMMAN SYSTEMS
345A-7	6615-00-134-5980	GYROSCOPE, RATE OF TURN	ROCKWELL COLLINS
345A-7A	6615-00-134-5980	GYROSCOPE, RATE OF TURN	ROCKWELL COLLINS
345A-7B		GYROSCOPE, RATE OF TURN	ROCKWELL COLLINS
345C-2A	6615-01-043-2763	ACCELEROMETER, ELECTRICAL, LINEAR	ROCKWELL COLLINS
3510M0	2925-14-305-4212	RELAY, REVERSE CURRENT	ZODIAC AEROSPACE
35160-0124	6610-00-473-5046	INDICATOR, VERTICAL VELOCITY	AEROSONIC
351B-6		MOUNT, AUTO-PILOT, SERVO	ROCKWELL COLLINS
351B-6A		MOUNT, AUTO-PILOT, SERVO	ROCKWELL COLLINS
351B-6B		MOUNT, AUTO-PILOT, SERVO	ROCKWELL COLLINS
351B-6C		MOUNT, AUTO-PILOT, SERVO	ROCKWELL COLLINS
351B-6E		MOUNT, AUTO-PILOT, SERVO	ROCKWELL COLLINS
351B-6F		MOUNT, AUTO-PILOT, SERVO	ROCKWELL COLLINS
351B-6G		MOUNT, AUTO-PILOT, SERVO	ROCKWELL COLLINS
351B-6H		MOUNT, AUTO-PILOT, SERVO	ROCKWELL COLLINS
351B-7		MOUNT, AUTO-PILOT, SERVO	ROCKWELL COLLINS
351B-7A		MOUNT, AUTO-PILOT, SERVO	ROCKWELL COLLINS
351B-7B		MOUNT, AUTO-PILOT, SERVO	ROCKWELL COLLINS
351B-7C		MOUNT, AUTO-PILOT, SERVO	ROCKWELL COLLINS
3567609-3703	6685-01-146-8649	TRANSMITTER, PRESSURE	HONEYWELL INTERNATIONAL
3567709-1501	6620-00-553-8988	TRANSMITTER, PRESSURE	HONEYWELL INTERNATIONAL
3567709-1502	6685-00-851-1824	TRANSMITTER, PRESSURE	HONEYWELL INTERNATIONAL

3567709-1504		TRANSMITTER, PRESSURE	HONEYWELL INTERNATIONAL
3567742-1001	6620-00-999-2425	TRANSMITTER, PRESSURE	HONEYWELL INTERNATIONAL
3567742-1501	6620-00-999-2222	TRANSMITTER, PRESSURE	HONEYWELL INTERNATIONAL
3567742-1701	6620-01-029-5135	TRANSMITTER, PRESSURE	HONEYWELL INTERNATIONAL
3567742-3001	6620-00-999-2424	TRANSMITTER, PRESSURE	HONEYWELL INTERNATIONAL
3567742-4701	6620-00-065-3235	TRANSMITTER, PRESSURE	HONEYWELL INTERNATIONAL
3567745-1701	6620-00-901-7848	TRANSMITTER PRESSURE	HONEYWELL INTERNATIONAL
35-811	1650-01-021-2865	SERVOVALVE, HYDRAULIC	HYDRO-AIRE
3602043-1		SWITCH, APU, SLIDE	HONEYWELL INTERNATIONAL
3602043-2	2990-01-341-3579	SWITCH, APU, SLIDE	HONEYWELL INTERNATIONAL
3602043-3	5930-01-231-6885	SWITCH, APU, SLIDE	HONEYWELL INTERNATIONAL
3602043-3-1	5930-01-231-6885	SWITCH, APU, SLIDE	HONEYWELL INTERNATIONAL
3604174-1	5930-01-019-5594	SWITCH, APU, SLIDE	HONEYWELL INTERNATIONAL
3604174-1-1	5930-01-019-5594	SWITCH, APU, SLIDE	HONEYWELL INTERNATIONAL
36104-1H-8-A1	5826-00-505-3094	INDICATOR, RADIO MAGNETIC	HONEYWELL INTERNATIONAL
36104-1L-11-A1	5826-00-505-2222	INDICATOR, RADIO MAGNETIC	HONEYWELL INTERNATIONAL
36104-1L-11-A2	5826-00-505-3094	INDICATOR, RADIO MAGNETIC	HONEYWELL INTERNATIONAL
362-014-001	6610-01-040-4430	INDICATOR, ANGLE OF ATTACK	PARKER-HANNIFIN
365EDP2-3	7310-00-905-6212	DISPLAY, ENGINE INFORMATION	GE AVIATION SYSTEMS
372021-11	1650-01-132-3641	BOOSTER ASSY, RUDDER CONTROL	LOCKHEED MARTIN
372697-10	2920-00-906-6251	STARTER, ENGINE, ELECTRICAL	HONEYWELL INTERNATIONAL
372697-6	2920-00-906-6251	STARTER, ENGINE, ELECTRICAL	HONEYWELL INTERNATIONAL
374455-7	1650-01-134-4415	BOOSTER ASSY, AILERON CONTROL	LOCKHEED MARTIN
374D-1		TRANSCEIVER, TACAN	ROCKWELL COLLINS
374D-2	5826-01-411-6748	TRANSCEIVER, TACAN	ROCKWELL COLLINS
377J-1		CONTROL PANEL, TACAN, TRANSCEIVER	ROCKWELL COLLINS
377J-2		CONTROL PANEL, TACAN, TRANSCEIVER	ROCKWELL COLLINS
37R-2	5985-01-003-2611	ANTENNA, VHF	ROCKWELL COLLINS
37R-2A		ANTENNA, VHF	ROCKWELL COLLINS
38106-001	6130-01-217-5880	POWER SUPPLY	KOLLSMAN
38210-397	6610-14-380-2775	INDICATOR, VERTICAL VELOCITY	BADIN CROUZET
3895-1	1680-00-888-3687	PUMP, WINDSHIELD	HAMILTON SUNDSTRAND
38E45-1C	2995-00-911-6736	VALVE, START, CONTROL	GOODRICH
38E45-1D	2995-00-168-2418	VALVE, START, CONTROL	GOODRICH
38E45-1E	2995-00-168-2418	VALVE, START, CONTROL	GOODRICH
38E45-4B	4810-01-058-5300	VALVE, START, CONTROL	GOODRICH
38E73-4A	2925-01-038-5770	VALVE, STARTER, CONTROL	GOODRICH
39-075	1630-00-908-9999	VALVE, DUAL CONTROL	HYDRO-AIRE
39-075A	1630-00-998-7896	VALVE, SKID CONTROL	HYDRO-AIRE
39130G	5965-00-755-4643	MICROPHONE, DYNAMIC	ROANWELL
392200-11-1	4810-00-106-7401	VALVE, BUTTERFLY	HONEYWELL INTERNATIONAL
393007-07869	6680-00-815-7282	INDICATOR, FUEL QUANTITY	SIMMONDS PRECISION PRODUCTS
393007-07870	6680-00-815-7285	INDICATOR, FUEL QUANTITY	SIMMONDS PRECISION PRODUCTS
393065-01858	6680-00-815-7284	INDICATOR, TOTALIZER, FUEL QUANTITY	SIMMONDS PRECISION PRODUCTS
39-471	1630-01-009-8616	VALVE, DUAL ANTI-SKID	HYDRO-AIRE
396308-1-1	4810-00-588-3479	VALVE, BUTTERFLY	HONEYWELL INTERNATIONAL
396308-2-1	4810-01-040-2372	VALVE, BUTTERFLY	HONEYWELL INTERNATIONAL
396308-2-2	4810-01-040-2372	VALVE, BUTTERFLY	HONEYWELL INTERNATIONAL
396308-3-1	4810-01-380-0393	VALVE, BUTTERFLY	HONEYWELL INTERNATIONAL
398648-1-1	4810-00-575-7781	VALVE, TEMPERATURE CONTROL, BUTTERFLY	HONEYWELL INTERNATIONAL
398648-1-2	4810-00-575-7781	VALVE, TEMPERATURE CONTROL, BUTTERFLY	HONEYWELL INTERNATIONAL
398648-2-1	4810-01-523-0579	VALVE, TEMPERATURE CONTROL, BUTTERFLY	HONEYWELL INTERNATIONAL
398650-1-1	4810-00-575-7789	VALVE, BUTTERFLY	HONEYWELL INTERNATIONAL

398654-1-2	4810-01-039-0459	VALVE, BUTTERFLY	HONEYWELL INTERNATIONAL
398654-1-3	4810-01-039-0459	VALVE, BUTTERFLY	HONEYWELL INTERNATIONAL
398654-1-4	4810-01-039-0459	VALVE, BUTTERFLY	HONEYWELL INTERNATIONAL
3A95550-107	4810-00-796-1672	VALVE, BUTTERFLY, SHUT-OFF	LOCKHEED MARTIN
3P99005-103	2915-00-074-1724	VALVE, FLOAT, FUEL TANK	LOCKHEED MARTIN
400-1494-01-L	7310-01-480-7786	OVEN, WARMING, ELECTRIC	SAFRAN CABIN STERLING
4005A	6610-00-557-3030	INDICATOR, ATTITUDE DIRECTOR	GE AVIATION SYSTEMS
4005F	6610-00-866-3234	INDICATOR, ATTITUDE DIRECTOR	GE AVIATION SYSTEMS
402-0466-020	6645-00-121-7551	CLOCK, MECHANICAL, PANEL	ROCKWELL COLLINS
4023400-0501	5841-00-089-7179	TRANSCEIVER, RADAR	RAYTHEON
4023400-0503	5841-00-149-1319	TRANSCEIVER, RADAR	RAYTHEON
4026927-901	6130-01-059-9017	POWER SUPPLY SUBASSEMBLY	HONEYWELL INTERNATIONAL
4047-1	5945-00-628-6484	RELAY, HYBRID	DNE TECHNOLOGIES
405485-2	5826-00-234-6315	INDICATOR, BEARING	KEARFOTT
4055K	6610-00-068-3464	INDICATOR, ATTITUDE DIRECTOR	GE AVIATION SYSTEMS
405968-1	5985-00-149-1451	ANTENNA, LOOP	KEARFOTT
406-121AF		TRANSMITTER, EMERGENCY LOCATOR (ELT)	KANNAD
40-621	6695-00-055-6404	TRANSDUCER, WHELL SPEED	HYDRO-AIRE
40-637-4	6680-01-060-4248	INDICATOR, FUEL QUANTITY	SIMMONDS PRECISION PRODUCTS
406AF406AF-G		TRANSMITTER, EMERGENCY LOCATOR (ELT)	KANNAD
406AF-6D		TRANSMITTER, EMERGENCY LOCATOR (ELT)	KANNAD
406AF-COMPACT		TRANSMITTER, EMERGENCY LOCATOR (ELT)	KANNAD
406AF-H		TRANSMITTER, EMERGENCY LOCATOR (ELT)	KANNAD
406AP		TRANSMITTER, EMERGENCY LOCATOR (ELT)	KANNAD
406AP-H		TRANSMITTER, EMERGENCY LOCATOR (ELT)	KANNAD
406AS		TRANSMITTER, EMERGENCY LOCATOR (ELT)	KANNAD
406-SURVIVAL		TRANSMITTER, EMERGENCY LOCATOR (ELT)	KANNAD
4080A	6645-00-950-8599	CLOCK, MECHANICAL, PANEL	WALTHAM AIRCRAFT CLOCK
40D830-1	4820-00-006-5087	VALVE, ENGINE, BLEED AIR, CHECK	MOOG
40D830-3	4820-00-006-5087	VALVE, ENGINE, BLEED AIR, CHECK	MOOG
40D980	4810-00-018-3825	VALVE, BUTTERFLY	MOOG
40D990	4810-00-018-3826	VALVE, BUTTERFLY	MOOG
40F106	4820-01-097-8734	VALVE, FUEL, VENT	HONEYWELL INTERNATIONAL
4100050-2	1650-01-058-6259	MOTOR, HYDRAULIC, FFP	ALLEN AICRAFT PRODUCTS
41-2036-002	4810-00-627-4825	VALVE ASSY, SOLENOID, DRAIN	PARKER HANNIFIN
41-2036-003		VALVE ASSY, SOLENOID, DRAIN	HONEYWELL INTERNATIONAL
41-2036-004	4810-00-749-8896	VALVE ASSY, SOLENOID, DRAIN	HONEYWELL INTERNATIONAL
4-156-1	2915-00-671-7892	VALVE, FLOAT, FUEL TANK	HONEYWELL INTERNATIONAL
4-156-1M1	2915-00-671-7892	VALVE, FLOAT, FUEL TANK	PARKER HANNIFIN
418200-2	5826-00-390-5744	INDICATOR, BEARING	KEARFOTT
41D110-1	4810-00-943-5223	VALVE, BUTTERFLY	MOOG
41D230	2995-00-822-3053	VALVE, HOT AIR	MOOG
42-109	1630-00-085-2625	CONTROL UNIT, ANTI-SKID	HYDRO-AIRE
42-109-1A	1630-00-133-8183	CONTROL UNIT, ANTI-SKID	HYDRO-AIRE
42-109A	1630-01-104-1015	CONTROL UNIT, ANTI-SKID	HYDRO-AIRE
43030-1	4810-00-914-9508	VALVE, SHUTOFF, BLEED AIR	MOOG
43030-11	4810-00-085-1104	VALVE, SHUTOFF, BLEED AIR	MOOG
4309-210-01-10	6610-14-380-2741	INDICATOR, POSITION	ACTIA (THALES AVIONICS)
4344D1-1	1680-00-402-6201	ACTUATOR, ELECTRO-MECHANICAL, LINEAR	SARGENT AEROSPACE & DEFENSE
4344D1-2	1680-00-402-6202	ACTUATOR, ELECTRO-MECHANICAL, LINEAR	SARGENT AEROSPACE & DEFENSE
4344D1-3	1680-01-181-9873	ACTUATOR, ELECTRO-MECHANICAL, LINEAR	SARGENT AEROSPACE & DEFENSE
4344D1-4	1680-01-181-9874	ACTUATOR, ELECTRO-MECHANICAL, LINEAR	SARGENT AEROSPACE & DEFENSE
4344D2-1	1680-01-222-2551	ACTUATOR, ELECTRO-MECHANICAL, LINEAR	SARGENT AEROSPACE & DEFENSE

4344EA03	1680-00-615-1335	ACTUATOR, ELECTRO-MECHANICAL, ROTARY	SARGENT AEROSPACE & DEFENSE
4344EA1	1680-00-615-1335	ACTUATOR, ELECTRO-MECHANICAL, ROTARY	SARGENT AEROSPACE & DEFENSE
4344EA-1	1680-00-615-1335	ACTUATOR, ELECTRO-MECHANICAL, ROTARY	SARGENT AEROSPACE & DEFENSE
4344EA2	1680-01-004-2086	ACTUATOR, ELECTRO-MECHANICAL, ROTARY	SARGENT AEROSPACE & DEFENSE
4344EA-2	1680-01-004-2086	ACTUATOR, ELECTRO-MECHANICAL, ROTARY	SARGENT AEROSPACE & DEFENSE
4344EA3	3040-01-414-2019	ACTUATOR, ELECTRO-MECHANICAL, ROTARY	SARGENT AEROSPACE & DEFENSE
4344EA-3	3040-01-414-2019	ACTUATOR, ELECTRO-MECHANICAL, ROTARY	SARGENT AEROSPACE & DEFENSE
4344EA4	1680-01-416-3926	ACTUATOR, ELECTRO-MECHANICAL, ROTARY	SARGENT AEROSPACE & DEFENSE
4344EA-4	1680-01-414-0474	ACTUATOR, ELECTRO-MECHANICAL, ROTARY	SARGENT AEROSPACE & DEFENSE
4371R	2925-01-483-3517	MAGNETO, IGNITION	HARTZELL ENGINE TECHNOLOGIES
437X-1	5985-00-758-4548	ANTENNA, RADIO ALTEMETER	ROCKWELL COLLINS
437X-1A	5985-00-088-8562	ANTENNA, RADIO ALTEMETER	ROCKWELL COLLINS
437X-1B		ANTENNA, RADIO ALTEMETER	ROCKWELL COLLINS
43932-052	6610-01-074-2819	ALTIMETER, PRESSURE	KOLLSMAN
44910-5	6220-00-370-5447	LIGHT, EMERGENCY EXIT	GRIMES AEROSPACE
449201-6	5831-00-987-1815	CONTROL BOX	RAYTHEON
449330-1	4920-00-986-7642	TEST SET, INTERCOMMUNICATION	TRAYTHEON
45-0325-1	6220-01-437-7640	LIGHT, LANDING, AIRCRAFT	GRIMES AEROSPACE
45-0325-3	6220-01-437-7640	LIGHT, LANDING, AIRCRAFT	GRIMES AEROSPACE
450-655	5841-00-892-1070	INDICATOR, DRIFT ANGLE-GROUND SPEED	CMC ELECTRONIQUE
450A5200014-009	450A5200014-009	TRANSCEIVER, RADAR	LOCKHEED MARTIN
453-5000		TRANSMITTER, EMERGENCY LOCATOR (ELT)	ARTEX
453-5001		TRANSMITTER, EMERGENCY LOCATOR (ELT)	ARTEX
453-5002		TRANSMITTER, EMERGENCY LOCATOR (ELT)	ARTEX
453-5003		TRANSMITTER, EMERGENCY LOCATOR (ELT)	ARTEX
453-5004		TRANSMITTER, EMERGENCY LOCATOR (ELT)	ARTEX
453-5012		TRANSMITTER, EMERGENCY LOCATOR (ELT)	ARTEX
453-5060	5821-01-561-9503	TRANSMITTER, EMERGENCY LOCATOR (ELT)	ARTEX
453-5061		TRANSMITTER, EMERGENCY LOCATOR (ELT)	ARTEX
4536-01C	6615-00-077-1831	GYROSCOPE, RATE OF TURN	PARKER-HANNIFIN
453-6603		ME406	ARTEX
453-6604		TRANSMITTER, EMERGENCY LOCATOR (ELT)	ARTEX
453-6611		TRANSMITTER, EMERGENCY LOCATOR (ELT)	ARTEX
461-00269-001	6605-14-369-3135	GYROSCOPE, COMPASS	SFIM INDUSTRIES
461-00269-003	6605-14-369-3134	GYROSCOPE, COMPASS	SFIM INDUSTRIES
461-00331-300	6605-14-387-2597	GYROSCOPE, COMPASS	SFIM INDUSTRIES
468100-0-1	6645-00-091-7107	TIMER, ELECTRICAL, STOP	HONEYWELL INTERNATIONAL
468100-1	6645-00-091-7107	TIMER, ELECTRICAL, STOP	HONEYWELL INTERNATIONAL
46D40163	5826-00-521-0571	COUPLING, ANTENNA	RAYTHEON
47B38P	6685-00-553-4726	INDICATOR, TEMPERATURE, ELECTRICAL RESISTANCE	HORIZON AEROSPACE
47B38P2	6685-00-553-4726	INDICATOR, TEMPERATURE, ELECTRICAL RESISTANCE	HORIZON AEROSPACE
482-0061-00	5826-01-422-0955	INDICATOR, RADIO MAGNETIC	ROCKWELL COLLINS
482-0061-000		INDICATOR, RADIO MAGNETIC	ROCKWELL COLLINS
482-0061-030	6655-01-394-5119	INDICATOR, RADIO MAGNETIC	ROCKWELL COLLINS
483A	5945-00-628-6484	RELAY, HYBRID	PANEX
490T-1	5985-00-954-1665	COUPLER, ANTENNA	ROCKWELL COLLINS
490T-1A	5985-00-852-0457	COUPLER, ANTENNA	ROCKWELL COLLINS
494-116-001-694	5965-01-127-3890	HEADSET, MICROPHONE	ROANWELL
494-196-001-694	5965-01-127-3890	HEADSET, MICROPHONE	ROANWELL
495116003-604	5965-01-128-1410	HEADSET, MICROPHONE	ROANWELL
495-116-03	5965-01-128-1410	HEADSET, MICROPHONE	ROANWELL
495-199-004	5965-01-128-1410	HEADSET, MICROPHONE	ROANWELL
495-199-004-604	5965-01-127-3890	HEADSET, MICROPHONE	ROANWELL

4K95000-253A	5985-00-673-5831	ANTENNA, DME/TACAN, BEACON	LOCKHEED MARTIN
4K95000-281A	5841-01-246-9183	TRANSCEIVER, CARA	LOCKHEED MARTIN
500-12		TRANSMITTER, PERSONAL LOCATOR (PLT/PLB)	TECHTEST
500-16		TRANSMITTER, PERSONAL LOCATOR (PLT/PLB)	TECHTEST
500-27		TRANSMITTER, PERSONAL LOCATOR (PLT/PLB)	TECHTEST
5005284B28	5965-00-755-4643	MICROPHONE, DYNAMIC	MOTOROLA SOLUTIONS
500702-3613	4140-00-241-0065	FAN, VANE, AXIAL	HAMILTON SUNDSTRAND
5007-410-00-11	6680-14-409-2567	TACHOMETER	ACTIA (THALES AVIONICS)
501-1027-01	6615-00-877-9343	GYROSCOPE, RATE OF TURN	L3 AVIATION PRODUCTS
501-1131-01	6610-00-200-8832	INDICATOR, VERTICAL VELOCITY	L3 AVIATION PRODUCTS
501-1228-04	6130-01-219-8285	POWER SUPPLY, BATTERY	L3 AVIATION PRODUCTS
501-1804-01	6610-01-464-5517	INDICATOR, ATTITUDE DIRECTOR	L3 AVIATION PRODUCTS
501-1847-04	6605-01-532-2364	INDICATOR, ELECTRONIC HORIZONTAL SITUATION (EHSI)	L3 AVIATION PRODUCTS
50150-20	4810-00-728-3396	VALVE, LINEAR, DIRECTIONAL CONTROL	WOODWARD
50150-28	4810-00-401-5524	VALVE, LINEAR, DIRECTIONAL CONTROL	WOODWARD
50150-3		VALVE, LINEAR, DIRECTIONAL CONTROL	WOODWARD
502600-7	1680-00-809-8502	VALVE, LINEAR, DIRECTIONAL CONTROL	TRANSDIGM
505485-2	5826-00-234-6315	INDICATOR, BEARING	KEARFOTT
5-09192-1	6685-00-670-0895	THERMOSTAT, FLOW CONTROL	PSG CONTROLS
50F12696	5985-00-217-0457	ANTENNA	EDO
50F13903	5826-00-333-9867	MOUNTING BASE ASSEMBLY	RAYTHEON
5-10052	6685-01-119-6546	THERMOSTAT, FLOW CONTROL	PSG CONTROLS
510414-3-1	6610-00-887-6725	COMPUTER, TRUE AIR SPEED	HONEYWELL INTERNATIONAL
510414-3-2	6610-00-759-7170	COMPUTER, TRUE AIR SPEED	HONEYWELL INTERNATIONAL
5122-4	5965-00-755-4643	MICROPHONE, DYNAMIC	RAYTHEON
518-28007-001		ALTIMETER, ENCODING	KOLLSMAN
518-28007-002	6610-01-121-9627	ALTIMETER, ENCODING	KOLLSMAN
518-28007-003		ALTIMETER, ENCODING	KOLLSMAN
518-28007-004		ALTIMETER, ENCODING	KOLLSMAN
518-28007-005		ALTIMETER, ENCODING	KOLLSMAN
518-28007-006		ALTIMETER, ENCODING	KOLLSMAN
518-28007-007		ALTIMETER, ENCODING	KOLLSMAN
518-28007-008		ALTIMETER, ENCODING	KOLLSMAN
518-28007-009		ALTIMETER, ENCODING	KOLLSMAN
518-28007-010		ALTIMETER, ENCODING	KOLLSMAN
518-28007-011		ALTIMETER, ENCODING	KOLLSMAN
518-28007-012		ALTIMETER, ENCODING	KOLLSMAN
518-28007-013		ALTIMETER, ENCODING	KOLLSMAN
518-28007-014		ALTIMETER, ENCODING	KOLLSMAN
518-28007-015		ALTIMETER, ENCODING	KOLLSMAN
518-28007-016		ALTIMETER, ENCODING	KOLLSMAN
518-28007-017		ALTIMETER, ENCODING	KOLLSMAN
518-28007-018		ALTIMETER, ENCODING	KOLLSMAN
518-28007-019		ALTIMETER, ENCODING	KOLLSMAN
518-28007-020		ALTIMETER, ENCODING	KOLLSMAN
518-28007-021		ALTIMETER, ENCODING	KOLLSMAN
518-28007-022		ALTIMETER, ENCODING	KOLLSMAN
518-28007-023		ALTIMETER, ENCODING	KOLLSMAN
518-28007-024		ALTIMETER, ENCODING	KOLLSMAN
518-28007-025		ALTIMETER, ENCODING	KOLLSMAN
518-28007-026		ALTIMETER, ENCODING	KOLLSMAN
518-28007-027		ALTIMETER, ENCODING	KOLLSMAN
518-28007-028		ALTIMETER, ENCODING	KOLLSMAN



518-28007-029		ALTIMETER, ENCODING	KOLLSMAN
518-28007-030		ALTIMETER, ENCODING	KOLLSMAN
518-28007-171		ALTIMETER, ENCODING	KOLLSMAN
518-28007-172		ALTIMETER, ENCODING	KOLLSMAN
518-28007-173		ALTIMETER, ENCODING	KOLLSMAN
518-28007-174	6610-01-346-5592	ALTIMETER, ENCODING	KOLLSMAN
518-28007-175		ALTIMETER, ENCODING	KOLLSMAN
518-28007-176		ALTIMETER, ENCODING	KOLLSMAN
518-28007-177		ALTIMETER, ENCODING	KOLLSMAN
518-28007-178		ALTIMETER, ENCODING	KOLLSMAN
518-28007-201		ALTIMETER, ENCODING	KOLLSMAN
518-28007-202		ALTIMETER, ENCODING	KOLLSMAN
518-28007-203		ALTIMETER, ENCODING	KOLLSMAN
518-28007-204	6610-01-259-0251	ALTIMETER, ENCODING	KOLLSMAN
518-28007-205		ALTIMETER, ENCODING	KOLLSMAN
518-28007-206		ALTIMETER, ENCODING	KOLLSMAN
518-28007-207		ALTIMETER, ENCODING	KOLLSMAN
518-28007-208		ALTIMETER, ENCODING	KOLLSMAN
518-28007-209		ALTIMETER, ENCODING	KOLLSMAN
518-28007-210		ALTIMETER, ENCODING	KOLLSMAN
518-28007-211		ALTIMETER, ENCODING	KOLLSMAN
518-28007-212		ALTIMETER, ENCODING	KOLLSMAN
518-28007-213		ALTIMETER, ENCODING	KOLLSMAN
518-28007-214		ALTIMETER, ENCODING	KOLLSMAN
518-28007-215		ALTIMETER, ENCODING	KOLLSMAN
518-28007-216		ALTIMETER, ENCODING	KOLLSMAN
518-28007-217		ALTIMETER, ENCODING	KOLLSMAN
518-28007-218		ALTIMETER, ENCODING	KOLLSMAN
518-28007-223		ALTIMETER, ENCODING	KOLLSMAN
518-28007-224		ALTIMETER, ENCODING	KOLLSMAN
518-28007-225		ALTIMETER, ENCODING	KOLLSMAN
518-28007-226		ALTIMETER, ENCODING	KOLLSMAN
518-28007-227		ALTIMETER, ENCODING	KOLLSMAN
518-28007-228		ALTIMETER, ENCODING	KOLLSMAN
518-28007-229		ALTIMETER, ENCODING	KOLLSMAN
518-28007-230		ALTIMETER, ENCODING	KOLLSMAN
518-28007-231		ALTIMETER, ENCODING	KOLLSMAN
518-28007-232		ALTIMETER, ENCODING	KOLLSMAN
518-28007-233		ALTIMETER, ENCODING	KOLLSMAN
518-28007-234		ALTIMETER, ENCODING	KOLLSMAN
518-28007-235		ALTIMETER, ENCODING	KOLLSMAN
518-28007-261		ALTIMETER, ENCODING	KOLLSMAN
518-28007-262		ALTIMETER, ENCODING	KOLLSMAN
518-28007-263		ALTIMETER, ENCODING	KOLLSMAN
518-28007-264		ALTIMETER, ENCODING	KOLLSMAN
518-28007-265		ALTIMETER, ENCODING	KOLLSMAN
518-28007-266		ALTIMETER, ENCODING	KOLLSMAN
518-28007-267		ALTIMETER, ENCODING	KOLLSMAN
518-28007-268		ALTIMETER, ENCODING	KOLLSMAN
518-28007-269		ALTIMETER, ENCODING	KOLLSMAN
518-28007-270		ALTIMETER, ENCODING	KOLLSMAN
518-28007-271		ALTIMETER, ENCODING	KOLLSMAN
518-28007-272		ALTIMETER, ENCODING	KOLLSMAN

518-28007-301	ALTIMETER, ENCODING	KOLLSMAN
518-28007-302	ALTIMETER, ENCODING	KOLLSMAN
518-28007-303	ALTIMETER, ENCODING	KOLLSMAN
518-28007-304	ALTIMETER, ENCODING	KOLLSMAN
518-28007-305	ALTIMETER, ENCODING	KOLLSMAN
518-28007-306	ALTIMETER, ENCODING	KOLLSMAN
518-28007-307	ALTIMETER, ENCODING	KOLLSMAN
518-28007-308	ALTIMETER, ENCODING	KOLLSMAN
518-28007-309	ALTIMETER, ENCODING	KOLLSMAN
518-28007-310	ALTIMETER, ENCODING	KOLLSMAN
518-28007-311	ALTIMETER, ENCODING	KOLLSMAN
518-28007-312	ALTIMETER, ENCODING	KOLLSMAN
518-28007-313	ALTIMETER, ENCODING	KOLLSMAN
518-28007-314	ALTIMETER, ENCODING	KOLLSMAN
518-28007-315	ALTIMETER, ENCODING	KOLLSMAN
518-28007-316	ALTIMETER, ENCODING	KOLLSMAN
518-28007-317	ALTIMETER, ENCODING	KOLLSMAN
518-28007-318	ALTIMETER, ENCODING	KOLLSMAN
518-28007-319	ALTIMETER, ENCODING	KOLLSMAN
518-28007-320	ALTIMETER, ENCODING	KOLLSMAN
518-28007-321	ALTIMETER, ENCODING	KOLLSMAN
518-28007-322	ALTIMETER, ENCODING	KOLLSMAN
518-28007-323	ALTIMETER, ENCODING	KOLLSMAN
518-28007-324	ALTIMETER, ENCODING	KOLLSMAN
518-28007-325	ALTIMETER, ENCODING	KOLLSMAN
518-28007-326	ALTIMETER, ENCODING	KOLLSMAN
518-28007-327	ALTIMETER, ENCODING	KOLLSMAN
518-28007-328	ALTIMETER, ENCODING	KOLLSMAN
518-28007-329	ALTIMETER, ENCODING	KOLLSMAN
518-28007-330	ALTIMETER, ENCODING	KOLLSMAN
518-28007-331	ALTIMETER, ENCODING	KOLLSMAN
518-28007-332	ALTIMETER, ENCODING	KOLLSMAN
518-28007-333	ALTIMETER, ENCODING	KOLLSMAN
518-28007-334	ALTIMETER, ENCODING	KOLLSMAN
518-28007-335	ALTIMETER, ENCODING	KOLLSMAN
518-28007-336	ALTIMETER, ENCODING	KOLLSMAN
518-28007-337	ALTIMETER, ENCODING	KOLLSMAN
518-28007-338	ALTIMETER, ENCODING	KOLLSMAN
518-28007-339	ALTIMETER, ENCODING	KOLLSMAN
518-28007-340	ALTIMETER, ENCODING	KOLLSMAN
518-28007-341	ALTIMETER, ENCODING	KOLLSMAN
518-28007-342	ALTIMETER, ENCODING	KOLLSMAN
518-28007-343	ALTIMETER, ENCODING	KOLLSMAN
518-28007-344	ALTIMETER, ENCODING	KOLLSMAN
518-28007-345	ALTIMETER, ENCODING	KOLLSMAN
518-28007-346	ALTIMETER, ENCODING	KOLLSMAN
518-28007-347	ALTIMETER, ENCODING	KOLLSMAN
518-28007-700	ALTIMETER, ENCODING	KOLLSMAN
518-28007-800	ALTIMETER, ENCODING	KOLLSMAN
518-28007-906	ALTIMETER, ENCODING	KOLLSMAN
518-28007-907	ALTIMETER, ENCODING	KOLLSMAN
518-28007-921	ALTIMETER, ENCODING	KOLLSMAN
518-28007-922	ALTIMETER, ENCODING	KOLLSMAN

51RV-4		RECEIVER, VOR/ILS RADIO NAVIGATION	ROCKWELL COLLINS
51RV-4B		RECEIVER, VOR/ILS RADIO NAVIGATION	ROCKWELL COLLINS
51RV-4D		RECEIVER, VOR/ILS RADIO NAVIGATION	ROCKWELL COLLINS
51RV-5		RECEIVER, VOR/ILS RADIO NAVIGATION	ROCKWELL COLLINS
51RV-5B	5826-01-481-6179	RECEIVER, RADIO NAVIGATION	ROCKWELL COLLINS
51RV-5D		RECEIVER, VOR/ILS RADIO NAVIGATION	ROCKWELL COLLINS
51Y-7	5826-00-322-2167	TRANSCEIVER, ADF	ROCKWELL COLLINS
51Y-7A	5826-00-275-0612	TRANSCEIVER, ADF	ROCKWELL COLLINS
51Y-7C		TRANSCEIVER, ADF	ROCKWELL COLLINS
51Y-7D	5826-01-194-5731	TRANSCEIVER, ADF	ROCKWELL COLLINS
51Z4	5826-00-960-0830	TRANSCEIVER, RADIO BEACON	ROCKWELL COLLINS
5207-00-1	4810-01-154-3200	VALVE, REGULATING, FLUID PRESSURE	DUKES AEROSPACE
522-0690-003		INDICATOR, BEARING DISTANCE HEADING	ROCKWELL COLLINS
522-0954-001		ANTENNA, RADIO ALTEMETER	ROCKWELL COLLINS
522-0954-002		ANTENNA, RADIO ALTEMETER	ROCKWELL COLLINS
522-0974-003	5826-00-679-3205	INDICATOR, BEARING DISTANCE HEADING	ROCKWELL COLLINS
522-1135-011		ANTENNA, VHF	ROCKWELL COLLINS
522-1135-012	5985-01-080-8452	ANTENNA, VHF	ROCKWELL COLLINS
522-1230-00	5821-00-893-0193	TRANSCEIVER, RADIO	ROCKWELL COLLINS
522-1230-000	5821-00-893-0193	TRANSCEIVER, RADIO	ROCKWELL COLLINS
522-1230-021		TRANSCEIVER, RADIO	ROCKWELL COLLINS
522-1230-022		TRANSCEIVER, RADIO	ROCKWELL COLLINS
522-1230-023		TRANSCEIVER, RADIO	ROCKWELL COLLINS
522-1261-00		CONTROL, RADIO SET	ROCKWELL COLLINS
522-1261-000		CONTROL, RADIO SET	ROCKWELL COLLINS
522-1394-003	5996-00-617-0426	AMPLIFIER, HSI, ELECTRONIC CONTROL	ROCKWELL COLLINS
522-1394-335	5996-00-617-0426	AMPLIFIER, HSI, ELECTRONIC CONTROL	ROCKWELL COLLINS
522-1501-00	5821-00-893-2906	TRANSCEIVER, RADIO	ROCKWELL COLLINS
522-1501-000	5821-00-893-2906	TRANSCEIVER, RADIO	ROCKWELL COLLINS
522-1501-041	5826-00-142-9449	TRANSCEIVER, RADIO	ROCKWELL COLLINS
522-1501-043	5820-01-496-3825	TRANSCEIVER, RADIO	ROCKWELL COLLINS
522-1501-044	5820-01-496-3829	TRANSCEIVER, RADIO	ROCKWELL COLLINS
522-1660-00	5821-00-604-3307	TRANSCEIVER, RADIO	ROCKWELL COLLINS
522-1660-000	5821-00-124-4484	TRANSCEIVER, RADIO	ROCKWELL COLLINS
522-1660-031	5895-01-105-3821	TRANSCEIVER, RADIO	ROCKWELL COLLINS
522-1660-033	5820-01-496-3802	TRANSCEIVER, RADIO	ROCKWELL COLLINS
522-1660-034	5820-01-496-3804	TRANSCEIVER, RADIO	ROCKWELL COLLINS
522-1771-003		INDICATOR, BEARING DISTANCE HEADING	ROCKWELL COLLINS
522-1837-000	5985-00-312-4577	ANTENNA, LOOP, ADF	ROCKWELL COLLINS
522-2213-00	5821-00-838-7051	CONTROL, RADIO SET	ROCKWELL COLLINS
522-2213-000	5821-00-838-7051	CONTROL, RADIO SET	ROCKWELL COLLINS
522-2213-011		CONTROL, RADIO SET	ROCKWELL COLLINS
522-2213-012		CONTROL, RADIO SET	ROCKWELL COLLINS
522-2213-013		CONTROL, RADIO SET	ROCKWELL COLLINS
522-2213-014		CONTROL, RADIO SET	ROCKWELL COLLINS
522-2213-015		CONTROL, RADIO SET	ROCKWELL COLLINS
522-2213-016		CONTROL, RADIO SET	ROCKWELL COLLINS
522-2213-017		CONTROL, RADIO SET	ROCKWELL COLLINS
522-2213-018		CONTROL, RADIO SET	ROCKWELL COLLINS
522-2213-019		CONTROL, RADIO SET	ROCKWELL COLLINS
522-2213-020		CONTROL, RADIO SET	ROCKWELL COLLINS
522-2213-021		CONTROL, RADIO SET	ROCKWELL COLLINS
522-2213-022		CONTROL, RADIO SET	ROCKWELL COLLINS

522-2213-023		CONTROL, RADIO SET	ROCKWELL COLLINS
522-2213-024		CONTROL, RADIO SET	ROCKWELL COLLINS
522-2213-025		CONTROL, RADIO SET	ROCKWELL COLLINS
522-2213-026		CONTROL, RADIO SET	ROCKWELL COLLINS
522-2213-027		CONTROL, RADIO SET	ROCKWELL COLLINS
522-2213-028		CONTROL, RADIO SET	ROCKWELL COLLINS
522-2213-029		CONTROL, RADIO SET	ROCKWELL COLLINS
522-2213-030		CONTROL, RADIO SET	ROCKWELL COLLINS
522-2213-031		CONTROL, RADIO SET	ROCKWELL COLLINS
522-2213-032		CONTROL, RADIO SET	ROCKWELL COLLINS
522-2213-033		CONTROL, RADIO SET	ROCKWELL COLLINS
522-2213-034		CONTROL, RADIO SET	ROCKWELL COLLINS
522-2213-035		CONTROL, RADIO SET	ROCKWELL COLLINS
522-2213-036		CONTROL, RADIO SET	ROCKWELL COLLINS
522-2213-037		CONTROL, RADIO SET	ROCKWELL COLLINS
522-2213-038		CONTROL, RADIO SET	ROCKWELL COLLINS
522-2213-039		CONTROL, RADIO SET	ROCKWELL COLLINS
522-2213-040		CONTROL, RADIO SET	ROCKWELL COLLINS
522-2213-041		CONTROL, RADIO SET	ROCKWELL COLLINS
522-2213-042		CONTROL, RADIO SET	ROCKWELL COLLINS
522-2213-043		CONTROL, RADIO SET	ROCKWELL COLLINS
522-2213-044		CONTROL, RADIO SET	ROCKWELL COLLINS
522-2213-045		CONTROL, RADIO SET	ROCKWELL COLLINS
522-2213-046		CONTROL, RADIO SET	ROCKWELL COLLINS
522-2213-047		CONTROL, RADIO SET	ROCKWELL COLLINS
522-2213-048		CONTROL, RADIO SET	ROCKWELL COLLINS
522-2213-049		CONTROL, RADIO SET	ROCKWELL COLLINS
522-2213-050		CONTROL, RADIO SET	ROCKWELL COLLINS
522-2213-051		CONTROL, RADIO SET	ROCKWELL COLLINS
522-2213-052		CONTROL, RADIO SET	ROCKWELL COLLINS
522-2213-053		CONTROL, RADIO SET	ROCKWELL COLLINS
522-2213-054		CONTROL, RADIO SET	ROCKWELL COLLINS
522-2213-055		CONTROL, RADIO SET	ROCKWELL COLLINS
522-2301-005	5985-00-985-9173	ANTENNA, LOOP, ADF	ROCKWELL COLLINS
522-2377-003	5826-00-953-9298	INDICATOR, BEARING DISTANCE HEADING	ROCKWELL COLLINS
522-2411-003	6610-00-799-8315	INDICATOR, HORIZONTAL SITUATION	ROCKWELL COLLINS
522-2447-005		CONTROL, NAVIGATION	ROCKWELL COLLINS
522-2447-015	6625-00-063-6398	CONTROL, NAVIGATION	ROCKWELL COLLINS
522-2447-025		CONTROL, NAVIGATION	ROCKWELL COLLINS
522-2447-035		CONTROL, NAVIGATION	ROCKWELL COLLINS
522-2447-046		CONTROL, NAVIGATION	ROCKWELL COLLINS
522-2447-048		CONTROL, NAVIGATION	ROCKWELL COLLINS
522-2447-050	5826-00-028-6810	CONTROL, NAVIGATION	ROCKWELL COLLINS
522-2447-051		CONTROL, NAVIGATION	ROCKWELL COLLINS
522-2447-053		CONTROL, NAVIGATION	ROCKWELL COLLINS
522-2447-055		CONTROL, NAVIGATION	ROCKWELL COLLINS
522-2447-056		CONTROL, NAVIGATION	ROCKWELL COLLINS
522-2447-057		CONTROL, NAVIGATION	ROCKWELL COLLINS
522-2447-058		CONTROL, NAVIGATION	ROCKWELL COLLINS
522-2447-059		CONTROL, NAVIGATION	ROCKWELL COLLINS
522-2447-205		CONTROL, NAVIGATION	ROCKWELL COLLINS
522-2447-215	5826-01-077-7047	CONTROL, NAVIGATION	ROCKWELL COLLINS
522-2447-225		CONTROL, NAVIGATION	ROCKWELL COLLINS

522-2447-235		CONTROL, NAVIGATION	ROCKWELL COLLINS
522-2447-248		CONTROL, NAVIGATION	ROCKWELL COLLINS
522-2447-250	5825-01-044-1407	CONTROL, NAVIGATION	ROCKWELL COLLINS
522-2447-251	5821-01-090-2847	CONTROL, NAVIGATION	ROCKWELL COLLINS
522-2447-252	5895-01-099-8589	CONTROL, NAVIGATION	ROCKWELL COLLINS
522-2447-253	5821-01-049-5456	CONTROL, NAVIGATION	ROCKWELL COLLINS
522-2447-255		CONTROL, NAVIGATION	ROCKWELL COLLINS
522-2447-256	5895-01-416-2525	CONTROL, NAVIGATION	ROCKWELL COLLINS
522-2447-257		CONTROL, NAVIGATION	ROCKWELL COLLINS
522-2447-258		CONTROL, NAVIGATION	ROCKWELL COLLINS
522-2447-259		CONTROL, NAVIGATION	ROCKWELL COLLINS
522-2447-260		CONTROL, NAVIGATION	ROCKWELL COLLINS
522-2447-261		CONTROL, NAVIGATION	ROCKWELL COLLINS
522-2447-262	5821-01-503-5826	CONTROL, NAVIGATION	ROCKWELL COLLINS
522-2447-263	5821-01-278-0398	CONTROL, NAVIGATION	ROCKWELL COLLINS
522-2447-264	5895-01-416-2524	CONTROL, NAVIGATION	ROCKWELL COLLINS
522-2447-266		CONTROL, NAVIGATION	ROCKWELL COLLINS
522-2447-267		CONTROL, NAVIGATION	ROCKWELL COLLINS
522-2447-268		CONTROL, NAVIGATION	ROCKWELL COLLINS
522-2447-269		CONTROL, NAVIGATION	ROCKWELL COLLINS
522-2447-270		CONTROL, NAVIGATION	ROCKWELL COLLINS
522-2447-271	5826-01-369-4446	CONTROL, NAVIGATION	ROCKWELL COLLINS
522-2447-272		CONTROL, NAVIGATION	ROCKWELL COLLINS
522-2447-273		CONTROL, NAVIGATION	ROCKWELL COLLINS
522-2457-00	5821-00-019-8405	CONTROL, RADIO SET	ROCKWELL COLLINS
522-2457-000	5821-00-019-8405	CONTROL, RADIO SET	ROCKWELL COLLINS
522-2457-011		CONTROL, RADIO SET	ROCKWELL COLLINS
522-2457-012		CONTROL, RADIO SET	ROCKWELL COLLINS
522-2457-013		CONTROL, RADIO SET	ROCKWELL COLLINS
522-2457-014		CONTROL, RADIO SET	ROCKWELL COLLINS
522-2457-015		CONTROL, RADIO SET	ROCKWELL COLLINS
522-2457-016		CONTROL, RADIO SET	ROCKWELL COLLINS
522-2457-017		CONTROL, RADIO SET	ROCKWELL COLLINS
522-2457-018		CONTROL, RADIO SET	ROCKWELL COLLINS
522-2457-019		CONTROL, RADIO SET	ROCKWELL COLLINS
522-2457-020		CONTROL, RADIO SET	ROCKWELL COLLINS
522-2457-021		CONTROL, RADIO SET	ROCKWELL COLLINS
522-2457-022		CONTROL, RADIO SET	ROCKWELL COLLINS
522-2457-023		CONTROL, RADIO SET	ROCKWELL COLLINS
522-2457-024		CONTROL, RADIO SET	ROCKWELL COLLINS
522-2457-025		CONTROL, RADIO SET	ROCKWELL COLLINS
522-2457-026		CONTROL, RADIO SET	ROCKWELL COLLINS
522-2457-027		CONTROL, RADIO SET	ROCKWELL COLLINS
522-2457-028		CONTROL, RADIO SET	ROCKWELL COLLINS
522-2457-029		CONTROL, RADIO SET	ROCKWELL COLLINS
522-2457-030		CONTROL, RADIO SET	ROCKWELL COLLINS
522-2457-031		CONTROL, RADIO SET	ROCKWELL COLLINS
522-2457-032		CONTROL, RADIO SET	ROCKWELL COLLINS
522-2457-033		CONTROL, RADIO SET	ROCKWELL COLLINS
522-2457-034		CONTROL, RADIO SET	ROCKWELL COLLINS
522-2457-035		CONTROL, RADIO SET	ROCKWELL COLLINS
522-2457-036		CONTROL, RADIO SET	ROCKWELL COLLINS
522-2457-037		CONTROL, RADIO SET	ROCKWELL COLLINS

522-2457-038		CONTROL, RADIO SET	ROCKWELL COLLINS
522-2457-039		CONTROL, RADIO SET	ROCKWELL COLLINS
522-2457-040		CONTROL, RADIO SET	ROCKWELL COLLINS
522-2457-041		CONTROL, RADIO SET	ROCKWELL COLLINS
522-2457-042		CONTROL, RADIO SET	ROCKWELL COLLINS
522-2457-043		CONTROL, RADIO SET	ROCKWELL COLLINS
522-2615-005	5985-00-689-6576	ANTENNA, LOOP, ADF	ROCKWELL COLLINS
522-2615-006	5985-00-061-3079	ANTENNA, LOOP, ADF	ROCKWELL COLLINS
522-2646-000	5985-01-097-8681	ANTENNA, VHF	ROCKWELL COLLINS
522-2646-014		ANTENNA, VHF	ROCKWELL COLLINS
522-2703-011		TRANSPONDER	ROCKWELL COLLINS
522-2892-00		CONTROL, RADIO SET	ROCKWELL COLLINS
522-2892-011		CONTROL, RADIO SET	ROCKWELL COLLINS
522-2892-012		CONTROL, RADIO SET	ROCKWELL COLLINS
522-2892-013		CONTROL, RADIO SET	ROCKWELL COLLINS
522-2892-014		CONTROL, RADIO SET	ROCKWELL COLLINS
522-2892-015		CONTROL, RADIO SET	ROCKWELL COLLINS
522-2892-016		CONTROL, RADIO SET	ROCKWELL COLLINS
522-2892-017		CONTROL, RADIO SET	ROCKWELL COLLINS
522-2892-018		CONTROL, RADIO SET	ROCKWELL COLLINS
522-2900-002	6615-01-468-8150	CONTROL, SERVO, AUTO-PILOT	ROCKWELL COLLINS
522-2900-003		CONTROL, SERVO, AUTO-PILOT	ROCKWELL COLLINS
522-2900-005		CONTROL, SERVO, AUTO-PILOT	ROCKWELL COLLINS
522-2900-006		CONTROL, SERVO, AUTO-PILOT	ROCKWELL COLLINS
522-2900-008		CONTROL, SERVO, AUTO-PILOT	ROCKWELL COLLINS
522-2900-009		CONTROL, SERVO, AUTO-PILOT	ROCKWELL COLLINS
522-2900-010		CONTROL, SERVO, AUTO-PILOT	ROCKWELL COLLINS
522-2900-011		CONTROL, SERVO, AUTO-PILOT	ROCKWELL COLLINS
522-2900-013		CONTROL, SERVO, AUTO-PILOT	ROCKWELL COLLINS
522-2900-014		CONTROL, SERVO, AUTO-PILOT	ROCKWELL COLLINS
522-2900-015		CONTROL, SERVO, AUTO-PILOT	ROCKWELL COLLINS
522-2900-016	6615-01-391-4192	CONTROL, SERVO, AUTO-PILOT	ROCKWELL COLLINS
522-2900-017		CONTROL, SERVO, AUTO-PILOT	ROCKWELL COLLINS
522-2900-020		CONTROL, SERVO, AUTO-PILOT	ROCKWELL COLLINS
522-2900-021		CONTROL, SERVO, AUTO-PILOT	ROCKWELL COLLINS
522-2900-022		CONTROL, SERVO, AUTO-PILOT	ROCKWELL COLLINS
522-2900-023		CONTROL, SERVO, AUTO-PILOT	ROCKWELL COLLINS
522-2900-024		CONTROL, SERVO, AUTO-PILOT	ROCKWELL COLLINS
522-2900-025		CONTROL, SERVO, AUTO-PILOT	ROCKWELL COLLINS
522-2900-026		CONTROL, SERVO, AUTO-PILOT	ROCKWELL COLLINS
522-2900-027		CONTROL, SERVO, AUTO-PILOT	ROCKWELL COLLINS
522-2900-028		CONTROL, SERVO, AUTO-PILOT	ROCKWELL COLLINS
522-2900-057	6615-01-038-7294	CONTROL, SERVO, AUTO-PILOT	ROCKWELL COLLINS
522-2900-114		CONTROL, SERVO, AUTO-PILOT	ROCKWELL COLLINS
522-2900-16	6615-01-391-4192	CONTROL, SERVO, AUTO-PILOT	ROCKWELL COLLINS
522-2996-000	5826-00-960-0830	TRANSCEIVER, RADIO BEACON	ROCKWELL COLLINS
522-2996-014	5826-00-960-0830	TRANSCEIVER, RADIO BEACON	ROCKWELL COLLINS
522-3306-000	5826-01-131-6622	INDICATOR, OMNI BEARING	ROCKWELL COLLINS
522-3306-011	5826-00-404-0245	INDICATOR, OMNI BEARING	ROCKWELL COLLINS
522-3443-00	5985-00-939-7495	COUPLER, ANTENNA	ROCKWELL COLLINS
522-3443-000	5985-00-939-7495	COUPLER, ANTENNA	ROCKWELL COLLINS
522-3443-001	5985-00-954-1665	COUPLER, ANTENNA	ROCKWELL COLLINS
522-3443-006	5985-00-954-1665	COUPLER, ANTENNA	ROCKWELL COLLINS

522-3444-001	5985-00-852-0457	COUPLER, ANTENNA	ROCKWELL COLLINS
522-3698-002	5826-01-013-0955	TRANSCEIVER, RADIO ALTIMETER	ROCKWELL COLLINS
522-3698-003	5826-00-758-4546	TRANSCEIVER, RADIO ALTIMETER	ROCKWELL COLLINS
522-3698-004	5826-01-124-7459	TRANSCEIVER, RADIO ALTIMETER	ROCKWELL COLLINS
522-3698-005		TRANSCEIVER, RADIO ALTIMETER	ROCKWELL COLLINS
522-3698-006	5826-01-397-4398	TRANSCEIVER, RADIO ALTIMETER	ROCKWELL COLLINS
522-3761-001	5985-01-105-8719	ANTENNA, LOOP, ADF	ROCKWELL COLLINS
522-3761-002		ANTENNA, LOOP, ADF	ROCKWELL COLLINS
522-3903-001	5895-01-069-9153	CONTROL, RADIO SET	ROCKWELL COLLINS
522-3903-002	5821-01-332-4630	CONTROL, RADIO SET	ROCKWELL COLLINS
522-3985-001		GYROSCOPE, VERTICAL	ROCKWELL COLLINS
522-4057-001	5835-01-103-7517	RECORDER, SOUND	ROCKWELL COLLINS
522-4114-002	1680-01-481-5724	INDICATOR, RADIO ALTIMETER	ROCKWELL COLLINS
522-4114-003	5841-00-758-4547	INDICATOR, RADIO ALTIMETER	ROCKWELL COLLINS
522-4114-004		INDICATOR, RADIO ALTIMETER	ROCKWELL COLLINS
522-4114-006		INDICATOR, RADIO ALTIMETER	ROCKWELL COLLINS
522-4114-008		INDICATOR, RADIO ALTIMETER	ROCKWELL COLLINS
522-4114-012	5841-01-012-2184	INDICATOR, RADIO ALTIMETER	ROCKWELL COLLINS
522-4140-001	5985-00-758-4548	ANTENNA, RADIO ALTEMETER	ROCKWELL COLLINS
522-4140-002		ANTENNA, RADIO ALTEMETER	ROCKWELL COLLINS
522-4140-003		ANTENNA, RADIO ALTEMETER	ROCKWELL COLLINS
522-4140-004		ANTENNA, RADIO ALTEMETER	ROCKWELL COLLINS
522-4140-006	5985-00-758-4548	ANTENNA, RADIO ALTEMETER	ROCKWELL COLLINS
522-4140-007	5985-00-758-4548	ANTENNA, RADIO ALTEMETER	ROCKWELL COLLINS
522-4174-001	6610-00-763-2415	COMPUTER, FLIGHT DIRECTOR	ROCKWELL COLLINS
522-4255-001	5985-00-088-8562	ANTENNA, RADIO ALTEMETER	ROCKWELL COLLINS
522-4255-002		ANTENNA, RADIO ALTEMETER	ROCKWELL COLLINS
522-4255-003		ANTENNA, RADIO ALTEMETER	ROCKWELL COLLINS
522-4255-004		ANTENNA, RADIO ALTEMETER	ROCKWELL COLLINS
522-4329-001	5985-00-322-2172	ACCELEROMETER, ELECTRICAL, LINEAR	ROCKWELL COLLINS
522-4329-002	6615-01-043-2763	ACCELEROMETER, ELECTRICAL, LINEAR	ROCKWELL COLLINS
522-4354-002		INDICATOR, RADIO ALTIMETER	ROCKWELL COLLINS
522-4363-004		INDICATOR, RADIO ALTIMETER	ROCKWELL COLLINS
522-4706-001	6610-00-975-1699	INDICATOR, HORIZONTAL SITUATION	ROCKWELL COLLINS
522-4828-001	5826-01-496-3805	TRANSCEIVER, RADIO	ROCKWELL COLLINS
522-4828-002		TRANSCEIVER, RADIO	ROCKWELL COLLINS
522-4829-001	5826-01-095-1097	TRANSCEIVER, RADIO	ROCKWELL COLLINS
522-4829-002		TRANSCEIVER, RADIO	ROCKWELL COLLINS
522-4830-001	5821-01-033-8754	TRANSCEIVER, RADIO	ROCKWELL COLLINS
522-4830-002		TRANSCEIVER, RADIO	ROCKWELL COLLINS
522-4853-001	5985-00-617-7123	ANTENNA, LOOP, ADF	ROCKWELL COLLINS
523EA8	1680-00-078-4322	GEAR BOX ASSYFLAP DRIVEMOTOR DRIVEN	SARGENT AEROSPACE & DEFENSE
523EA9	1680-00-789-9345	GEAR BOX ASSYFLAP DRIVEMOTOR DRIVEN	SARGENT AEROSPACE & DEFENSE
52F12984	5826-00-522-3428	MOUNTING BASE ASSEMBLY	RAYTHEON
53150-1	4810-01-066-0321	VALVE, LINEAR, DIRECTIONAL CONTROL	EATON
53150-2	1650-01-217-3659	VALVE, LINEAR, DIRECTIONAL CONTROL	EATON
532-38105-201		INDICATOR, MAX ALLOWABLE AIRSPEED	KOLLSMAN
532-38105-202	6610-01-263-1400	INDICATOR, MAX ALLOWABLE AIRSPEED	KOLLSMAN
532-38105-203		INDICATOR, MAX ALLOWABLE AIRSPEED	KOLLSMAN
532-38105-204		INDICATOR, MAX ALLOWABLE AIRSPEED	KOLLSMAN
532-38105-301		INDICATOR, MAX ALLOWABLE AIRSPEED	KOLLSMAN
532-38105-302	6610-01-297-7004	INDICATOR, MAX ALLOWABLE AIRSPEED	KOLLSMAN
532-38105-303		INDICATOR, MAX ALLOWABLE AIRSPEED	KOLLSMAN

532-38105-304	6610-01-244-1521	INDICATOR, MAX ALLOWABLE AIRSPEED	KOLLSMAN
535429-0-1	6610-00-887-9422	MOUNT ASSY, COMPUTER RESILIENT	HONEYWELL INTERNATIONAL
538088-0-2	6610-00-991-0770	INDICATOR, TRUE AIR SPEED	HONEYWELL INTERNATIONAL
5386-106-01-11	6620-14-414-0225	INDICATOR, OIL, PRESSURE	ACTIA (THALES AVIONICS)
53C14232	5826-00-342-1964	COUPLING, ANTENNA	RAYTHEON
540-25100-004	1680-01-201-5691	ALERTER, ALTITUDE	KOLLSMAN
540-25100-005	6340-01-394-9780	ALERTER, ALTITUDE	KOLLSMAN
540-25100-021	1680-01-104-0475	ALERTER, ALTITUDE	KOLLSMAN
540-25100-022		ALERTER, ALTITUDE	KOLLSMAN
540-25100-034		ALERTER, ALTITUDE	KOLLSMAN
540-25100-134		ALERTER, ALTITUDE	KOLLSMAN
540538-2-1	1680-00-973-4891	ACTUATOR, ELECTRO-MECHANICAL, LINEAR	HONEYWELL INTERNATIONAL
541214-1-2	1660-00-777-0154	ACTUATOR,ELECTRO-MECHANICAL,ROTARY	HONEYWELL INTERNATIONAL
54D12603	5826-00-535-6629	CONTROL PANEL, DIRECTION FINDER	PHILIPS ELECTRONIC INSTRUMENTS
5502636-1	5996-00-458-2768	AMPLIFIER, ELECTRONIC TEMPERATURE DATUM	ABB BENDIX
5502636-2	5996-01-096-4648	AMPLIFIER, ELECTRONIC TEMPERATURE DATUM	ABB BENDIX
5502636-4	2915-01-221-6837	AMPLIFIER, ELECTRONIC TEMPERATURE DATUM	ABB BENDIX
5505067-3	5996-01-114-8652	AMPLIFIER, ELECTRONIC CONTROL	ABB BENDIX
551200-3	1650-00-395-2599	ACCUMULATOR ASSY, HYDRAULIC	HONEYWELL INTERNATIONAL
5579-501-01-11	6685-14-380-2742	INDICATOR, EGT	ACTIA (THALES AVIONICS)
5617-354-01-10	6685-14-380-2743	INDICATOR, TEMPERATURE	ACTIA (THALES AVIONICS)
562C-5	6615-01-038-7294	CONTROL, SERVO, AUTO-PILOT	ROCKWELL COLLINS
562C-5B		CONTROL, SERVO, AUTO-PILOT	ROCKWELL COLLINS
562C-5C	6615-01-020-3673	CONTROL, SERVO, AUTO-PILOT	ROCKWELL COLLINS
562C-5F		CONTROL, SERVO, AUTO-PILOT	ROCKWELL COLLINS
5633-701-01-10	6680-14-380-2744	INDICATOR, ENGINE, ELECTRICAL TACHOMETER	ACTIA (THALES AVIONICS)
568-4838-001	5826-01-008-4097	DIRECTION FINDER SET	ROCKWELL COLLINS
570-23932-001		ALTIMETER, PRESSURE	KOLLSMAN
570-23932-002		ALTIMETER, PRESSURE	KOLLSMAN
570-23932-003	6610-01-009-8021	ALTIMETER, PRESSURE	KOLLSMAN
570-23932-004	6660-01-020-3765	ALTIMETER, PRESSURE	KOLLSMAN
570-23932-005	6660-01-020-3765	ALTIMETER, PRESSURE	KOLLSMAN
570-23932-006		ALTIMETER, PRESSURE	KOLLSMAN
570-23932-008		ALTIMETER, PRESSURE	KOLLSMAN
570-23932-011		ALTIMETER, PRESSURE	KOLLSMAN
570-23932-012	6610-01-074-2819	ALTIMETER, PRESSURE	KOLLSMAN
570-23932-013		ALTIMETER, PRESSURE	KOLLSMAN
570-23932-014		ALTIMETER, PRESSURE	KOLLSMAN
570-23932-021		ALTIMETER, PRESSURE	KOLLSMAN
570-23932-022		ALTIMETER, PRESSURE	KOLLSMAN
570-23932-023		ALTIMETER, PRESSURE	KOLLSMAN
570-23932-024		ALTIMETER, PRESSURE	KOLLSMAN
570-23932-031		ALTIMETER, PRESSURE	KOLLSMAN
570-23932-032		ALTIMETER, PRESSURE	KOLLSMAN
570-23932-033		ALTIMETER, PRESSURE	KOLLSMAN
570-23932-034		ALTIMETER, PRESSURE	KOLLSMAN
570-23932-201		ALTIMETER, PRESSURE	KOLLSMAN
570-23932-202		ALTIMETER, PRESSURE	KOLLSMAN
570-23932-203		ALTIMETER, PRESSURE	KOLLSMAN
570-23932-204		ALTIMETER, PRESSURE	KOLLSMAN
570-23932-211		ALTIMETER, PRESSURE	KOLLSMAN
570-23932-212		ALTIMETER, PRESSURE	KOLLSMAN
570-23932-213		ALTIMETER, PRESSURE	KOLLSMAN



570-23932-214		ALTIMETER, PRESSURE	KOLLSMAN
570-23932-301		ALTIMETER, PRESSURE	KOLLSMAN
570-23932-302		ALTIMETER, PRESSURE	KOLLSMAN
570-23932-303		ALTIMETER, PRESSURE	KOLLSMAN
570-23932-304		ALTIMETER, PRESSURE	KOLLSMAN
570-23932-311		ALTIMETER, PRESSURE	KOLLSMAN
570-23932-312		ALTIMETER, PRESSURE	KOLLSMAN
570-23932-313		ALTIMETER, PRESSURE	KOLLSMAN
570-23932-314		ALTIMETER, PRESSURE	KOLLSMAN
570-23932-401		ALTIMETER, PRESSURE	KOLLSMAN
570-23932-402		ALTIMETER, PRESSURE	KOLLSMAN
570-23932-403		ALTIMETER, PRESSURE	KOLLSMAN
570-23932-404		ALTIMETER, PRESSURE	KOLLSMAN
570-23932-411		ALTIMETER, PRESSURE	KOLLSMAN
570-23932-412		ALTIMETER, PRESSURE	KOLLSMAN
570-23932-413		ALTIMETER, PRESSURE	KOLLSMAN
570-23932-414	6610-01-294-5633	ALTIMETER, PRESSURE	KOLLSMAN
570-23932-901	6610-01-329-9067	ALTIMETER, PRESSURE	KOLLSMAN
570-23932-902		ALTIMETER, PRESSURE	KOLLSMAN
5712-10	6620-14-406-3186	TRANSMITTER, PRESSURE	KOLLSMAN
57-12-10	6620-14-406-3186	TRANSMITTER, PRESSURE	LABEM
5728N1	6610-14-423-7041	INDICATOR, TURN AND SLIP	AIR PRECISION
575-7	6340-00-304-5556	DETECTOR, ICE	NORTHERN TELECOM
575-716	5930-00-615-7340	SWITCH, PRESSURE	NORTHERN TELECOM
578578	1610-00-034-6051	SYNCHROPHASER, PROPELLER	HAMILTON SUNDSTRAND
58057-1	6605-14-510-2970	GYROSCOPE, COMPASS	SFIM INDUSTRIES
58057-11		GYROSCOPE, COMPASS	SFIM INDUSTRIES
58057-12	6605-14-369-3134	GYROSCOPE, COMPASS	SFIM INDUSTRIES
58057-13		GYROSCOPE, COMPASS	SFIM INDUSTRIES
58057-32	6605-14-558-0093	GYROSCOPE, COMPASS	SFIM INDUSTRIES
58057-33		GYROSCOPE, COMPASS	SFIM INDUSTRIES
58057-34		GYROSCOPE, COMPASS	SFIM INDUSTRIES
58057-35		GYROSCOPE, COMPASS	SFIM INDUSTRIES
58057-4		GYROSCOPE, COMPASS	SFIM INDUSTRIES
58057-41		GYROSCOPE, COMPASS	SFIM INDUSTRIES
58057-42	6605-14-369-3135	GYROSCOPE, COMPASS	SFIM INDUSTRIES
58057-43		GYROSCOPE, COMPASS	SFIM INDUSTRIES
58057-82	6605-14-369-3135	GYROSCOPE, COMPASS	SFIM INDUSTRIES
58057-83	6605-14-387-2597	GYROSCOPE, COMPASS	SFIM INDUSTRIES
58057-84		GYROSCOPE, COMPASS	SFIM INDUSTRIES
58057-85	6605-14-433-6921	GYROSCOPE, COMPASS	SFIM INDUSTRIES
588530-3	1660-00-760-0622	INDICATOR, AIRCRAFT AIR TEMPERATURE, SELECTOR	HAMILTON SUNDSTRAND
588530-5	1660-01-097-8733	INDICATOR, AIRCRAFT AIR TEMPERATURE, SELECTOR	HAMILTON SUNDSTRAND
588531-3		CONTROL UNIT, AIRCRAFT AIR TEMPERATURE	HAMILTON SUNDSTRAND
588531-5	1660-00-918-6727	CONTROL UNIT, AIRCRAFT AIR TEMPERATURE	HAMILTON SUNDSTRAND
588531-7	1660-01-097-8747	CONTROL UNIT, AIRCRAFT AIR TEMPERATURE	HAMILTON SUNDSTRAND
58C12681	5965-01-128-1410	HEADSET, MICROPHONE	ASTROCOM ELECTRONICS
58C12682	5965-01-127-3890	HEADSET, MICROPHONE	ASTROCOM ELECTRONICS
58F12501	5826-00-629-8309	MOUNTING BASE ASSEMBLY	RAYTHEON
590A-3H		CONTROL, AIR DATA	ROCKWELL COLLINS
590A-3J	6615-01-038-7296	CONTROL, AIR DATA	ROCKWELL COLLINS
590A-3J1		CONTROL, AIR DATA	ROCKWELL COLLINS
590A-3K		CONTROL, AIR DATA	ROCKWELL COLLINS

590A-3K1	6615-01-188-4494	CONTROL, AIR DATA	ROCKWELL COLLINS
590A-3KI	6615-01-188-4494	CONTROL, AIR DATA	ROCKWELL COLLINS
593-8655-001		CONTROL, RADIO SET	ROCKWELL COLLINS
5965PL0644579	5965-01-128-1410	HEADSET, MICROPHONE	JEDNOLITY INDEKS
597-2259-301	5826-14-547-0474	RECEIVER PROCESSOR	ROCKWELL COLLINS
5A527	2935-00-966-3321	COOLER, ENGINE, OIL	STANDARD THOMSON
5A527-000	2935-00-966-3321	COOLER, ENGINE, OIL	STANDARD THOMSON
5A844	4820-00-072-5573	VALVE, OIL TEMPERATURE, REGULATING	STANDARD THOMSON
5A844-000	4820-00-072-5573	VALVE, OIL TEMPERATURE, REGULATING	STANDARD THOMSON
6002052-1		SENSOR, WHEEL SPEED	STANDARD THOMSON
6002052-2		SENSOR, WHEEL SPEED	MEGGITT AIRCRAFT BRAKING SYSTEMS
6002052-3	1630-01-217-3141	SENSOR, WHEEL SPEED	MEGGITT AIRCRAFT BRAKING SYSTEMS
6002052-4		SENSOR, WHEEL SPEED	MEGGITT AIRCRAFT BRAKING SYSTEMS
600A835.112	5965-01-128-1410	HEADSET, MICROPHONE	ASC SCHUEBEL ELECTRONIC
600A835.113	5965-01-127-3890	HEADSET, MICROPHONE	ASC SCHUEBEL ELECTRONIC
60-2650-1	6130-01-017-5448	POWER SUPPLY	MEGGITT AIRCRAFT BRAKING SYSTEMS
60-2927-1	6130-01-139-3549	POWER SUPPLY, FLASHTUBE	GRIMES AEROSPACE
60-551	4320-00-631-4859	PUMP, ROTARY	HYDRO-AIRE
605600-1-1		FAN, TUBE, AXIAL	HONEYWELL INTERNATIONAL
605600-2-1	4140-00-924-8116	FAN, TUBE, AXIAL	HONEYWELL INTERNATIONAL
60-5851	4320-00-631-4859	PUMP, ROTARY	HYDRO-AIRE
614E-20R		SELECTOR, FLIGHT MODE	ROCKWELL COLLINS
614E-20S		SELECTOR, FLIGHT MODE	ROCKWELL COLLINS
614E-22B		SELECTOR, HEADING, REMOTE	ROCKWELL COLLINS
614E-22F		SELECTOR, HEADING, REMOTE	ROCKWELL COLLINS
614E-22M	1680-01-537-2927	SELECTOR, HEADING, REMOTE	ROCKWELL COLLINS
614E-23R	6615-01-038-7295	SELECTOR, FLIGHT MODE	ROCKWELL COLLINS
614E-37		SELECTOR, FLIGHT MODE	ROCKWELL COLLINS
614E-5A	6615-01-038-7299	CONTROLLER, FLIGHT, AUTOPILOT	ROCKWELL COLLINS
616297-57	5831-00-987-1815	CONTROL BOX	LOCKHEED MARTIN
618368-5	6220-00-572-6413	LIGHT, EMERGENCY, ROTATING	LOCKHEED MARTIN
618368-7	6220-00-691-1189	LIGHT, EMERGENCY, ROTATING	LOCKHEED MARTIN
618M-3		TRANSCEIVER, VHF, RADIO	ROCKWELL COLLINS
618M-3A		TRANSCEIVER, VHF, RADIO	ROCKWELL COLLINS
618M-4		TRANSCEIVER, VHF, RADIO	ROCKWELL COLLINS
618M-4A		TRANSCEIVER, VHF, RADIO	ROCKWELL COLLINS
618M-5		TRANSCEIVER, VHF, RADIO	ROCKWELL COLLINS
618M-5A		TRANSCEIVER, VHF, RADIO	ROCKWELL COLLINS
618T-1	5821-00-123-4846	TRANSCEIVER, RADIO	ROCKWELL COLLINS
618T-1B		TRANSCEIVER, RADIO	ROCKWELL COLLINS
618T-2	5821-00-123-4853	TRANSCEIVER, RADIO	ROCKWELL COLLINS
618T-2B	5826-01-095-1097	TRANSCEIVER, RADIO	ROCKWELL COLLINS
618T-3	5821-00-604-3307	TRANSCEIVER, RADIO	ROCKWELL COLLINS
618T-3B		TRANSCEIVER, RADIO	ROCKWELL COLLINS
618T-4		TRANSCEIVER, RADIO	ROCKWELL COLLINS
618T-4B		TRANSCEIVER, RADIO	ROCKWELL COLLINS
618T-5		TRANSCEIVER, RADIO	ROCKWELL COLLINS
618T-5B		TRANSCEIVER, RADIO	ROCKWELL COLLINS
618T-6		TRANSCEIVER, RADIO	ROCKWELL COLLINS
618T-6B		TRANSCEIVER, RADIO	ROCKWELL COLLINS
619209-1	6220-00-858-0915	LIGHT, AIRCRAFT, LANDING	LOCKHEED MARTIN
620572-1	1650-00-566-0331	VALVE, TRANSFER, AUTOMATIC PILOT	LOCKHEED MARTIN
620577-1	6615-00-550-6628	GYROSCOPE, DISPLACEMENT	LOCKHEED MARTIN

620664-11	6610-00-759-7170	COMPUTER, TRUE AIR SPEED	LOCKHEED MARTIN
620865-103	6620-00-928-0216	INDICATOR, TORQUEMETER	SIMMONDS PRECISION PRODUCTS
620865-107	6620-00-148-7313	INDICATOR, TORQUEMETER	SIMMONDS PRECISION PRODUCTS
622-0181-001	6625-01-092-5410	GYROSCOPE, RATE OF TURN	ROCKWELL COLLINS
622-0181-002	6615-01-074-7193	GYROSCOPE, RATE OF TURN	ROCKWELL COLLINS
622-0181-003	6615-01-074-7193	GYROSCOPE, RATE OF TURN	ROCKWELL COLLINS
622-0356-001	5821-00-100-7931	TRANSCEIVER, UHF, RADIO	ROCKWELL COLLINS
622-0356-002	5821-01-020-3970	TRANSCEIVER, UHF, RADIO	ROCKWELL COLLINS
622-0507-001	5826-01-012-1938	TRANSCEIVER, TACAN	ROCKWELL COLLINS
622-0507-002	5821-01-411-2680	TRANSCEIVER, TACAN	ROCKWELL COLLINS
622-0507-004		TRANSCEIVER, TACAN	ROCKWELL COLLINS
622-0507-005	5821-01-324-1976	TRANSCEIVER, TACAN	ROCKWELL COLLINS
622-0507-006	5826-01-455-8243	TRANSCEIVER, TACAN	ROCKWELL COLLINS
622-0748-001	5895-01-012-1919	CONTROL PANEL, TACAN, TRANSCEIVER	ROCKWELL COLLINS
622-0748-002	5895-01-012-1920	CONTROL PANEL, TACAN, TRANSCEIVER	ROCKWELL COLLINS
622-0876-001	5895-01-014-1704	RECEIVER, RADIO NAVIGATION	ROCKWELL COLLINS
622-0876-002		RECEIVER, RADIO NAVIGATION	ROCKWELL COLLINS
622-0876-003		RECEIVER, RADIO NAVIGATION	ROCKWELL COLLINS
622-0876-004	5820-01-359-9930	RECEIVER, RADIO NAVIGATION	ROCKWELL COLLINS
622-0876-011	5826-01-309-9786	RECEIVER, RADIO NAVIGATION	ROCKWELL COLLINS
622-0876-012		RECEIVER, RADIO NAVIGATION	ROCKWELL COLLINS
622-0876-013		RECEIVER, RADIO NAVIGATION	ROCKWELL COLLINS
622-0876-014		RECEIVER, RADIO NAVIGATION	ROCKWELL COLLINS
622-0876-201		RECEIVER, RADIO NAVIGATION	ROCKWELL COLLINS
622-0876-202		RECEIVER, RADIO NAVIGATION	ROCKWELL COLLINS
622-0876-203		RECEIVER, RADIO NAVIGATION	ROCKWELL COLLINS
622-0876-204		RECEIVER, RADIO NAVIGATION	ROCKWELL COLLINS
622-0876-211		RECEIVER, RADIO NAVIGATION	ROCKWELL COLLINS
622-0876-212		RECEIVER, RADIO NAVIGATION	ROCKWELL COLLINS
622-0876-213		RECEIVER, RADIO NAVIGATION	ROCKWELL COLLINS
622-0876-214		RECEIVER, RADIO NAVIGATION	ROCKWELL COLLINS
622-0877-001		RECEIVER, RADIO NAVIGATION	ROCKWELL COLLINS
622-0877-002		RECEIVER, RADIO NAVIGATION	ROCKWELL COLLINS
622-0877-003		RECEIVER, RADIO NAVIGATION	ROCKWELL COLLINS
622-0877-004		RECEIVER, RADIO NAVIGATION	ROCKWELL COLLINS
622-0877-201		RECEIVER, RADIO NAVIGATION	ROCKWELL COLLINS
622-0877-202		RECEIVER, RADIO NAVIGATION	ROCKWELL COLLINS
622-0877-203		RECEIVER, RADIO NAVIGATION	ROCKWELL COLLINS
622-0877-204		RECEIVER, RADIO NAVIGATION	ROCKWELL COLLINS
622-0902-001	5826-01-008-4097	DIRECTION FINDER SET	ROCKWELL COLLINS
622-0902-005	5826-01-008-4097	DIRECTION FINDER SET	ROCKWELL COLLINS
622-0944-003	5930-01-420-7373	SELECTOR, FLIGHT MODE	ROCKWELL COLLINS
622-0944-006		SELECTOR, FLIGHT MODE	ROCKWELL COLLINS
622-0944-007		SELECTOR, FLIGHT MODE	ROCKWELL COLLINS
622-0945-003	5895-01-015-3713	SELECTOR, FLIGHT MODE	ROCKWELL COLLINS
622-0945-006	5826-01-422-5470	SELECTOR, FLIGHT MODE	ROCKWELL COLLINS
622-0945-007	6615-01-038-7295	SELECTOR, FLIGHT MODE	ROCKWELL COLLINS
622-0945-008		SELECTOR, FLIGHT MODE	ROCKWELL COLLINS
622-0945-017	6615-01-394-6499	SELECTOR, FLIGHT MODE	ROCKWELL COLLINS
622-0950-001	5895-01-020-3852	SELECTOR, FLIGHT MODE	ROCKWELL COLLINS
622-0950-002	6610-01-117-3659	SELECTOR, FLIGHT MODE	ROCKWELL COLLINS
622-1001-001	5895-01-013-0722	CONTROL, AIR DATA	ROCKWELL COLLINS
622-1001-002	6615-01-038-7296	CONTROL, AIR DATA	ROCKWELL COLLINS

622-1001-019	6610-01-360-3564	CONTROL, AIR DATA	ROCKWELL COLLINS
622-1116-004		CONTROL, SERVO, AUTO-PILOT	ROCKWELL COLLINS
622-1116-018		CONTROL, SERVO, AUTO-PILOT	ROCKWELL COLLINS
622-1116-019		CONTROL, SERVO, AUTO-PILOT	ROCKWELL COLLINS
622-1181-001	5895-01-215-0303	TRANSCEIVER, VHF, RADIO	ROCKWELL COLLINS
622-1181-002		TRANSCEIVER, VHF, RADIO	ROCKWELL COLLINS
622-1181-003		TRANSCEIVER, VHF, RADIO	ROCKWELL COLLINS
622-1181-004	5895-01-215-0303	TRANSCEIVER, VHF, RADIO	ROCKWELL COLLINS
622-1181-005		TRANSCEIVER, VHF, RADIO	ROCKWELL COLLINS
622-1181-006	5821-01-473-7187	TRANSCEIVER, VHF, RADIO	ROCKWELL COLLINS
622-1181-008		TRANSCEIVER, VHF, RADIO	ROCKWELL COLLINS
622-1239-001	5826-01-120-5991	RECEIVER, RADIO NAVIGATION	ROCKWELL COLLINS
622-1239-002		RECEIVER, RADIO NAVIGATION	ROCKWELL COLLINS
622-1239-003		RECEIVER, RADIO NAVIGATION	ROCKWELL COLLINS
622-1239-004		RECEIVER, RADIO NAVIGATION	ROCKWELL COLLINS
622-1239-007	5826-01-486-8271	RECEIVER, RADIO NAVIGATION	ROCKWELL COLLINS
622-1239-008		RECEIVER, RADIO NAVIGATION	ROCKWELL COLLINS
622-1239-009	5826-01-074-7167	RECEIVER, RADIO NAVIGATION	ROCKWELL COLLINS
622-1239-011	5826-01-202-7420	RECEIVER, RADIO NAVIGATION	ROCKWELL COLLINS
622-1239-012	5821-01-130-3162	RECEIVER, RADIO NAVIGATION	ROCKWELL COLLINS
622-1239-013		RECEIVER, RADIO NAVIGATION	ROCKWELL COLLINS
622-1239-014		RECEIVER, RADIO NAVIGATION	ROCKWELL COLLINS
622-1239-027	5826-01-136-7886	RECEIVER, RADIO NAVIGATION	ROCKWELL COLLINS
622-1239-201	5826-01-482-4504	RECEIVER, RADIO NAVIGATION	ROCKWELL COLLINS
622-1239-202		RECEIVER, RADIO NAVIGATION	ROCKWELL COLLINS
622-1239-203		RECEIVER, RADIO NAVIGATION	ROCKWELL COLLINS
622-1239-204		RECEIVER, RADIO NAVIGATION	ROCKWELL COLLINS
622-1239-207	5999-01-494-1903	RECEIVER, RADIO NAVIGATION	ROCKWELL COLLINS
622-1239-208	5820-01-450-7989	RECEIVER, RADIO NAVIGATION	ROCKWELL COLLINS
622-1239-209		RECEIVER, RADIO NAVIGATION	ROCKWELL COLLINS
622-1239-211	5826-01-482-4505	RECEIVER, RADIO NAVIGATION	ROCKWELL COLLINS
622-1239-212	5999-01-487-6103	RECEIVER, RADIO NAVIGATION	ROCKWELL COLLINS
622-1239-213		RECEIVER, RADIO NAVIGATION	ROCKWELL COLLINS
622-1239-214	5826-01-482-4506	RECEIVER, RADIO NAVIGATION	ROCKWELL COLLINS
622-1239-227	5826-01-487-7615	RECEIVER, RADIO NAVIGATION	ROCKWELL COLLINS
622-1275-002	5826-01-479-7796	RECEIVER, RADIO NAVIGATION	ROCKWELL COLLINS
622-1281-001	6615-01-020-3673	AMPLIFIER, AUTOPILOT	ROCKWELL COLLINS
622-1281-007		AMPLIFIER, AUTOPILOT	ROCKWELL COLLINS
622-1396-001	5820-01-087-6982	TRANSCEIVER, VHF, RADIO	ROCKWELL COLLINS
622-1396-002	5821-01-038-7301	TRANSCEIVER, VHF, RADIO	ROCKWELL COLLINS
622-1396-003	5821-01-083-0695	TRANSCEIVER, VHF, RADIO	ROCKWELL COLLINS
622-1396-010		TRANSCEIVER, VHF, RADIO	ROCKWELL COLLINS
622-1396-011		TRANSCEIVER, VHF, RADIO	ROCKWELL COLLINS
622-1396-101	5895-01-357-4630	TRANSCEIVER, VHF, RADIO	ROCKWELL COLLINS
622-1396-102	5821-01-316-3554	TRANSCEIVER, VHF, RADIO	ROCKWELL COLLINS
622-1396-103	5821-01-363-5414	TRANSCEIVER, VHF, RADIO	ROCKWELL COLLINS
622-1396-110		TRANSCEIVER, VHF, RADIO	ROCKWELL COLLINS
622-1396-111		TRANSCEIVER, VHF, RADIO	ROCKWELL COLLINS
622-1396-203		TRANSCEIVER, VHF, RADIO	ROCKWELL COLLINS
622-1396-205		TRANSCEIVER, VHF, RADIO	ROCKWELL COLLINS
622-1396-206		TRANSCEIVER, VHF, RADIO	ROCKWELL COLLINS
622-1396-208		TRANSCEIVER, VHF, RADIO	ROCKWELL COLLINS
622-1396-209		TRANSCEIVER, VHF, RADIO	ROCKWELL COLLINS

622-1396-210		TRANSCEIVER, VHF, RADIO	ROCKWELL COLLINS
622-1406-001		SELECTOR, HEADING, REMOTE	ROCKWELL COLLINS
622-1678-001	5826-01-012-4864	ADAPTER, TACAN, TRANSCEIVER	ROCKWELL COLLINS
622-1678-002	5895-01-289-5677	ADAPTER, TACAN, TRANSCEIVER	ROCKWELL COLLINS
622-1678-004	5895-01-289-5677	ADAPTER, TACAN, TRANSCEIVER	ROCKWELL COLLINS
622-1679-001	5975-01-060-9629	MOUNTING BASE, TACAN, TRANSCEIVER	ROCKWELL COLLINS
622-1680-001	5975-01-013-0861	MOUNTING BASE, TACAN, TRANSCEIVER	ROCKWELL COLLINS
622-1680-002	5975-01-131-4232	MOUNTING BASE, TACAN, TRANSCEIVER	ROCKWELL COLLINS
622-1680-003	5975-01-151-9680	MOUNTING BASE, TACAN, TRANSCEIVER	ROCKWELL COLLINS
622-1680-004	5975-01-045-6683	MOUNTING BASE, TACAN, TRANSCEIVER	ROCKWELL COLLINS
622-1680-005	5975-01-154-9194	MOUNTING BASE, TACAN, TRANSCEIVER	ROCKWELL COLLINS
622-1782-001	5975-01-013-0862	MOUNTING BASE, TACAN, TRANSCEIVER	ROCKWELL COLLINS
622-1782-002	5975-01-034-5476	MOUNTING BASE, TACAN, TRANSCEIVER	ROCKWELL COLLINS
622-1783-001	5975-01-012-1857	MOUNTING BASE, TACAN, TRANSCEIVER	ROCKWELL COLLINS
622-1783-002	5975-01-034-5477	MOUNTING BASE, TACAN, TRANSCEIVER	ROCKWELL COLLINS
622-1783-003	5975-01-062-5189	MOUNTING BASE, TACAN, TRANSCEIVER	ROCKWELL COLLINS
622-1783-005	5975-01-208-8418	MOUNTING BASE, TACAN, TRANSCEIVER	ROCKWELL COLLINS
622-2041-001	5975-01-041-2044	MOUNTING BASE, TACAN, TRANSCEIVER	ROCKWELL COLLINS
622-2041-002		MOUNTING BASE, TACAN, TRANSCEIVER	ROCKWELL COLLINS
622-2360-001	5895-01-012-7084	CONTROL PANEL, TACAN, TRANSCEIVER	ROCKWELL COLLINS
622-2360-002	5895-01-012-7085	CONTROL PANEL, TACAN, TRANSCEIVER	ROCKWELL COLLINS
622-2362-001	5826-01-125-1023	RECEIVER, ADF	ROCKWELL COLLINS
622-2363-001	5985-01-112-8057	ANTENNA, ADF	ROCKWELL COLLINS
622-2363-002		ANTENNA, ADF	ROCKWELL COLLINS
622-2510-001	5895-01-037-6772	CONTROL PANEL, TACAN, TRANSCEIVER	ROCKWELL COLLINS
622-2510-002	5895-01-079-7568	CONTROL PANEL, TACAN, TRANSCEIVER	ROCKWELL COLLINS
622-2510-003	5895-01-075-9774	CONTROL PANEL, TACAN, TRANSCEIVER	ROCKWELL COLLINS
622-2511-001	5895-01-014-3656	CONTROL PANEL, TACAN, TRANSCEIVER	ROCKWELL COLLINS
622-2511-002	5895-01-018-3511	CONTROL PANEL, TACAN, TRANSCEIVER	ROCKWELL COLLINS
622-2586-001		TRANSCEIVER, RADIO	ROCKWELL COLLINS
622-2586-002		TRANSCEIVER, RADIO	ROCKWELL COLLINS
622-2587-001		TRANSCEIVER, RADIO	ROCKWELL COLLINS
622-2588-001		TRANSCEIVER, RADIO	ROCKWELL COLLINS
622-2588-002	5821-01-069-1018	TRANSCEIVER, RADIO	ROCKWELL COLLINS
622-2589-001		TRANSCEIVER, RADIO	ROCKWELL COLLINS
622-2590-001		TRANSCEIVER, RADIO	ROCKWELL COLLINS
622-2590-002		TRANSCEIVER, RADIO	ROCKWELL COLLINS
622-2591-001	5895-01-069-3279	TRANSCEIVER, RADIO	ROCKWELL COLLINS
622-2614-012		CONTROL, SERVO, AUTO-PILOT	ROCKWELL COLLINS
622-2819-001		RECEIVER, RADIO NAVIGATION	ROCKWELL COLLINS
622-2819-002		RECEIVER, RADIO NAVIGATION	ROCKWELL COLLINS
622-2819-003		RECEIVER, RADIO NAVIGATION	ROCKWELL COLLINS
622-2819-004		RECEIVER, RADIO NAVIGATION	ROCKWELL COLLINS
622-2819-201	5826-01-507-9558	RECEIVER, RADIO NAVIGATION	ROCKWELL COLLINS
622-2819-202		RECEIVER, RADIO NAVIGATION	ROCKWELL COLLINS
622-2819-203		RECEIVER, RADIO NAVIGATION	ROCKWELL COLLINS
622-2819-204		RECEIVER, RADIO NAVIGATION	ROCKWELL COLLINS
622-2855-001	5841-01-272-2715	ALTIMETER SET, ELECTRONIC	ROCKWELL COLLINS
622-2873-001	5825-01-335-5226	RECEIVER, ADF	ROCKWELL COLLINS
622-2889-001	5826-01-554-6297	ADAPTER, BEARING	ROCKWELL COLLINS
622-2889-002	5826-MD-010-2546	ADAPTER, BEARING	ROCKWELL COLLINS
622-2921-002	5826-01-126-6339	EQUIPMENT, DISTANCE	ROCKWELL COLLINS
622-3177-001	5895-01-448-0873	TRANSCEIVER, DME	ROCKWELL COLLINS

622-3178-001		TRANSCEIVER, ADF	ROCKWELL COLLINS
622-3178-002		TRANSCEIVER, ADF	ROCKWELL COLLINS
622-3178-003	5820-01-301-9433	TRANSCEIVER, ADF	ROCKWELL COLLINS
622-3178-004		TRANSCEIVER, ADF	ROCKWELL COLLINS
622-3179-001		TRANSCEIVER, ADF	ROCKWELL COLLINS
622-3179-002		TRANSCEIVER, ADF	ROCKWELL COLLINS
622-3179-003		TRANSCEIVER, ADF	ROCKWELL COLLINS
622-3179-004	5826-01-194-5731	TRANSCEIVER, ADF	ROCKWELL COLLINS
622-3204-001		CONTROL, AIR DATA	ROCKWELL COLLINS
622-3204-042		CONTROL, AIR DATA	ROCKWELL COLLINS
622-3255-001	5820-01-208-8750	RECEIVER, VOR/ILS RADIO NAVIGATION	ROCKWELL COLLINS
622-3255-002	5826-01-360-2878	RECEIVER, VOR/ILS RADIO NAVIGATION	ROCKWELL COLLINS
622-3255-003		RECEIVER, VOR/ILS RADIO NAVIGATION	ROCKWELL COLLINS
622-3255-004	5826-01-499-1906	RECEIVER, VOR/ILS RADIO NAVIGATION	ROCKWELL COLLINS
622-3255-005		RECEIVER, VOR/ILS RADIO NAVIGATION	ROCKWELL COLLINS
622-3255-006		RECEIVER, VOR/ILS RADIO NAVIGATION	ROCKWELL COLLINS
622-3255-007		RECEIVER, VOR/ILS RADIO NAVIGATION	ROCKWELL COLLINS
622-3255-008		RECEIVER, VOR/ILS RADIO NAVIGATION	ROCKWELL COLLINS
622-3255-009		RECEIVER, VOR/ILS RADIO NAVIGATION	ROCKWELL COLLINS
622-3257-001	5826-01-129-6079	RECEIVER, VOR/ILS RADIO NAVIGATION	ROCKWELL COLLINS
622-3257-002		RECEIVER, VOR/ILS RADIO NAVIGATION	ROCKWELL COLLINS
622-3257-003	5826-01-251-4020	RECEIVER, VOR/ILS RADIO NAVIGATION	ROCKWELL COLLINS
622-3257-004	5826-01-601-6931	RECEIVER, VOR/ILS RADIO NAVIGATION	ROCKWELL COLLINS
622-3257-005		RECEIVER, VOR/ILS RADIO NAVIGATION	ROCKWELL COLLINS
622-3257-006		RECEIVER, VOR/ILS RADIO NAVIGATION	ROCKWELL COLLINS
622-3257-007		RECEIVER, VOR/ILS RADIO NAVIGATION	ROCKWELL COLLINS
622-3257-008		RECEIVER, VOR/ILS RADIO NAVIGATION	ROCKWELL COLLINS
622-3257-009		RECEIVER, VOR/ILS RADIO NAVIGATION	ROCKWELL COLLINS
622-3257-010	5826-01-548-2159	RECEIVER, VOR/ILS RADIO NAVIGATION	ROCKWELL COLLINS
622-3257-011		RECEIVER, VOR/ILS RADIO NAVIGATION	ROCKWELL COLLINS
622-3257-012		RECEIVER, VOR/ILS RADIO NAVIGATION	ROCKWELL COLLINS
622-3257-013		RECEIVER, VOR/ILS RADIO NAVIGATION	ROCKWELL COLLINS
622-3257-101		RECEIVER, VOR/ILS RADIO NAVIGATION	ROCKWELL COLLINS
622-3257-201		RECEIVER, VOR/ILS RADIO NAVIGATION	ROCKWELL COLLINS
622-3259-002		RECEIVER, VOR/ILS RADIO NAVIGATION	ROCKWELL COLLINS
622-3259-003		RECEIVER, VOR/ILS RADIO NAVIGATION	ROCKWELL COLLINS
622-3259-005		RECEIVER, VOR/ILS RADIO NAVIGATION	ROCKWELL COLLINS
622-3343-001		INDICATOR, ATTITUDE DIRECTOR	ROCKWELL COLLINS
622-3343-002		INDICATOR, ATTITUDE DIRECTOR	ROCKWELL COLLINS
622-3344-002	6610-01-620-8831	INDICATOR, ATTITUDE DIRECTOR	ROCKWELL COLLINS
622-3371-001	5820-01-312-2024	TRANSCEIVER, RADIO	ROCKWELL COLLINS
622-3372-001	5820-01-183-3036	TRANSCEIVER, RADIO	ROCKWELL COLLINS
622-3374-002	6610-01-101-1927	INDICATOR, ATTITUDE DIRECTOR	ROCKWELL COLLINS
622-3710-001	5985-01-258-5646	ANTENNA, ADF	ROCKWELL COLLINS
622-3765-001	5975-01-037-6649	MOUNTING BASE, TACAN, TRANSCEIVER	ROCKWELL COLLINS
622-3766-001	5975-01-039-7621	MOUNTING BASE, TACAN, TRANSCEIVER	ROCKWELL COLLINS
622-3881-001		INDICATOR, DME	ROCKWELL COLLINS
622-3881-002		INDICATOR, DME	ROCKWELL COLLINS
622-3890-002	5999-01-234-9779	TRANSCEIVER, RADIO ALTIMITER	ROCKWELL COLLINS
622-3890-003	5841-01-220-1390	TRANSCEIVER, RADIO ALTIMITER	ROCKWELL COLLINS
622-3890-004	5826-01-124-7459	TRANSCEIVER, RADIO ALTIMITER	ROCKWELL COLLINS
622-3890-005		TRANSCEIVER, RADIO ALTIMITER	ROCKWELL COLLINS
622-3890-006		TRANSCEIVER, RADIO ALTIMITER	ROCKWELL COLLINS

622-3890-008	5826-01-124-4793	TRANSCEIVER, RADIO ALTIMETER	ROCKWELL COLLINS
622-3890-011	5826-01-197-9612	TRANSCEIVER, RADIO ALTIMETER	ROCKWELL COLLINS
622-3890-013		TRANSCEIVER, RADIO ALTIMETER	ROCKWELL COLLINS
622-3890-014		TRANSCEIVER, RADIO ALTIMETER	ROCKWELL COLLINS
622-3890-015		TRANSCEIVER, RADIO ALTIMETER	ROCKWELL COLLINS
622-3890-018	5841-01-328-8012	TRANSCEIVER, RADIO ALTIMETER	ROCKWELL COLLINS
622-3890-102		TRANSCEIVER, RADIO ALTIMETER	ROCKWELL COLLINS
622-3890-103	5841-01-426-8489	TRANSCEIVER, RADIO ALTIMETER	ROCKWELL COLLINS
622-3890-104		TRANSCEIVER, RADIO ALTIMETER	ROCKWELL COLLINS
622-3890-108		TRANSCEIVER, RADIO ALTIMETER	ROCKWELL COLLINS
622-3890-114		TRANSCEIVER, RADIO ALTIMETER	ROCKWELL COLLINS
622-3915-001	5840-01-188-4694	INDICATOR, DME	ROCKWELL COLLINS
622-3915-002		INDICATOR, DME	ROCKWELL COLLINS
622-3916-001	6605-01-350-7225	INDICATOR, DME	ROCKWELL COLLINS
622-3916-002		INDICATOR, DME	ROCKWELL COLLINS
622-3917-001		INDICATOR, DME	ROCKWELL COLLINS
622-3917-002		INDICATOR, DME	ROCKWELL COLLINS
622-3918-001		INDICATOR, DME	ROCKWELL COLLINS
622-3918-002	5841-01-126-6621	INDICATOR, DME	ROCKWELL COLLINS
622-3919-001	5841-01-220-0659	INDICATOR, DME	ROCKWELL COLLINS
622-3919-002		INDICATOR, DME	ROCKWELL COLLINS
622-3920-001	5826-01-422-5469	INDICATOR, DME	ROCKWELL COLLINS
622-3920-002		INDICATOR, DME	ROCKWELL COLLINS
622-3921-001		INDICATOR, DME	ROCKWELL COLLINS
622-3921-002		INDICATOR, DME	ROCKWELL COLLINS
622-3986-001		CONTROL, RADIO SET	ROCKWELL COLLINS
622-3986-002		CONTROL, RADIO SET	ROCKWELL COLLINS
622-3986-003		CONTROL, RADIO SET	ROCKWELL COLLINS
622-3986-004		CONTROL, RADIO SET	ROCKWELL COLLINS
622-3986-005		CONTROL, RADIO SET	ROCKWELL COLLINS
622-3987-001		CONTROL, RADIO SET	ROCKWELL COLLINS
622-3987-002		CONTROL, RADIO SET	ROCKWELL COLLINS
622-3987-003		CONTROL, RADIO SET	ROCKWELL COLLINS
622-3987-004		CONTROL, RADIO SET	ROCKWELL COLLINS
622-4186-001	5826-01-066-2662	ADAPTER, TACAN, TRANSCEIVER	ROCKWELL COLLINS
622-4298-001	6605-01-101-1883	INDICATOR, HORIZONTAL SITUATION	ROCKWELL COLLINS
622-4393-001	6615-01-477-9209	CONTROL, AIR DATA	ROCKWELL COLLINS
622-4393-002	6615-01-092-0363	CONTROL, AIR DATA	ROCKWELL COLLINS
622-4393-019		CONTROL, AIR DATA	ROCKWELL COLLINS
622-4394-001		CONTROL, AIR DATA	ROCKWELL COLLINS
622-4394-002		CONTROL, AIR DATA	ROCKWELL COLLINS
622-4394-004		CONTROL, AIR DATA	ROCKWELL COLLINS
622-4394-005		CONTROL, AIR DATA	ROCKWELL COLLINS
622-4394-008		CONTROL, AIR DATA	ROCKWELL COLLINS
622-4394-009		CONTROL, AIR DATA	ROCKWELL COLLINS
622-4394-013	6615-01-188-4494	CONTROL, AIR DATA	ROCKWELL COLLINS
622-4394-019	6615-01-208-8751	CONTROL, AIR DATA	ROCKWELL COLLINS
622-4394-025		CONTROL, AIR DATA	ROCKWELL COLLINS
622-4394-042		CONTROL, AIR DATA	ROCKWELL COLLINS
622-4401-001		AIR DATA COMPUTER	ROCKWELL COLLINS
622-4401-003		AIR DATA COMPUTER	ROCKWELL COLLINS
622-4401-004		AIR DATA COMPUTER	ROCKWELL COLLINS
622-4401-005		AIR DATA COMPUTER	ROCKWELL COLLINS

622-4401-007		AIR DATA COMPUTER	ROCKWELL COLLINS
622-4401-010		AIR DATA COMPUTER	ROCKWELL COLLINS
622-4401-014		AIR DATA COMPUTER	ROCKWELL COLLINS
622-4401-015		AIR DATA COMPUTER	ROCKWELL COLLINS
622-4401-020		AIR DATA COMPUTER	ROCKWELL COLLINS
622-4401-026		AIR DATA COMPUTER	ROCKWELL COLLINS
622-4424-001	6615-01-134-8914	GYROSCOPE, VERTICAL	ROCKWELL COLLINS
622-4488-001		GYROSCOPE, VERTICAL	ROCKWELL COLLINS
622-4564-001		MOUNTING BASE, TACAN, TRANSCEIVER	ROCKWELL COLLINS
622-4565-001	6615-01-328-1062	GYROSCOPE, VERTICAL	ROCKWELL COLLINS
622-4565-002	5996-01-353-3975	GYROSCOPE, VERTICAL	ROCKWELL COLLINS
622-4754-001	5975-01-066-9462	MOUNTING BASE, TACAN, TRANSCEIVER	ROCKWELL COLLINS
622-4924-001	1680-01-537-2927	SELECTOR, HEADING, REMOTE	ROCKWELL COLLINS
622-4938-001	5826-01-296-3914	INDICATOR, RADIO MAGNETIC	ROCKWELL COLLINS
622-4938-001.E	5826-MD-031-3433	INDICATOR, RADIO MAGNETIC	ROCKWELL COLLINS
622-4956-103	5821-01-258-7579	TRANSCEIVER, RADIO	ROCKWELL COLLINS
622-4959-001	5826-01-132-7214	MOUNTING BASE, TACAN, TRANSCEIVER	ROCKWELL COLLINS
622-4960-001	5975-01-136-2750	MOUNTING BASE, TACAN, TRANSCEIVER	ROCKWELL COLLINS
622-5145-001	5826-01-411-6748	TRANSCEIVER, TACAN	ROCKWELL COLLINS
622-5150-001		MOUNT, AUTO-PILOT, SERVO	ROCKWELL COLLINS
622-5150-002		MOUNT, AUTO-PILOT, SERVO	ROCKWELL COLLINS
622-5151-001		MOUNT, AUTO-PILOT, SERVO	ROCKWELL COLLINS
622-5151-002		MOUNT, AUTO-PILOT, SERVO	ROCKWELL COLLINS
622-5152-001		MOUNT, AUTO-PILOT, SERVO	ROCKWELL COLLINS
622-5152-002		MOUNT, AUTO-PILOT, SERVO	ROCKWELL COLLINS
622-5229-001		MOUNT, AUTO-PILOT, SERVO	ROCKWELL COLLINS
622-5229-002		MOUNT, AUTO-PILOT, SERVO	ROCKWELL COLLINS
622-5377-001	5895-01-254-2749	TRANSCEIVER, RADIO	ROCKWELL COLLINS
622-5458-001	5975-01-120-7047	MOUNTING BASE, TACAN, TRANSCEIVER	ROCKWELL COLLINS
622-5486-001	5826-01-188-4493	SELECTOR, FLIGHT MODE	ROCKWELL COLLINS
622-5486-011	5826-01-395-9995	SELECTOR, FLIGHT MODE	ROCKWELL COLLINS
622-5508-001	5340-01-384-4056	TRAY, ELECTRONIC, MOUNTING	ROCKWELL COLLINS
622-5508-002	5975-01-424-3707	TRAY, ELECTRONIC, MOUNTING	ROCKWELL COLLINS
622-5508-003		TRAY, ELECTRONIC, MOUNTING	ROCKWELL COLLINS
622-5509-001	5820-01-308-2377	ADAPTER, RADIO, HIGH FREQUENCY	ROCKWELL COLLINS
622-5510-001	5820-01-210-2008	ADAPTER, RADIO, HIGH FREQUENCY	ROCKWELL COLLINS
622-5680-001	5975-01-149-4014	MOUNTING BASE, TACAN, TRANSCEIVER	ROCKWELL COLLINS
622-5680-002	5975-01-151-9681	MOUNTING BASE, TACAN, TRANSCEIVER	ROCKWELL COLLINS
622-5680-003		MOUNTING BASE, TACAN, TRANSCEIVER	ROCKWELL COLLINS
622-5812-001	6605-01-345-1258	VALVE, FLUX DETECTOR	ROCKWELL COLLINS
622-6020-011		DISPLAY, OPTOELECTRONIC, EADI/EHSI	ROCKWELL COLLINS
622-6020-012		DISPLAY, OPTOELECTRONIC, EADI/EHSI	ROCKWELL COLLINS
622-6020-021	5840-01-345-1650	DISPLAY, OPTOELECTRONIC, EADI/EHSI	ROCKWELL COLLINS
622-6020-022	5980-01-289-5788	DISPLAY, OPTOELECTRONIC, EADI/EHSI	ROCKWELL COLLINS
622-6020-121		DISPLAY, OPTOELECTRONIC, EADI/EHSI	ROCKWELL COLLINS
622-6020-122		DISPLAY, OPTOELECTRONIC, EADI/EHSI	ROCKWELL COLLINS
622-6129-001	5985-01-151-5848	COUPLER, ANTENNA	ROCKWELL COLLINS
622-6137-001	5821-01-300-2715	RECEIVER, RADIO NAVIGATION	ROCKWELL COLLINS
622-6137-201	5821-01-300-2715	RECEIVER, RADIO NAVIGATION	ROCKWELL COLLINS
622-6152-001	5895-01-369-5448	TRANSCEIVER, VHF, RADIO	ROCKWELL COLLINS
622-6152-002		TRANSCEIVER, VHF, RADIO	ROCKWELL COLLINS
622-6152-011		TRANSCEIVER, VHF, RADIO	ROCKWELL COLLINS
622-6152-012		TRANSCEIVER, VHF, RADIO	ROCKWELL COLLINS



622-6152-021		TRANSCEIVER, VHF, RADIO	ROCKWELL COLLINS
622-6152-022		TRANSCEIVER, VHF, RADIO	ROCKWELL COLLINS
622-6152-023		TRANSCEIVER, VHF, RADIO	ROCKWELL COLLINS
622-6152-031	5821-01-640-9029	TRANSCEIVER, VHF, RADIO	ROCKWELL COLLINS
622-6152-032		TRANSCEIVER, VHF, RADIO	ROCKWELL COLLINS
622-6152-033		TRANSCEIVER, VHF, RADIO	ROCKWELL COLLINS
622-6153-001	5820-01-328-1040	TRANSCEIVER, VHF, RADIO	ROCKWELL COLLINS
622-6153-002	5820-01-423-9200	TRANSCEIVER, VHF, RADIO	ROCKWELL COLLINS
622-6153-021	5821-01-581-2908	TRANSCEIVER, VHF, RADIO	ROCKWELL COLLINS
622-6153-022		TRANSCEIVER, VHF, RADIO	ROCKWELL COLLINS
622-6153-023		TRANSCEIVER, VHF, RADIO	ROCKWELL COLLINS
622-6208-303	6615-01-289-5715	SELECT PANEL, AUTO-PILOT MODE	ROCKWELL COLLINS
622-6208-403		SELECT PANEL, AUTO-PILOT MODE	ROCKWELL COLLINS
622-6209-001		SELECT PANEL, AUTO-PILOT MODE	ROCKWELL COLLINS
622-6209-002		SELECT PANEL, AUTO-PILOT MODE	ROCKWELL COLLINS
622-6209-003		SELECT PANEL, AUTO-PILOT MODE	ROCKWELL COLLINS
622-6209-004		SELECT PANEL, AUTO-PILOT MODE	ROCKWELL COLLINS
622-6209-005		SELECT PANEL, AUTO-PILOT MODE	ROCKWELL COLLINS
622-6209-006		SELECT PANEL, AUTO-PILOT MODE	ROCKWELL COLLINS
622-6209-007		SELECT PANEL, AUTO-PILOT MODE	ROCKWELL COLLINS
622-6209-008		SELECT PANEL, AUTO-PILOT MODE	ROCKWELL COLLINS
622-6209-010		SELECT PANEL, AUTO-PILOT MODE	ROCKWELL COLLINS
622-6209-011	5895-01-289-5757	SELECT PANEL, AUTO-PILOT MODE	ROCKWELL COLLINS
622-6209-019		SELECT PANEL, AUTO-PILOT MODE	ROCKWELL COLLINS
622-6209-020		SELECT PANEL, AUTO-PILOT MODE	ROCKWELL COLLINS
622-6209-103		SELECT PANEL, AUTO-PILOT MODE	ROCKWELL COLLINS
622-6209-104		SELECT PANEL, AUTO-PILOT MODE	ROCKWELL COLLINS
622-6209-105		SELECT PANEL, AUTO-PILOT MODE	ROCKWELL COLLINS
622-6209-106		SELECT PANEL, AUTO-PILOT MODE	ROCKWELL COLLINS
622-6209-109		SELECT PANEL, AUTO-PILOT MODE	ROCKWELL COLLINS
622-6209-110		SELECT PANEL, AUTO-PILOT MODE	ROCKWELL COLLINS
622-6209-111		SELECT PANEL, AUTO-PILOT MODE	ROCKWELL COLLINS
622-6209-112		SELECT PANEL, AUTO-PILOT MODE	ROCKWELL COLLINS
622-6209-114		SELECT PANEL, AUTO-PILOT MODE	ROCKWELL COLLINS
622-6209-118		SELECT PANEL, AUTO-PILOT MODE	ROCKWELL COLLINS
622-6209-120		SELECT PANEL, AUTO-PILOT MODE	ROCKWELL COLLINS
622-6209-203		SELECT PANEL, AUTO-PILOT MODE	ROCKWELL COLLINS
622-6209-204		SELECT PANEL, AUTO-PILOT MODE	ROCKWELL COLLINS
622-6209-205	1560-01-646-3939	SELECT PANEL, AUTO-PILOT MODE	ROCKWELL COLLINS
622-6209-206		SELECT PANEL, AUTO-PILOT MODE	ROCKWELL COLLINS
622-6209-303		SELECT PANEL, AUTO-PILOT MODE	ROCKWELL COLLINS
622-6209-304		SELECT PANEL, AUTO-PILOT MODE	ROCKWELL COLLINS
622-6209-305		SELECT PANEL, AUTO-PILOT MODE	ROCKWELL COLLINS
622-6209-306	6930-01-349-0661	SELECT PANEL, AUTO-PILOT MODE	ROCKWELL COLLINS
622-6209-405		SELECT PANEL, AUTO-PILOT MODE	ROCKWELL COLLINS
622-6209-817	6615-01-450-2720	SELECT PANEL, AUTO-PILOT MODE	ROCKWELL COLLINS
622-6263-001	5895-01-304-3814	INTERROGATOR SET	ROCKWELL COLLINS
622-6263-003	5895-01-304-3814	INTERROGATOR SET	ROCKWELL COLLINS
622-6321-001	5821-01-203-3480	TRANSCEIVER, RADIO AM/FM	ROCKWELL COLLINS
622-6342-011		DISPLAY, ELECTRONIC FLIGHT	ROCKWELL COLLINS
622-6342-012		DISPLAY, ELECTRONIC FLIGHT	ROCKWELL COLLINS
622-6342-013		DISPLAY, ELECTRONIC FLIGHT	ROCKWELL COLLINS
622-6342-021		DISPLAY, ELECTRONIC FLIGHT	ROCKWELL COLLINS

622-6342-022		DISPLAY, ELECTRONIC FLIGHT	ROCKWELL COLLINS
622-6342-023		DISPLAY, ELECTRONIC FLIGHT	ROCKWELL COLLINS
622-6342-024	6220-01-646-3936	DISPLAY, ELECTRONIC FLIGHT	ROCKWELL COLLINS
622-6342-121		DISPLAY, ELECTRONIC FLIGHT	ROCKWELL COLLINS
622-6342-122		DISPLAY, ELECTRONIC FLIGHT	ROCKWELL COLLINS
622-6389-001		TRANSCEIVER, VHF, RADIO	ROCKWELL COLLINS
622-6389-002		TRANSCEIVER, VHF, RADIO	ROCKWELL COLLINS
622-6389-011	5825-01-332-9175	TRANSCEIVER, VHF, RADIO	ROCKWELL COLLINS
622-6389-012		TRANSCEIVER, VHF, RADIO	ROCKWELL COLLINS
622-6390-001	5821-01-330-6120	TRANSCEIVER, VHF, RADIO	ROCKWELL COLLINS
622-6390-002		TRANSCEIVER, VHF, RADIO	ROCKWELL COLLINS
622-6424-001	5975-01-152-1266	MOUNTING BASE, TACAN, TRANSCEIVER	ROCKWELL COLLINS
622-6464-011		DISPLAY, ELECTRONIC FLIGHT	ROCKWELL COLLINS
622-6464-012		DISPLAY, ELECTRONIC FLIGHT	ROCKWELL COLLINS
622-6464-021		DISPLAY, ELECTRONIC FLIGHT	ROCKWELL COLLINS
622-6464-022		DISPLAY, ELECTRONIC FLIGHT	ROCKWELL COLLINS
622-6535-011		DISPLAY, ELECTRONIC FLIGHT	ROCKWELL COLLINS
622-6535-012		DISPLAY, ELECTRONIC FLIGHT	ROCKWELL COLLINS
622-6535-021		DISPLAY, ELECTRONIC FLIGHT	ROCKWELL COLLINS
622-6535-022	5980-01-333-7947	DISPLAY, ELECTRONIC FLIGHT	ROCKWELL COLLINS
622-6563-001		SELECT PANEL, AUTO-PILOT MODE	ROCKWELL COLLINS
622-6563-002		SELECT PANEL, AUTO-PILOT MODE	ROCKWELL COLLINS
622-6563-003		SELECT PANEL, AUTO-PILOT MODE	ROCKWELL COLLINS
622-6563-004		SELECT PANEL, AUTO-PILOT MODE	ROCKWELL COLLINS
622-6563-005		SELECT PANEL, AUTO-PILOT MODE	ROCKWELL COLLINS
622-6563-006		SELECT PANEL, AUTO-PILOT MODE	ROCKWELL COLLINS
622-6563-007		SELECT PANEL, AUTO-PILOT MODE	ROCKWELL COLLINS
622-6563-008		SELECT PANEL, AUTO-PILOT MODE	ROCKWELL COLLINS
622-6563-010		SELECT PANEL, AUTO-PILOT MODE	ROCKWELL COLLINS
622-6563-011		SELECT PANEL, AUTO-PILOT MODE	ROCKWELL COLLINS
622-6563-103		SELECT PANEL, AUTO-PILOT MODE	ROCKWELL COLLINS
622-6563-104		SELECT PANEL, AUTO-PILOT MODE	ROCKWELL COLLINS
622-6563-105		SELECT PANEL, AUTO-PILOT MODE	ROCKWELL COLLINS
622-6563-106		SELECT PANEL, AUTO-PILOT MODE	ROCKWELL COLLINS
622-6563-109		SELECT PANEL, AUTO-PILOT MODE	ROCKWELL COLLINS
622-6563-203		SELECT PANEL, AUTO-PILOT MODE	ROCKWELL COLLINS
622-6563-204		SELECT PANEL, AUTO-PILOT MODE	ROCKWELL COLLINS
622-6563-205		SELECT PANEL, AUTO-PILOT MODE	ROCKWELL COLLINS
622-6563-206		SELECT PANEL, AUTO-PILOT MODE	ROCKWELL COLLINS
622-6563-303		SELECT PANEL, AUTO-PILOT MODE	ROCKWELL COLLINS
622-6563-304		SELECT PANEL, AUTO-PILOT MODE	ROCKWELL COLLINS
622-6563-305		SELECT PANEL, AUTO-PILOT MODE	ROCKWELL COLLINS
622-6563-306		SELECT PANEL, AUTO-PILOT MODE	ROCKWELL COLLINS
622-6563-405		SELECT PANEL, AUTO-PILOT MODE	ROCKWELL COLLINS
622-6563-413		SELECT PANEL, AUTO-PILOT MODE	ROCKWELL COLLINS
622-6667-001	5996-01-306-4529	AMPLIFIER, ELECTRONIC CONTROL	ROCKWELL COLLINS
622-6900-007		SELECT PANEL, AUTO-PILOT MODE	ROCKWELL COLLINS
622-6900-027		SELECT PANEL, AUTO-PILOT MODE	ROCKWELL COLLINS
622-6900-407		SELECT PANEL, AUTO-PILOT MODE	ROCKWELL COLLINS
622-7233-001	5975-01-256-7216	MOUNTING BASE, TACAN, TRANSCEIVER	ROCKWELL COLLINS
622-7234-001	5975-01-242-9549	MOUNTING BASE, TACAN, TRANSCEIVER	ROCKWELL COLLINS
622-7236-001		DISPLAY, MULTIFUNCTION	ROCKWELL COLLINS
622-7236-002		DISPLAY, MULTIFUNCTION	ROCKWELL COLLINS

622-7236-011	5840-01-345-1652	DISPLAY, MULTIFUNCTION	ROCKWELL COLLINS
622-7236-012		DISPLAY, MULTIFUNCTION	ROCKWELL COLLINS
622-7236-201		DISPLAY, MULTIFUNCTION	ROCKWELL COLLINS
622-7236-202		DISPLAY, MULTIFUNCTION	ROCKWELL COLLINS
622-7337-001	5841-01-315-0645	TRANSCEIVER, RADAR	ROCKWELL COLLINS
622-7411-204		SELECT PANEL, AUTO-PILOT MODE	ROCKWELL COLLINS
622-7570-001	5975-01-242-9549	MOUNTING BASE, TACAN, TRANSCEIVER	ROCKWELL COLLINS
622-7667-001	5998-01-308-3066	ADAPTER, DME	ROCKWELL COLLINS
622-7876-011	7025-01-476-7706	DISPLAY, MULTIFUNCTION	ROCKWELL COLLINS
622-7876-012	5895-01-324-1442	DISPLAY, MULTIFUNCTION	ROCKWELL COLLINS
622-7876-211		DISPLAY, MULTIFUNCTION	ROCKWELL COLLINS
622-7876-212		DISPLAY, MULTIFUNCTION	ROCKWELL COLLINS
622-7978-321	6605-15-191-3981	COMPUTER, AP/FD	ROCKWELL COLLINS
622-8084-001	5985-01-281-1984	ANTENNA	RAYTHEON
622-8139-001	5975-01-249-5920	MOUNTING BASE, TACAN, TRANSCEIVER	ROCKWELL COLLINS
622-8140-001	5826-01-251-1148	CONTROL PANEL, TACAN, TRANSCEIVER	ROCKWELL COLLINS
622-8329-013		AIR DATA COMPUTER	ROCKWELL COLLINS
622-8329-646	7021-MD-017-8134	AIR DATA COMPUTER	ROCKWELL COLLINS
622-8329-647		AIR DATA COMPUTER	ROCKWELL COLLINS
622-8677-001		DISPLAY, OPTOELECTRONIC, EADI/EHSI	ROCKWELL COLLINS
622-9009-001	5821-01-333-9238	PROCESSOR UNIT, DISPLAY	ROCKWELL COLLINS
622-9010-001	5821-01-333-9239	PROCESSOR UNIT, MULTI	ROCKWELL COLLINS
622-9076-001		CONTROL PANEL, TACAN, TRANSCEIVER	ROCKWELL COLLINS
622-9301-001		TRANSCEIVER, WEATHER, RADAR	ROCKWELL COLLINS
622-9849-001		DISPLAY, MULTIFUNCTION	ROCKWELL COLLINS
622-9849-002		DISPLAY, MULTIFUNCTION	ROCKWELL COLLINS
622-9849-011		DISPLAY, MULTIFUNCTION	ROCKWELL COLLINS
622-9849-012		DISPLAY, MULTIFUNCTION	ROCKWELL COLLINS
622-9849-201		DISPLAY, MULTIFUNCTION	ROCKWELL COLLINS
622-9849-202		DISPLAY, MULTIFUNCTION	ROCKWELL COLLINS
624334-1	6685-00-887-6815	INDICATOR, FUEL CROSS FEED PRESSURE	LOCKHEED MARTIN
624394-5	6680-00-319-1723	TRANSMITTER, OIL QUANTITY	LOCKHEED MARTIN
624407-1	6680-00-815-7282	INDICATOR, FUEL QUANTITY	LOCKHEED MARTIN
624407-3	6680-00-815-7285	INDICATOR, FUEL QUANTITY	LOCKHEED MARTIN
624408-1	6680-00-815-7284	INDICATOR, TOTALIZER, FUEL QUANTITY	LOCKHEED MARTIN
624437-1	6620-00-020-3211	TRANSMITTER, FUEL FLOW	LOCKHEED MARTIN
624438-1	6620-00-021-2239	INDICATOR, FUEL FLOW	LOCKHEED MARTIN
624439-101	6130-01-227-4291	POWER SUPPLY, FUEL FLOW	LOCKHEED MARTIN
624439-101	6130-00-906-9917	POWER SUPPLY	LOCKHEED MARTIN
624439-103	6130-01-227-4291	POWER SUPPLY, FUEL FLOW	LOCKHEED MARTIN
626125-5	6685-00-557-0370	INDICATOR, TEMPERATURE, ELECTRICAL RESISTANCE	LOCKHEED MARTIN
626149-3	6685-00-887-6812	GAGE, DIFFERENTIAL, DIAL INDICATING	LOCKHEED MARTIN
626151-1	6685-00-887-1971	TRANSMITTER, PRESSURE	LOCKHEED MARTIN
626158-1	6685-00-887-6813	INDICATOR, BLEED MANIFOLD PRESSURE	LOCKHEED MARTIN
627076-2-1	1660-01-057-5182	CONTROL BOX, AIR TEMPERATURE	LOCKHEED MARTIN
627T-1	5820-01-312-2024	TRANSCEIVER, RADIO	ROCKWELL COLLINS
628T-1	5820-01-312-2024	TRANSCEIVER, RADIO	ROCKWELL COLLINS
628T-2	5820-01-183-3036	TRANSCEIVER, RADIO	ROCKWELL COLLINS
628T-2A	5895-01-254-2749	TRANSCEIVER, RADIO	ROCKWELL COLLINS
629292-1	1660-00-887-4277	CONTROL BOX, AIR TEMPERATURE	LOCKHEED MARTIN
629318-5	6610-00-799-8315	INDICATOR, HORIZONTAL SITUATION	LOCKHEED MARTIN
630-37070-235	6610-01-101-1905	COMPUTER, AIR SPEED	KOLLSMAN
631215-501	5965-01-127-3890	HEADSET, MICROPHONE	LOCKHEED MARTIN

632184-3	5930-00-961-8506	SWITCH, PRESSURE	LOCKHEED MARTIN
632238-7	2995-00-887-1963	MOUNT, DYNAFOCAL	LOCKHEED MARTIN
634055-9	2915-00-887-1904	VALVE, FUEL SYSTEM	LOCKHEED MARTIN
634065-3	5930-00-961-8507	SWITCH, PRESSURE	LOCKHEED MARTIN
634080-11	2935-00-887-4267	COOLER, ENGINE OIL	LOCKHEED MARTIN
634174-1	2935-00-887-1969	COOLER, LUBRICATING OIL	LOCKHEED MARTIN
64042-401-1	6610-14-395-6835	INDICATOR, AIR SPEED	JAEGER (THALES AVIONICS)
64111-635-1	6610-14-349-3965	ALTIMETER, ENCODER	JAEGER (THALES AVIONICS)
64111-635-2	6610-14-482-5668	ALTIMETER, ENCODER	JAEGER (THALES AVIONICS)
64111-835-1	6610-14-043-0158	ALTIMETER, ENCODER	JAEGER (THALES AVIONICS)
642C1	5835-01-103-7517	RECORDER, SOUND	ROCKWELL COLLINS
64400-004-1	6610-14-395-6836	ACCELEROMETER, MECHANICAL	JAEGER (THALES AVIONICS)
644647-51	1660-00-887-6729	VALVE, CABIN AIR PRESSURE, OUTFLOW	LOCKHEED MARTIN
644648-103	1660-01-067-0390	REGULATOR, AIR PRESSURE, AIRCRAFT CABIN	LOCKHEED MARTIN
644648-105	1660-01-159-9078	REGULATOR, AIR PRESSURE, AIRCRAFT CABIN	LOCKHEED MARTIN
644648-107	1660-01-159-9078	VALVE, AIR PRESSURE, CONTROLLER	LOCKHEED MARTIN
644648-53	1660-00-887-6728	REGULATOR, AIR PRESSURE, AIRCRAFT CABIN	LOCKHEED MARTIN
644669-101	4810-00-884-7571	VALVE, BUTTERFLY	LOCKHEED MARTIN
644669-51	4810-00-887-1914	VALVE, BUTTERFLY	LOCKHEED MARTIN
644673-101	4810-00-914-9508	VALVE, CROSS	LOCKHEED MARTIN
644673-105	4810-00-085-1104	VALVE, SHUTOFF, BLEED AIR	LOCKHEED MARTIN
644673-51	4810-00-566-0332	VALVE, CROSS, SOLENOID	LOCKHEED MARTIN
644676-3	1660-00-818-7701	VALVE, BUTTERFLY	GE AVIATION
644810-51	2995-00-822-3053	VALVE, HOT AIR	LOCKHEED MARTIN
644850-103	4810-01-142-8229	VALVE, BUTTERFLY	LOCKHEED MARTIN
644850-107	4810-01-142-8229	VALVE, BUTTERFLY	LOCKHEED MARTIN
644850-7	4810-00-018-3825	VALVE, BUTTERFLY	LOCKHEED MARTIN
644853-101	4810-00-943-5223	VALVE, BUTTERFLY	LOCKHEED MARTIN
644853-103	4810-01-085-7038	VALVE, BUTTERFLY	LOCKHEED MARTIN
644858-101	4810-01-082-7208	VALVE, BUTTERFLY	LOCKHEED MARTIN
644858-103	4810-01-082-7207	VALVE, BUTTERFLY	LOCKHEED MARTIN
644858-107	4810-01-152-5662	VALVE, BUTTERFLY	LOCKHEED MARTIN
644858-7	4810-00-018-3825	VALVE, BUTTERFLY	LOCKHEED MARTIN
644859-1	4140-00-887-6787	FAN, VANE, AXIAL	LOCKHEED MARTIN
644859-101	4140-00-241-0065	FAN, VANE, AXIAL	LOCKHEED MARTIN
647091-101	4110-00-015-7627	REFRIGERATOR, MECHANICAL	LOCKHEED MARTIN
64811-399-1	6685-14-380-2756	INDICATOR, TEMPERATURE	JAEGER (THALES AVIONICS)
65-3569	5985-00-217-0457	ANTENNA	BOEING
658059-9	1630-00-887-4268	VALVE, BRAKE ACTUATOR	LOCKHEED MARTIN
658060-57	1650-00-858-0501	ACCUMULATOR, PNEUMATIC	LOCKHEED MARTIN
65A27D1	5841-00-900-8081	WARNING SET, RADIO ALTIMETER (RAWS)	PRECISION AEROSPACE
65B45233	5826-00-904-9822	INDICATOR, RADIO MAGNETIC	HONEYWELL INTERNATIONAL
66039-01	4320-01-171-0452	PUMP, AXIAL PISTONS	PARKER HANNIFIN
66039-2	4320-00-616-3812	PUMP, AXIAL PISTONS	PARKER HANNIFIN
6610PLO798923	6610-00-808-7038	INDICATOR, AILERON TRIM TAB, POSITION	JEDNOLITY INDEKS
6610PLO800405	6610-00-808-7037	INDICATOR, AILERON TRIM TAB, POSITION	JEDNOLITY INDEKS
668133-1	4820-00-855-8411	VALVE, HYDRAULIC PRESSURE SHUTOFF	LOCKHEED MARTIN
668223-1	1650-00-767-2241	ACCUMULATOR ASSY, HYDRAULIC	LOCKHEED MARTIN
668223-101	1650-00-767-2241	ACCUMULATOR ASSY, HYDRAULIC	LOCKHEED MARTIN
668281-11	1630-00-887-1916	VALVE, BRAKE	LOCKHEED MARTIN
668401-1	4810-00-887-4337	VALVE, SOLENOID, SHUTOFF	LOCKHEED MARTIN
668402-5	1650-00-566-0335	VALVE, BOMB BAY, HYDRAULIC, CONTROL	LOCKHEED MARTIN
669345-13	1680-00-887-1911	ACTUATOR, ELECTRO-MECHANICAL, LINEAR	LOCKHEED MARTIN

669353-101	1680-00-866-7187	GEARBOX, FLAP DRIVE	LOCKHEED MARTIN
669353-103	1680-00-921-8698	GEARBOX, FLAP DRIVE	LOCKHEED MARTIN
669353-5	1680-00-887-1908	GEARBOX, FLAP DRIVE	LOCKHEED MARTIN
66WBD300-4	4320-00-213-5986	PUMP, AXIAL PISTONS	EATON AEROSPACE
66WBD300B1	4320-00-213-5986	PUMP, AXIAL PISTONS	EATON AEROSPACE
670596-105	1660-01-097-8733	INDICATOR, AIRCRAFT AIR TEMPERATURE, SELECTOR	LOCKHEED MARTIN
670597-105	1660-00-918-6727	CONTROL UNIT, AIRCRAFT AIR TEMPERATURE	LOCKHEED MARTIN
670597-107	1660-01-097-8747	CONTROL UNIT, AIRCRAFT AIR TEMPERATURE	LOCKHEED MARTIN
670734-105	1660-00-909-4309	HEAT EXCHANGER, AIR TO AIR	LOCKHEED MARTIN
670734-106	1660-00-909-4310	HEAT EXCHANGER, AIR TO AIR	LOCKHEED MARTIN
670734-113	4140-00-924-8116	FAN, TUBE, AXIAL	LOCKHEED MARTIN
670750-107	1680-00-877-6385	ACTUATOR, ELECTRO-MECHANICAL, LINEAR	LOCKHEED MARTIN
670750-109	1680-01-181-3218	ACTUATOR, ELECTRO-MECHANICAL, LINEAR	LOCKHEED MARTIN
670752-107	1680-01-181-1374	ACTUATOR, ELECTRO-MECHANICAL, LINEAR	LOCKHEED MARTIN
670764-103	6680-00-923-8466	GENERATOR, TACHOMETER	LOCKHEED MARTIN
670835-101	1630-00-927-1773	BRAKE, MULTIPLE DISK	LOCKHEED MARTIN
670836-103	1630-01-115-1715	WHEEL, AIRCRAFT, MLG	LOCKHEED MARTIN
670846-101	2915-00-983-9306	VALVE, FUEL SYSTEM	LOCKHEED MARTIN
671352-103	5996-00-358-1724	AMPLIFIER, ELECTRONIC CONTROL	LOCKHEED MARTIN
671361-101	1630-00-075-1976	WHEEL, AIRCRAFT, NLG	LOCKHEED MARTIN
671484-105	1680-01-070-1508	ACTUATOR, ELECTRO-MECHANICAL, ROTARY	LOCKHEED MARTIN
671CPU19-015	6610-00-663-7740	ALTIMETER, PRESSURE	LOCKHEED MARTIN
671CPU19-015D	6610-00-526-6067	ALTIMETER, PRESSURE	KOLLSMAN
671CPU19-015DF	6610-00-179-4312	ALTIMETER, PRESSURE	KOLLSMAN
671CPU19-035	6610-00-514-4176	ALTIMETER, PRESSURE	KOLLSMAN
671CPU19-035D	6610-00-526-6054	ALTIMETER, PRESSURE	KOLLSMAN
671CPU19-035DF	6610-00-179-4309	ALTIMETER, PRESSURE	KOLLSMAN
671CPX4-037	6610-00-514-4183	ALTIMETER, PRESSURE	KOLLSMAN
671CPX4-037D	6610-00-526-6083	ALTIMETER, PRESSURE	KOLLSMAN
671CPX4-037DF	6610-00-179-5241	ALTIMETER, PRESSURE	KOLLSMAN
672434-101	6610-00-459-4578	ALTIMETER, PRESSURE	KOLLSMAN
67-2734-001	1660-00-065-2899	VALVE, MODULATING, HOT AIR	GRIMES AEROSPACE
67-2790-001	4810-00-725-7747	VALVE, MODULATING, HOT AIR	GRIMES AEROSPACE
67-2790-002	4810-00-003-4369	VALVE, MODULATING, HOT AIR	GRIMES AEROSPACE
672986-103	1660-00-351-3738	CONTROL BOX, AIR TEMPERATURE	LOCKHEED MARTIN
673483-101	6220-01-020-2550	LIGHT, NAVIGATIONAL, AIRCRAFT	LOCKHEED MARTIN
673483-103	6130-01-017-5448	POWER SUPPLY	LOCKHEED MARTIN
673578-105	5826-01-136-7886	RECEIVER, RADIO NAVIGATION	LOCKHEED MARTIN
673819-103	5821-01-140-7767	TRANSCEIVER, VHF, RADIO	LOCKHEED MARTIN
674167-101	4820-01-097-8734	VALVE, FUEL, VENT	LOCKHEED MARTIN
6799255-1	1610-00-960-9885	SYNCHROPHASER, PROPELLER	ROLLS-ROYCE
681200-1	5895-00-168-3590	AMPLIFIER, POWER SUPPLY	LOCKHEED MARTIN
6821493S	2995-MD-003-4605	VALVE, SPEED SENSITIVE	ROLLS-ROYCE
683-3133	5965-00-755-4643	MICROPHONE, DYNAMIC	BOSCH SECURITY SYSTEMS
684-4133-020	5950-14-407-5589	TRANSFORMER, POWER	THALES AVIONICS
687122-1	5985-01-097-8681	ANTENNA, VHF	LOCKHEED MARTIN
693-0933	5965-00-755-4643	MICROPHONE, DYNAMIC	BOSCH SECURITY SYSTEMS
695224-1	5945-00-628-6484	RELAY, HYBRID	LOCKHEED MARTIN
695316-1	4810-00-522-4595	VALVE, ENVIRONMENTAL AIR ,FLOW CONTROL	LOCKHEED MARTIN
695335-5	6220-00-299-4621	LIGHT, LANDING, AIRCRAFT	LOCKHEED MARTIN
695335-7	6220-01-316-4577	LIGHT, LANDING, AIRCRAFT	LOCKHEED MARTIN
695463-3	1660-00-343-4692	REGULATOR, AIR PRESSURE, CABIN	HONEYWELL INTERNATIONAL
695464-13	1660-00-062-0301	CONTROLLER, AIR PRESSURE, AIRCRAFT CABIN	LOCKHEED MARTIN

695539-4	6685-00-670-0895	THERMOSTAT, FLOW CONTROL	LOCKHEED MARTIN
695539-5	6685-01-119-6546	THERMOSTAT, FLOW CONTROL	LOCKHEED MARTIN
695579-69	1620-00-617-9123	GEARBOX, LANDING	LOCKHEED MARTIN
695592-1	4320-00-631-4859	PUMP, ROTARY	LOCKHEED MARTIN
695592-3	4320-00-659-9775	PUMP, ROTARY	LOCKHEED MARTIN
695607-5	1680-00-671-2101	SEAT, AIRCRAFT, TROOPS	LOCKHEED MARTIN
695607-7	1680-00-671-3837	SEAT, AIRCRAFT, TROOPS	LOCKHEED MARTIN
695676-11	1680-01-004-2086	ACTUATOR, ELECTRO-MECHANICAL, ROTARY	LOCKHEED MARTIN
695676-13	1680-01-472-9783	ACTUATOR, ELECTRO-MECHANICAL, ROTARY	LOCKHEED MARTIN
695676-15	1680-01-217-5837	ACTUATOR, ELECTRO-MECHANICAL, LINEAR	LOCKHEED MARTIN
695698-1	2915-00-671-7892	VALVE, FLOAT, FUEL TANK	LOCKHEED MARTIN
695698-3	2915-00-574-3227	VALVE, FLOAT, FUEL TANK	LOCKHEED MARTIN
695699-3	2915-00-581-0477	VALVE, FLOAT, FUEL TANK	PARKER HANNIFIN
695700-3	1680-01-013-9501	ACTUATOR, ELEVATOR TRIM TAB, ROTARY	LOCKHEED MARTIN
695715-1	5945-01-250-9675	RELAY, ELECTROMAGNETIC	LOCKHEED MARTIN
695715-7	5945-01-250-9675	RELAY, ELECTROMAGNETIC	LOCKHEED MARTIN
695746-1	2915-00-632-7932	VALVE, FUEL SYSTEM	LOCKHEED MARTIN
695748-13	4810-00-730-2852	VALVE, SOLENOID CONTROLLED, SHUT-OFF	LOCKHEED MARTIN
695748-15	4810-00-730-3551	VALVE, SOLENOID CONTROLLED, SHUT-OFF	LOCKHEED MARTIN
695752-1	2915-00-739-3047	VALVE, FLOAT, FUEL TANK	LOCKHEED MARTIN
695752-3	2915-00-074-1724	VALVE, FLOAT, FUEL TANK	LOCKHEED MARTIN
695755-1	1680-00-733-3491	WINCH, AIRCRAFT MOUNTED	LOCKHEED MARTIN
695757-31	6680-01-063-0597	INDICATOR, FUEL QUANTITY	HONEYWELL INTERNATIONAL
695762-3	4810-00-612-2696	VALVE, LINEAR, DIRECTIONAL CONTROL	LOCKHEED MARTIN
695768-1	2915-00-971-9130	PUMP, SUBMERGED, AIRCRAFT	LOCKHEED MARTIN
695775-1	1680-00-088-6102	ACTUATOR, ELECTRO-MECHANICAL, LINEAR	LOCKHEED MARTIN
695775-2	1680-00-981-7652	ACTUATOR, ELECTRO-MECHANICAL, LINEAR	LOCKHEED MARTIN
695797-1	6680-00-580-1247	INDICATOR, FUEL QUANTITY	LOCKHEED MARTIN
695797-11	6680-00-585-5444	INDICATOR, FUEL QUANTITY	LOCKHEED MARTIN
695797-13	6680-00-585-8600	INDICATOR, FUEL QUANTITY	LOCKHEED MARTIN
695797-17	6680-00-866-5116	INDICATOR, FUEL QUANTITY	LOCKHEED MARTIN
695797-19	6680-00-849-7809	INDICATOR, FUEL QUANTITY	LOCKHEED MARTIN
695797-23	6680-01-056-1779	INDICATOR, FUEL QUANTITY	LOCKHEED MARTIN
695797-25	6680-01-060-5228	INDICATOR, FUEL QUANTITY	LOCKHEED MARTIN
695797-27	6680-01-058-5859	INDICATOR, FUEL QUANTITY	LOCKHEED MARTIN
695797-3	6680-00-580-1246	INDICATOR, FUEL QUANTITY	LOCKHEED MARTIN
695797-33	6680-01-058-5861	INDICATOR, FUEL QUANTITY	HONEYWELL INTERNATIONAL
695797-35	6680-01-058-5862	INDICATOR, FUEL QUANTITY	HONEYWELL INTERNATIONAL
695797-37	6680-01-058-5860	INDICATOR, FUEL QUANTITY	LOCKHEED MARTIN
695797-5	6680-00-580-1248	INDICATOR, FUEL QUANTITY	LOCKHEED MARTIN
695797-9	6680-00-585-5859	INDICATOR, FUEL QUANTITY	LOCKHEED MARTIN
695799-185	6680-01-059-3387	COMPENSATOR, FUEL QUANTITY	LOCKHEED MARTIN
695799-225	6680-01-064-3231	COMPENSATOR, FUEL QUANTITY	LOCKHEED MARTIN
695799-235	6680-01-067-4552	COMPENSATOR, LIQUID QUANTITY GAGE	LOCKHEED MARTIN
695800-3	6680-01-419-1995	TRANSMITTER, OIL QUANTITY	LOCKHEED MARTIN
695800-5	6680-01-419-1995	TRANSMITTER, OIL QUANTITY	LOCKHEED MARTIN
695805-1	4810-00-987-3948	VALVE, SOLENOID, SHUT-OFF	LOCKHEED MARTIN
695807-1	1680-00-073-8204	ACTUATOR, OIL COOLER DOOR, ELECTRO-MECHANICAL	LOCKHEED MARTIN
695807-3	1680-01-254-6893	ACTUATOR, OIL COOLER DOOR, ELECTRO-MECHANICAL	LOCKHEED MARTIN
695807-5	1680-01-378-1631	ACTUATOR, OIL COOLER DOOR, ELECTRO-MECHANICAL	LOCKHEED MARTIN
695807-7	1680-01-497-7142	ACTUATOR, ELECTRO-MECHANICAL, LINEAR, OIL COOLER DOOR	LOCKHEED MARTIN
695808-1	4810-01-206-6309	VALVE, SOLENOID, SHUT-OFF	LOCKHEED MARTIN
695813-1	4820-00-006-5087	VALVE, ENGINE, BLEED AIR, CHECK	LOCKHEED MARTIN

695838-3	1680-00-426-5616	ACTUATOR, APU DOOR, ELECTRO-MECHANICAL	LOCKHEED MARTIN
695855-5	7310-00-905-6212	OVEN, WARMING, ELECTRIC	LOCKHEED MARTIN
695859-3	4810-00-003-4369	VALVE, MODULATING, HOT AIR	LOCKHEED MARTIN
695871-3	4820-00-810-2061	VALVE, FLUID, REGULATING	LOCKHEED MARTIN
695873-1	6350-01-280-1671	DETECTOR, HEAT	LOCKHEED MARTIN
695873-9	6350-01-280-1671	DETECTOR, HEAT	LOCKHEED MARTIN
695890-1	6105-00-630-5828	MOTOR, WINDSHIELD, DIRECT CURRENT	LOCKHEED MARTIN
695906-1	5930-00-615-7340	SWITCH, PRESSURE	LOCKHEED MARTIN
695923-1	1680-00-782-5861	SEAT, AIRCRAFT, TROOPS	LOCKHEED MARTIN
695923-3	1680-00-913-4840	SEAT, AIRCRAFT, TROOPS	LOCKHEED MARTIN
695923-5	1680-00-913-4841	SEAT, AIRCRAFT, TROOPS	LOCKHEED MARTIN
695960-1	1680-00-705-9996	ACTUATOR, ELECTRO-MECHANICAL, LINEAR	LOCKHEED MARTIN
695960-3	1680-00-705-9997	ACTUATOR, ELECTRO-MECHANICAL, LINEAR	LOCKHEED MARTIN
695960-5	2915-01-211-5951	ACTUATOR, ELECTRO-MECHANICAL, LINEAR	LOCKHEED MARTIN
695960-7	1680-01-131-0902	ACTUATOR, ELECTRO-MECHANICAL, LINEAR	LOCKHEED MARTIN
6970-1	6605-00-551-8187	COMPASS, MAGNETIC, MOUNTED	LOCKHEED MARTIN
697226-1	2935-00-966-3321	COOLER, ENGINE, OIL	LOCKHEED MARTIN
697232-1	1650-00-204-1703	MOTOR, HYDRAULIC	LOCKHEED MARTIN
697235-1	1680-01-221-8261	ACTUATOR, ELECTRO-MECHANICAL, LINEAR	LOCKHEED MARTIN
697273-1	5945-00-075-4925	SWITCH, INSTRUMENT	LOCKHEED MARTIN
697395-1	1630-00-998-7897	VALVE, BRAKE CONTROL	LOCKHEED MARTIN
697397-1	1630-00-998-7896	VALVE, SKID CONTROL	LOCKHEED MARTIN
697397-3	1630-00-908-9999	VALVE, DUAL CONTROL	LOCKHEED MARTIN
697398-1	1630-00-085-2625	CONTROL UNIT, ANTI-SKID	LOCKHEED MARTIN
697398-3	1630-00-133-8183	CONTROL UNIT, ANTI-SKID	LOCKHEED MARTIN
697489-1	1630-00-914-1329	WHEEL, NOSE LANDING GEAR	LOCKHEED MARTIN
697639-11		CONTROL BOX, TEMPERATURE	LOCKHEED MARTIN
697639-13	1660-00-595-7773	SENSOR, CABIN TEMPERATURE	LOCKHEED MARTIN
697639-17	1660-00-583-7106	SENSOR, DUCT, OVERHEAT	LOCKHEED MARTIN
697639-21	1660-01-021-4981	CONTROL BOX, TEMPERATURE	LOCKHEED MARTIN
697639-35	1660-01-003-6297	CONTROL BOX, TEMPERATURE	LOCKHEED MARTIN
697639-37	1660-01-014-4509	CONTROL BOX, TEMPERATURE	LOCKHEED MARTIN
697639-39	1660-01-021-4981	CONTROL BOX, AIRCRAFT AIR TEMPERATURE	LOCKHEED MARTIN
697640-1	1680-01-008-7442	ACTUATOR, ELECTRO-MECHANICAL, LINEAR	WHIPPANY ACTUATION SYSTEMS
697710-1	6680-01-170-8405	TRANSMITTER, LIQUID QUANTITY	LOCKHEED MARTIN
697749-11	6680-01-291-4271	INDICATOR, TOTALIZER, FUEL QUANTITY	LOCKHEED MARTIN
697749-13	6680-01-290-7552	INDICATOR, REPEATER, FUEL QUANTITY	LOCKHEED MARTIN
697749-15	6680-01-350-8049	INDICATOR, FUEL QUANTITY	LOCKHEED MARTIN
697749-17	6680-01-350-8048	INDICATOR, FUEL QUANTITY	LOCKHEED MARTIN
697749-19	6680-01-350-9120	INDICATOR, FUEL QUANTITY	LOCKHEED MARTIN
697749-3	6680-01-220-4091	INDICATOR, FUEL QUANTITY	LOCKHEED MARTIN
697749-5	6680-01-224-7271	INDICATOR, FUEL QUANTITY	LOCKHEED MARTIN
697749-9	6680-01-290-5920	INDICATOR, PRIMARY, FUEL QUANTITY	LOCKHEED MARTIN
697750-1	4810-01-237-5974	VALVE, OIL COOLER, AUGMENTATION	LOCKHEED MARTIN
697750-3	4810-01-237-5974	VALVE, OIL COOLER, AUGMENTATION	LOCKHEED MARTIN
697752-1	4810-01-218-2643	VALVE, TEMPERATURE CONTROL, BUTTERFLY	LOCKHEED MARTIN
697753-1	4810-01-219-3417	VALVE, TEMPERATURE CONTROL, BUTTERFLY	LOCKHEED MARTIN
697883-1	6620-01-394-4018	INDICATOR, FUEL QUANTITY	LOCKHEED MARTIN
697883-3	6680-01-394-2555	INDICATOR, FUEL QUANTITY	LOCKHEED MARTIN
698611-1	6620-00-111-0401	INDICATOR, TORQUEMETER	LOCKHEED MARTIN
7000B		GYROSCOPE, DISPLACEMENT	GE AVIATION SYSTEMS
7000E		GYROSCOPE, DISPLACEMENT	GE AVIATION SYSTEMS
7021-200	1650-14-377-8587	ACTUATOR, PNEUMATIC, NOSE CONE	LE BOZEC

703BD-OA-2	6610-MD-016-3590	INDICATOR, HORIZONTAL SITUATION	SFENA (THALES AVIONICS)
7041-1	1680-00-088-6102	ACTUATOR, ELECTRO-MECHANICAL, LINEAR	CEF INDUSTRIES
7041-2	1680-00-981-7652	ACTUATOR, ELECTRO-MECHANICAL, LINEAR	CEF INDUSTRIES
704A45-330-007	5985-01-112-8057	ANTENNA, ADF	CEF INDUSTRIES
705-12-333	6610-MD-016-3783	INDICATOR, HORIZONTAL SITUATION	OGMA
705565-2	6130-01-051-7518	CHARGER, BATTERY	GE AVIATION SYSTEMS
707073-801	5821-01-136-9512	TRANSCEIVER, UHF, RADIO	RAYTHEON
707877-1	5895-00-228-3133	CONTROL BOX, RECEIVER	RAYTHEON
707878-1	5826-00-521-0571	COUPLING, ANTENNA	RAYTHEON
707880-1	5826-00-390-5744	INDICATOR, BEARING	RAYTHEON
707881-1	5985-00-149-1451	ANTENNA, LOOP	RAYTHEON
708019-1	5821-00-090-2994	TRANSCEIVER, RADIO COMPASS	RAYTHEON
7088-1A	1680-00-789-9345	GEAR BOX ASSYFLAP DRIVEMOTOR DRIVEN	CEF INDUSTRIES
7-115945	2915-00-901-7206	VALVE, FLOAT, FUEL TANK	CEF INDUSTRIES
7125-9415	6615-01-178-0583	GYROSCOPE, RATE OF TURN	MID-CONTINENT INSTRUMENT
714E-1		CONTROL, RADIO SET	ROCKWELL COLLINS
714E-2		CONTROL, RADIO SET	ROCKWELL COLLINS
714E-2A		CONTROL, RADIO SET	ROCKWELL COLLINS
714E-2B		CONTROL, RADIO SET	ROCKWELL COLLINS
714E-2C		CONTROL, RADIO SET	ROCKWELL COLLINS
714E-3		CONTROL, RADIO SET	ROCKWELL COLLINS
714E-3B		CONTROL, RADIO SET	ROCKWELL COLLINS
714E-3C		CONTROL, RADIO SET	ROCKWELL COLLINS
714E-3D		CONTROL, RADIO SET	ROCKWELL COLLINS
714E-3E		CONTROL, RADIO SET	ROCKWELL COLLINS
714E-3F		CONTROL, RADIO SET	ROCKWELL COLLINS
714E-3G		CONTROL, RADIO SET	ROCKWELL COLLINS
714E-3H		CONTROL, RADIO SET	ROCKWELL COLLINS
715.158-915	5895-12-322-8156	TRANSCEIVER, IFF	BECKER AVIONICS
724CU-4-012	6610-00-514-5612	INDICATOR, AIR SPEED	KOLLSMAN
724CU-5-011	6610-00-531-4299	INDICATOR, AIR SPEED	KOLLSMAN
724CU-5-03		INDICATOR, AIR SPEED	KOLLSMAN
724CU-5-03M	6610-00-526-4798	INDICATOR, AIR SPEED	KOLLSMAN
724CU-8-011	6610-00-531-4296	INDICATOR, AIR SPEED	KOLLSMAN
724DU-4-012	6610-00-514-5611	INDICATOR, AIR SPEED	KOLLSMAN
724DX-4-012	6610-00-526-7944	INDICATOR, AIR SPEED	KOLLSMAN
731300-3	2915-00-357-2496	VALVE, FLOAT, FUEL TANK	TRANSDIGM
731700-3		VALVE, FLOAT, FUEL TANK	TRANSDIGM
73483-103	6130-01-017-5448	POWER SUPPLY	LOCKHEED MARTIN
7500-15A5A	6620-00-553-8988	TRANSMITTER, PRESSURE	HONEYWELL INTERNATIONAL
7-511C10035-1	6615-00-137-6038	GYROSCOPE, RATE OF TURN	BOEING
7514060-902	5985-01-461-0972	ANTENNA, TCAS DIRECTIONAL ANTENNA	ACSS
7514081-901		ANTENNA, TCAS DIRECTIONAL ANTENNA	ACSS
7514081-902	5985-01-521-0194	ANTENNA, TCAS DIRECTIONAL ANTENNA	ACSS
7514081-903	5985-01-628-4706	ANTENNA, TCAS DIRECTIONAL ANTENNA	ACSS
7514081-904	5985-01-466-0191	ANTENNA, TCAS DIRECTIONAL ANTENNA	ACSS
7514081-910	5985-01-482-4812	ANTENNA, TCAS DIRECTIONAL ANTENNA	ACSS
7514081-912	5985-01-575-9739	ANTENNA, TCAS DIRECTIONAL ANTENNA	ACSS
7514081-913	5985-01-588-4454	ANTENNA, TCAS DIRECTIONAL ANTENNA	ACSS
7514081-914	5985-01-521-8687	ANTENNA, TCAS DIRECTIONAL ANTENNA	ACSS
7514081-917	5985-01-476-4910	ANTENNA, TCAS DIRECTIONAL ANTENNA	ACSS
7519350-70051	5826-01-527-0947	TRANSPONDER SET	HONEYWELL INTERNATIONAL
758L1-01	6605-00-239-8205	COMPASS, MAGNETIC, MOUNTED	KOLLSMAN



758U	6605-00-239-8206	COMPASS, MAGNETIC, MOUNTED	KOLLSMAN
7609-36H5-1	6685-00-526-7864	TRANSMITTER, PRESSURE	HONEYWELL
7609-3705-2	6685-00-526-7864	TRANSMITTER, PRESSURE	RAYTHEON
7609-37A5-1	6685-00-526-7864	TRANSMITTER, PRESSURE	HONEYWELL
7609-37B5-2	6685-00-526-7864	TRANSMITTER, PRESSURE	HONEYWELL
7609-37C5-1	6685-00-526-7864	TRANSMITTER, PRESSURE	HONEYWELL
7609-37D5-2	6685-00-526-7864	TRANSMITTER, PRESSURE	HONEYWELL
7609-37H5-1	6685-00-526-7864	TRANSMITTER, PRESSURE	HONEYWELL
7609-37M5-2	6685-00-526-7864	TRANSMITTER, PRESSURE	HONEYWELL
77000546-001	5945-00-628-6484	RELAY, HYBRID	DNE TECHNOLOGIES
77000580-000	6685-01-119-6546	THERMOSTAT, FLOW CONTROL	DNE TECHNOLOGIES
7700-15A5-1A	6620-00-553-8988	TRANSMITTER, PRESSURE	HONEYWELL INTERNATIONAL
7700-15A5-2	6620-00-553-8988	TRANSMITTER, PRESSURE	HONEYWELL INTERNATIONAL
7-702755	2915-00-673-3257	VALVE, FLOAT, FUEL TANK	PARKER HANNIFIN
7706-15A5-1	6620-00-553-8988	TRANSMITTER, PRESSURE	HONEYWELL INTERNATIONAL
7709-15A5-1	6620-00-553-8988	TRANSMITTER, PRESSURE	HONEYWELL INTERNATIONAL
7709-15-B5-1	6620-00-553-8988	TRANSMITTER, PRESSURE	HONEYWELL INTERNATIONAL
7709-15-B8-2	6685-00-851-1824	TRANSMITTER, PRESSURE	HONEYWELL INTERNATIONAL
7709-15-G5-1		TRANSMITTER, PRESSURE	HONEYWELL INTERNATIONAL
7-716835	2915-00-739-3047	VALVE, FLOAT, FUEL TANK	PARKER HANNIFIN
772-5140-001	6615-00-134-5980	GYROSCOPE, RATE OF TURN	ROCKWELL COLLINS
772-5140-002	6615-01-134-3127	GYROSCOPE, RATE OF TURN	ROCKWELL COLLINS
772-5370-001		INDICATOR, COURSE	ROCKWELL COLLINS
772-5370-002		INDICATOR, COURSE	ROCKWELL COLLINS
772-5370-003	5826-01-065-9189	INDICATOR, COURSE	ROCKWELL COLLINS
772-5370-005		INDICATOR, COURSE	ROCKWELL COLLINS
7742-10-A5-1	6620-00-999-2425	TRANSMITTER, PRESSURE	HONEYWELL INTERNATIONAL
7742-15-A5-1	6620-00-999-2222	TRANSMITTER, PRESSURE	HONEYWELL INTERNATIONAL
7742-17-A5-1	6620-00-436-6401	TRANSMITTER, PRESSURE	HONEYWELL INTERNATIONAL
7742-30-A5-1	6620-00-999-2424	TRANSMITTER, PRESSURE	HONEYWELL INTERNATIONAL
7742-47-A5-1	6620-00-065-3235	TRANSMITTER, PRESSURE	HONEYWELL INTERNATIONAL
7745-17A5-1	6620-00-901-7848	TRANSMITTER PRESSURE	HONEYWELL INTERNATIONAL
77600000-3	6610-01-044-1860	INDICATOR, ATTITUDE DIRECTOR	MOOG
77600000-4	6610-01-092-9846	INDICATOR, ATTITUDE DIRECTOR	MOOG
777-1029-001		CONTROL, RADIO SET	ROCKWELL COLLINS
777-1029-002		CONTROL, RADIO SET	ROCKWELL COLLINS
777-1029-003		CONTROL, RADIO SET	ROCKWELL COLLINS
777-1029-004		CONTROL, RADIO SET	ROCKWELL COLLINS
777-1029-005		CONTROL, RADIO SET	ROCKWELL COLLINS
777-1029-006		CONTROL, RADIO SET	ROCKWELL COLLINS
777-1029-007		CONTROL, RADIO SET	ROCKWELL COLLINS
777-1034-001	6615-00-134-5980	GYROSCOPE, RATE OF TURN	ROCKWELL COLLINS
777-1061-001		SERVO, AUTO-PILOT, PRIMARY	ROCKWELL COLLINS
777-1062-001	5999-01-157-0310	MOUNT, AUTO-PILOT, SERVO	ROCKWELL COLLINS
777-1062-003		MOUNT, AUTO-PILOT, SERVO	ROCKWELL COLLINS
777-1492-001	5826-00-322-2167	TRANSCEIVER, ADF	ROCKWELL COLLINS
777-1492-002	5895-01-020-3854	TRANSCEIVER, ADF	ROCKWELL COLLINS
777-1492-003	5841-01-105-3259	TRANSCEIVER, ADF	ROCKWELL COLLINS
777-1492-004	5826-01-068-7371	TRANSCEIVER, ADF	ROCKWELL COLLINS
777-1557-001		MOUNT, AUTO-PILOT, SERVO	ROCKWELL COLLINS
78035-01118	6620-01-230-0197	INDICATOR, ELECTRICAL TACHOMETER	AEROSONIC
78035-11119	6620-01-228-1571	INDICATOR, ELECTRICAL TACHOMETER	AEROSONIC
78700000-01	6610-01-114-6817	INDICATOR, ANGLE OF ATTACK	MOOG

78700000-02	6610-01-345-6430	INDICATOR, ANGLE OF ATTACK	MOOG
787-6017-001	5985-01-144-6797	ANTENNA, LOOP, ADF	ROCKWELL COLLINS
787-6377-001		CONTROL, RADIO SET	ROCKWELL COLLINS
787-6377-002		CONTROL, RADIO SET	ROCKWELL COLLINS
787-6378-001		CONTROL, RADIO SET	ROCKWELL COLLINS
787-6378-002		CONTROL, RADIO SET	ROCKWELL COLLINS
787-6557-001		CONTROL, RADIO SET	ROCKWELL COLLINS
787-6643-001		ANTENNA, LOOP, ADF	ROCKWELL COLLINS
792-3931-001	5985-00-269-5364	ANTENNA, LOOP, ADF	ROCKWELL COLLINS
792-6010-001		ANTENNA, LOOP, ADF	ROCKWELL COLLINS
792-6216-001	5826-00-275-0612	TRANSCEIVER, ADF	ROCKWELL COLLINS
792-6216-002	5820-01-013-8918	TRANSCEIVER, ADF	ROCKWELL COLLINS
792-6216-003	5826-00-275-0612	TRANSCEIVER, ADF	ROCKWELL COLLINS
792-6216-004	5826-00-275-0612	TRANSCEIVER, ADF	ROCKWELL COLLINS
792-6221-001	5826-01-065-9132	SELECTOR, HEADING, REMOTE	ROCKWELL COLLINS
792-6221-002		SELECTOR, HEADING, REMOTE	ROCKWELL COLLINS
792-6221-003		SELECTOR, HEADING, REMOTE	ROCKWELL COLLINS
792-6221-004		SELECTOR, HEADING, REMOTE	ROCKWELL COLLINS
792-6221-005		SELECTOR, HEADING, REMOTE	ROCKWELL COLLINS
792-6221-011	6605-01-397-2869	SELECTOR, HEADING, REMOTE	ROCKWELL COLLINS
792-6275-002	5826-01-065-1759	CONTROL, ADF	ROCKWELL COLLINS
792-6348-001	6615-01-015-9189	CONTROLLER, AUTOPILOT	ROCKWELL COLLINS
792-6348-002	6615-01-020-3681	CONTROLLER, AUTOPILOT	ROCKWELL COLLINS
792-6348-003	6615-01-128-2179	CONTROLLER, AUTOPILOT	ROCKWELL COLLINS
792-6348-004	6615-01-096-9997	CONTROLLER, AUTOPILOT	ROCKWELL COLLINS
792-6348-005	6615-01-038-7299	CONTROLLER, AUTOPILOT	ROCKWELL COLLINS
792-6348-015	6615-01-394-5917	CONTROLLER, AUTOPILOT	ROCKWELL COLLINS
792-6348-101		CONTROLLER, AUTOPILOT	ROCKWELL COLLINS
792-6348-102		CONTROLLER, AUTOPILOT	ROCKWELL COLLINS
792-6348-103		CONTROLLER, AUTOPILOT	ROCKWELL COLLINS
792-6348-104		CONTROLLER, AUTOPILOT	ROCKWELL COLLINS
792-6348-105		CONTROLLER, AUTOPILOT	ROCKWELL COLLINS
792-6357-002	6610-01-013-8911	INDICATOR, ATTITUDE DIRECTOR	ROCKWELL COLLINS
792-6357-008	6610-01-013-8911	INDICATOR, ATTITUDE DIRECTOR	ROCKWELL COLLINS
792-6501-001	5985-01-092-5595	ANTENNA, LOOP, ADF	ROCKWELL COLLINS
792-6672-001		CONTROL, AIR DATA	ROCKWELL COLLINS
792-6672-002		CONTROL, AIR DATA	ROCKWELL COLLINS
792-6672-004		CONTROL, AIR DATA	ROCKWELL COLLINS
792-6672-005		CONTROL, AIR DATA	ROCKWELL COLLINS
792-6672-008		CONTROL, AIR DATA	ROCKWELL COLLINS
792-6672-019	5821-01-208-8752	CONTROL, AIR DATA	ROCKWELL COLLINS
792-6694-001	5826-00-348-3874	GYROSCOPE, VERTICAL	ROCKWELL COLLINS
792-6694-002	6615-01-074-7200	GYROSCOPE, VERTICAL	ROCKWELL COLLINS
792-6694-004	5826-01-340-3801	GYROSCOPE, VERTICAL	ROCKWELL COLLINS
792-6703-003	6615-01-040-0126	COMPUTER, FLIGHT CONTROL	ROCKWELL COLLINS
792-6780-001		SERVO, AUTO-PILOT, PRIMARY	ROCKWELL COLLINS
792-6781-001	6615-01-037-7780	SERVO, AUTO-PILOT, PRIMARY	ROCKWELL COLLINS
792-6781-003	6615-01-037-7780	SERVO, AUTO-PILOT, PRIMARY	ROCKWELL COLLINS
792-6782-001		MOUNT, AUTO-PILOT, SERVO	ROCKWELL COLLINS
792-6783-001	6615-01-140-8884	MOUNT, AUTO-PILOT, SERVO	ROCKWELL COLLINS
792-6784-001	5999-01-157-0312	MOUNT, AUTO-PILOT, SERVO	ROCKWELL COLLINS
792-6784-003	6615-01-037-7780	MOUNT, AUTO-PILOT, SERVO	ROCKWELL COLLINS
792-6784-004	6615-01-074-7201	MOUNT, AUTO-PILOT, SERVO	ROCKWELL COLLINS

792-6785-001	6615-01-143-3749	MOUNT, AUTO-PILOT, SERVO	ROCKWELL COLLINS
792-6785-002	6615-01-065-9448	MOUNT, AUTO-PILOT, SERVO	ROCKWELL COLLINS
792-6785-003		MOUNT, AUTO-PILOT, SERVO	ROCKWELL COLLINS
792-6972-001		SERVO, AUTO-PILOT, PRIMARY	ROCKWELL COLLINS
792-6972-003		SERVO, AUTO-PILOT, PRIMARY	ROCKWELL COLLINS
792-6973-001	5975-01-156-4343	MOUNT, AUTO-PILOT, SERVO	ROCKWELL COLLINS
792-6973-002		MOUNT, AUTO-PILOT, SERVO	ROCKWELL COLLINS
792-6973-003		MOUNT, AUTO-PILOT, SERVO	ROCKWELL COLLINS
792-6974-001	6615-01-075-4726	MOUNT, AUTO-PILOT, SERVO	ROCKWELL COLLINS
7938174-60	5826-01-307-7380	TRANSMITTER, EMERGENCY LOCATOR (ELT)	POINTER
7MJ1	6685-00-526-7864	TRANSMITTER, PRESSURE	HONEYWELL
8000000	7050-MD-036-3532	DISPLAY, PANEL, TACTICAL	LOCKHEED MARTIN
80052-0	1660-00-887-4277	CONTROL BOX, AIR TEMPERATURE	KIDDE TECHNOLOGIES
8010000653-1	5841-01-301-4588	TRANSCEIVER, CARA	NAVCOM DEFENSE ELECTRONICS
8010000653-3	5841-01-301-4588	TRANSCEIVER, CARA	NAVCOM DEFENSE ELECTRONICS
8010000653-5	5841-01-246-9183	TRANSCEIVER, CARA	NAVCOM DEFENSE ELECTRONICS
8010000653-6	5841-01-301-4588	TRANSCEIVER, CARA	NAVCOM DEFENSE ELECTRONICS
8010000788-1	5841-01-349-9175	TRANSCEIVER, CARA	NAVCOM DEFENSE ELECTRONICS
8037M1	1680-01-013-9501	ACTUATOR, ELEVATOR TRIM TAB, ROTARY	CEF INDUSTRIES
8037M2	1680-01-013-9501	ACTUATOR, ELEVATOR TRIM TAB, ROTARY	CEF INDUSTRIES
80552-2	5826-00-390-5744	INDICATOR, BEARING	BORG INSTRUMENTS
8067-1A	1680-01-009-8293	ACTUATOR, ELECTRO-MECHANICAL, LINEAR	CEF INDUSTRIES
8067-2A	1680-01-009-8294	ACTUATOR, ELECTRO-MECHANICAL, LINEAR	CEF INDUSTRIES
8067-3A	1680-01-131-0901	ACTUATOR, ELECTRO-MECHANICAL, LINEAR	CEF INDUSTRIES
8067-4A	1680-01-131-0902	ACTUATOR, ELECTRO-MECHANICAL, LINEAR	CEF INDUSTRIES
808352/000	5985-01-447-0682	ANTENNA CONTROL SUBASSEMBLY	CEF INDUSTRIES
808352/020	5985-01-506-5380	ANTENNA CONTROL SUBASSEMBLY	RAYTHEON
80C705	5930-00-615-7340	SWITCH, PRESSURE	HATHAWAY MOTION CONTROL
81-0284	5826-01-012-4864	ADAPTER, TACAN, TRANSCEIVER	ROCKWELL COLLINS
81-3207	4140-00-289-4277	FAN, VANE, AXIAL	NORTHROP GRUMMAN SYSTEMS
81-4557	5975-01-041-2044	MOUNTING BASE, TACAN, TRANSCEIVER	ROCKWELL COLLINS
814B	6605-00-221-1352	COMPASS, MAGNETIC, MOUNTED	KOLLSMAN
814BN	6605-00-641-1293	COMPASS, MAGNETIC, MOUNTED	KOLLSMAN
817586-1	6645-01-449-1630	TIMER, SEQUENTIAL	HAMILTON SUNDSTRAND
822-0400-001		RECEIVER, RADIO NAVIGATION	ROCKWELL COLLINS
822-0731-001		TRANSCEIVER, VHF, RADIO	ROCKWELL COLLINS
822-0731-002		TRANSCEIVER, VHF, RADIO	ROCKWELL COLLINS
822-0731-003		TRANSCEIVER, VHF, RADIO	ROCKWELL COLLINS
822-0731-004		TRANSCEIVER, VHF, RADIO	ROCKWELL COLLINS
822-0731-005		TRANSCEIVER, VHF, RADIO	ROCKWELL COLLINS
822-0731-006		TRANSCEIVER, VHF, RADIO	ROCKWELL COLLINS
822-0731-008		TRANSCEIVER, VHF, RADIO	ROCKWELL COLLINS
822-0731-009		TRANSCEIVER, VHF, RADIO	ROCKWELL COLLINS
822-0731-010		TRANSCEIVER, VHF, RADIO	ROCKWELL COLLINS
822-0731-011		TRANSCEIVER, VHF, RADIO	ROCKWELL COLLINS
822-0732-001	5821-01-535-6577	TRANSCEIVER, VHF, RADIO	ROCKWELL COLLINS
822-0732-002	5821-01-495-0990	TRANSCEIVER, VHF, RADIO	ROCKWELL COLLINS
822-0732-003		TRANSCEIVER, VHF, RADIO	ROCKWELL COLLINS
822-0732-010		TRANSCEIVER, VHF, RADIO	ROCKWELL COLLINS
822-0732-011		TRANSCEIVER, VHF, RADIO	ROCKWELL COLLINS
822-0732-101		TRANSCEIVER, VHF, RADIO	ROCKWELL COLLINS
822-0732-102		TRANSCEIVER, VHF, RADIO	ROCKWELL COLLINS
822-0732-103		TRANSCEIVER, VHF, RADIO	ROCKWELL COLLINS

822-0732-110		TRANSCEIVER, VHF, RADIO	ROCKWELL COLLINS
822-0732-111		TRANSCEIVER, VHF, RADIO	ROCKWELL COLLINS
822-0732-203		TRANSCEIVER, VHF, RADIO	ROCKWELL COLLINS
822-0732-205		TRANSCEIVER, VHF, RADIO	ROCKWELL COLLINS
822-0732-206		TRANSCEIVER, VHF, RADIO	ROCKWELL COLLINS
822-0732-208		TRANSCEIVER, VHF, RADIO	ROCKWELL COLLINS
822-0732-209		TRANSCEIVER, VHF, RADIO	ROCKWELL COLLINS
822-0732-210		TRANSCEIVER, VHF, RADIO	ROCKWELL COLLINS
822-0760-001	5826-01-519-4202	RECEIVER, VOR/ILS RADIO NAVIGATION	ROCKWELL COLLINS
822-0760-002	5895-01-493-8421	RECEIVER, VOR/ILS RADIO NAVIGATION	ROCKWELL COLLINS
822-0760-003		RECEIVER, VOR/ILS RADIO NAVIGATION	ROCKWELL COLLINS
822-0760-004		RECEIVER, VOR/ILS RADIO NAVIGATION	ROCKWELL COLLINS
822-0760-005		RECEIVER, VOR/ILS RADIO NAVIGATION	ROCKWELL COLLINS
822-0760-006		RECEIVER, VOR/ILS RADIO NAVIGATION	ROCKWELL COLLINS
822-0760-007		RECEIVER, VOR/ILS RADIO NAVIGATION	ROCKWELL COLLINS
822-0760-008		RECEIVER, VOR/ILS RADIO NAVIGATION	ROCKWELL COLLINS
822-0760-009		RECEIVER, VOR/ILS RADIO NAVIGATION	ROCKWELL COLLINS
822-0761-001	5826-01-481-6179	RECEIVER, VOR/ILS RADIO NAVIGATION	ROCKWELL COLLINS
822-0761-002		RECEIVER, VOR/ILS RADIO NAVIGATION	ROCKWELL COLLINS
822-0761-003		RECEIVER, VOR/ILS RADIO NAVIGATION	ROCKWELL COLLINS
822-0761-004	5826-01-462-3896	RECEIVER, VOR/ILS RADIO NAVIGATION	ROCKWELL COLLINS
822-0761-005		RECEIVER, VOR/ILS RADIO NAVIGATION	ROCKWELL COLLINS
822-0761-006		RECEIVER, VOR/ILS RADIO NAVIGATION	ROCKWELL COLLINS
822-0761-007		RECEIVER, VOR/ILS RADIO NAVIGATION	ROCKWELL COLLINS
822-0761-008		RECEIVER, VOR/ILS RADIO NAVIGATION	ROCKWELL COLLINS
822-0761-009		RECEIVER, VOR/ILS RADIO NAVIGATION	ROCKWELL COLLINS
822-0761-010	5826-01-509-8441	RECEIVER, VOR/ILS RADIO NAVIGATION	ROCKWELL COLLINS
822-0761-011		RECEIVER, VOR/ILS RADIO NAVIGATION	ROCKWELL COLLINS
822-0761-012		RECEIVER, VOR/ILS RADIO NAVIGATION	ROCKWELL COLLINS
822-0761-013		RECEIVER, VOR/ILS RADIO NAVIGATION	ROCKWELL COLLINS
822-0761-101		RECEIVER, VOR/ILS RADIO NAVIGATION	ROCKWELL COLLINS
822-0761-201		RECEIVER, VOR/ILS RADIO NAVIGATION	ROCKWELL COLLINS
822-0762-002	5826-01-657-7610	RECEIVER, VOR/ILS RADIO NAVIGATION	ROCKWELL COLLINS
822-0762-003		RECEIVER, VOR/ILS RADIO NAVIGATION	ROCKWELL COLLINS
822-0762-005		RECEIVER, VOR/ILS RADIO NAVIGATION	ROCKWELL COLLINS
822-1000-011		DISPLAY, OPTOELECTRONIC, EADI/EHSI	ROCKWELL COLLINS
822-1000-012		DISPLAY, OPTOELECTRONIC, EADI/EHSI	ROCKWELL COLLINS
822-1000-021	6610-01-460-1385	DISPLAY, OPTOELECTRONIC, EADI/EHSI	ROCKWELL COLLINS
822-1000-022		DISPLAY, OPTOELECTRONIC, EADI/EHSI	ROCKWELL COLLINS
822-1000-121		DISPLAY, OPTOELECTRONIC, EADI/EHSI	ROCKWELL COLLINS
822-1000-122		DISPLAY, OPTOELECTRONIC, EADI/EHSI	ROCKWELL COLLINS
822-1001-011	6610-01-459-8690	DISPLAY, MULTIFUNCTION	ROCKWELL COLLINS
822-1001-012		DISPLAY, MULTIFUNCTION	ROCKWELL COLLINS
822-1001-121		DISPLAY, MULTIFUNCTION	ROCKWELL COLLINS
822-1001-122		DISPLAY, MULTIFUNCTION	ROCKWELL COLLINS
822-1038-001	1680-01-471-2283	CONTROL PANEL, AIRCRAFT	ROCKWELL COLLINS
822-1045-001		TRANSCEIVER, VHF, RADIO	ROCKWELL COLLINS
822-1045-003		TRANSCEIVER, VHF, RADIO	ROCKWELL COLLINS
822-1045-004		TRANSCEIVER, VHF, RADIO	ROCKWELL COLLINS
822-1045-005		TRANSCEIVER, VHF, RADIO	ROCKWELL COLLINS
822-1045-006		TRANSCEIVER, VHF, RADIO	ROCKWELL COLLINS
822-1045-008		TRANSCEIVER, VHF, RADIO	ROCKWELL COLLINS
822-1045-009		TRANSCEIVER, VHF, RADIO	ROCKWELL COLLINS

822-1045-301		TRANSCEIVER, VHF, RADIO	ROCKWELL COLLINS
822-1045-303		TRANSCEIVER, VHF, RADIO	ROCKWELL COLLINS
822-1045-311		TRANSCEIVER, VHF, RADIO	ROCKWELL COLLINS
822-1045-401		TRANSCEIVER, VHF, RADIO	ROCKWELL COLLINS
822-1045-403		TRANSCEIVER, VHF, RADIO	ROCKWELL COLLINS
822-1045-411		TRANSCEIVER, VHF, RADIO	ROCKWELL COLLINS
822-1045-503		TRANSCEIVER, VHF, RADIO	ROCKWELL COLLINS
822-1045-505		TRANSCEIVER, VHF, RADIO	ROCKWELL COLLINS
822-1045-506		TRANSCEIVER, VHF, RADIO	ROCKWELL COLLINS
822-1045-508		TRANSCEIVER, VHF, RADIO	ROCKWELL COLLINS
822-1045-509		TRANSCEIVER, VHF, RADIO	ROCKWELL COLLINS
822-1046-001	5820-01-474-0840	TRANSCEIVER, VHF, RADIO	ROCKWELL COLLINS
822-1046-003	5821-01-541-6335	TRANSCEIVER, VHF, RADIO	ROCKWELL COLLINS
822-1046-011		TRANSCEIVER, VHF, RADIO	ROCKWELL COLLINS
822-1046-101	5820-01-517-3020	TRANSCEIVER, VHF, RADIO	ROCKWELL COLLINS
822-1046-103		TRANSCEIVER, VHF, RADIO	ROCKWELL COLLINS
822-1046-111		TRANSCEIVER, VHF, RADIO	ROCKWELL COLLINS
822-1046-203		TRANSCEIVER, VHF, RADIO	ROCKWELL COLLINS
822-1046-205		TRANSCEIVER, VHF, RADIO	ROCKWELL COLLINS
822-1046-206		TRANSCEIVER, VHF, RADIO	ROCKWELL COLLINS
822-1046-208		TRANSCEIVER, VHF, RADIO	ROCKWELL COLLINS
822-1046-209		TRANSCEIVER, VHF, RADIO	ROCKWELL COLLINS
822-1111-001		TRANSCEIVER, VHF, RADIO	ROCKWELL COLLINS
822-1112-001		TRANSCEIVER, VHF, RADIO	ROCKWELL COLLINS
822-1113-001	5821-01-587-6175	TRANSCEIVER, VHF, RADIO	ROCKWELL COLLINS
822-1113-021		TRANSCEIVER, VHF, RADIO	ROCKWELL COLLINS
822-1113-023		TRANSCEIVER, VHF, RADIO	ROCKWELL COLLINS
822-1114-001	5821-01-467-8793	TRANSCEIVER, VHF, RADIO	ROCKWELL COLLINS
822-1114-021	5821-01-484-2068	TRANSCEIVER, VHF, RADIO	ROCKWELL COLLINS
822-1114-023		TRANSCEIVER, VHF, RADIO	ROCKWELL COLLINS
822-1360-021	5895-MD-035-4227	WEATHER RADAR ADAPTER	ROCKWELL COLLINS
822-2092-001	5821-01-527-4256	CONTROL, RADIO SET	ROCKWELL COLLINS
828-0161-003	5820-01-503-5842	TRANSCEIVER, RADIO	ROCKWELL COLLINS
8301-102-00-11	6685-14-423-8334	SONDE, EGT	ACTIA (THALES AVIONICS)
831-0001	6340-00-304-5556	DETECTOR, ICE	NORTHERN TELECOM
831-8-10	1650-00-815-2499	FUSE, HYDRAULIC SYSTEM	PARKER-HANNIFIN
83200-3	5841-MD-010-4248	INDICATOR, DME	CINAVE
8348M1	1620-00-617-9123	GEARBOX, LANDING	LOCKHEED MARTIN
8445M1	1680-01-324-8157	ACTUATOR, ELECTRO-MECHANICAL, LINEAR	CEF INDUSTRIES
8446M1	1680-01-472-9783	ACTUATOR, ELECTRO-MECHANICAL, LINEAR	CEF INDUSTRIES
8545M1	1680-01-217-5837	ACTUATOR, ELECTRO-MECHANICAL, LINEAR	CEF INDUSTRIES
8546M1	1680-01-222-2551	ACTUATOR, ELECTRO-MECHANICAL, LINEAR	CEF INDUSTRIES
855-51-00-00-951	6130-14-380-2739	POWER SUPPLY	CEF INDUSTRIES
8555M1	6220-00-299-4621	LIGHT, LANDING, AIRCRAFT	CEF INDUSTRIES
8555M2		LIGHT, LANDING, AIRCRAFT	CEF INDUSTRIES
8555M3		LIGHT, LANDING, AIRCRAFT	CEF INDUSTRIES
8555M4		LIGHT, LANDING, AIRCRAFT	CEF INDUSTRIES
8555M5		LIGHT, LANDING, AIRCRAFT	CEF INDUSTRIES
8555M6	6220-01-316-4577	LIGHT, LANDING, AIRCRAFT	CEF INDUSTRIES
8555M7		LIGHT, LANDING, AIRCRAFT	CEF INDUSTRIES
8555M9	6220-01-657-7449	LIGHT, LANDING, AIRCRAFT	CEF INDUSTRIES
86000-1113	6645-00-415-9018	CLOCK, MECHANICAL, PANEL	CEF INDUSTRIES
860F-1		TRANSCEIVER, RADIO ALTIMETER	ROCKWELL COLLINS

860F-4		TRANSCEIVER, RADIO ALTIMETER	ROCKWELL COLLINS
86400-1110	6645-00-076-3050	CLOCK, MECHANICAL, PANEL	AEROSONIC
86425-4	6620-00-514-5334	INDICATOR, PRESSURE	S-TECH
8656M2	1680-01-497-7142	ACTUATOR, ELECTRO-MECHANICAL, LINEAR, OIL COOLER DOOR	CEF INDUSTRIES
880-22293-5	6605-00-239-8209	COMPASS, MAGNETIC, MOUNTED	CEF INDUSTRIES
880T100	1680-00-073-8204	ACTUATOR, ELECTRO-MECHANICAL, LINEAR	AEROCONTROLEX
880T100-3	1680-01-254-6893	ACTUATOR, ELECTRO-MECHANICAL, LINEAR	AEROCONTROLEX
89000-1	6620-00-901-7848	TRANSMITTER PRESSURE	S-TECH
891041-100	6350-01-280-1671	DETECTOR, HEAT	KIDDE TECHNOLOGIES
892541-100	6350-00-015-8049	DETECTOR, HEAT	KIDDE TECHNOLOGIES
899L-1		ADAPTER, TACAN, TRANSCEIVER	ROCKWELL COLLINS
8AW59FAA1	6625-00-668-7818	METER, ELECTRICAL FREQUENCY	AMETEK
8DJ179DBD3	6620-01-135-3043	INDICATOR, TEMPERATURE, FAN TURBINE INLET	AMETEK
8DJ179DBE1	6620-01-256-4307	INDICATOR, TEMPERATURE, FAN TURBINE INLET	AMETEK
8DJ179WAD1	6685-01-096-6867	INDICATOR, THERMOCOUPLE, TEMPERATURE	AMETEK
8DJ215WBA1	6620-01-129-7247	INDICATOR, ELECTRICAL, TACHOMETER	AMETEK
8DJ43AAM	6620-00-515-4541	INDICATOR, ELECTRICAL TACHOMETER	AMETEK
8DJ43AAM11	6680-00-663-4209	INDICATOR, ELECTRICAL TACHOMETER	AMETEK
8DJ43AAM13	6680-00-663-4207	INDICATOR, ELECTRICAL TACHOMETER	AMETEK
8DJ43AAM9	6680-00-663-4214	INDICATOR, ELECTRICAL TACHOMETER	AMETEK
8DJ48FAL1	6610-00-515-4600	INDICATOR, FLAP, POSITION	AMETEK
8DJ48FAL2	6610-00-515-4600	INDICATOR, FLAP, POSITION	AMETEK
8DJ49GAW1	6610-00-808-7037	INDICATOR, AILERON TRIM TAB, POSITION	AMETEK
8DJ49GAW2	6610-00-808-7037	INDICATOR, AILERON TRIM TAB, POSITION	AMETEK
8DJ49GAX2		INDICATOR, AILERON TRIM TAB, POSITION	AMETEK
8DJ49GAY	6610-00-580-9690	INDICATOR, AILERON TRIM TAB, POSITION	AMETEK
8DJ49GAY1	6610-00-580-9690	INDICATOR, AILERON TRIM TAB, POSITION	AMETEK
8DJ49GAY2	6610-00-580-9690	INDICATOR, AILERON TRIM TAB, POSITION	AMETEK
8DJ49GBV	6610-00-808-7038	INDICATOR, AILERON TRIM TAB, POSITION	AMETEK
8DJ49GBV1	6610-00-808-7038	INDICATOR, AILERON TRIM TAB, POSITION	AMETEK
8DJ49GBV2	6610-00-808-7038	INDICATOR, AILERON TRIM TAB, POSITION	AMETEK
8DJ49GEP2	6610-01-393-2386	INDICATOR, AILERON TRIM TAB, POSITION	AMETEK
8DJ49GER2	6610-01-393-4116	INDICATOR, AILERON TRIM TAB, POSITION	AMETEK
8DJ49GET2	6610-01-393-2384	INDICATOR, AILERON TRIM TAB, POSITION	AMETEK
8DJ49LAL2		INDICATOR, AILERON TRIM TAB, POSITION	AMETEK
8DJ49LAM2	6610-00-817-8771	INDICATOR, AILERON TRIM TAB, POSITION	AMETEK
8DJ49LAN2	6610-00-817-8772	INDICATOR, AILERON TRIM TAB, POSITION	AMETEK
8DJ49LAV2	6610-00-087-6303	INDICATOR, AILERON TRIM TAB, POSITION	AMETEK
8DJ51GAB4	6695-00-628-8990	INDICATOR, POSITION	AMETEK
8DJ64GAF1	6685-00-561-9378	INDICATOR, FUEL FLOW	AMETEK
8DJ64GAS1		INDICATOR, FUEL FLOW	AMETEK
8DJ64GAT1		INDICATOR, FUEL FLOW	AMETEK
8DJ64GAX	6620-00-021-2239	INDICATOR, FUEL FLOW	AMETEK
8DJ64GAX1	6620-00-021-2239	INDICATOR, FUEL FLOW	AMETEK
8DJ64GBA1		INDICATOR, FUEL FLOW	AMETEK
8DJ64GBC1	6620-01-098-2960	INDICATOR, FUEL FLOW	AMETEK
8DJ64GBH1	6620-01-038-5769	INDICATOR, FUEL FLOW	AMETEK
8DJ64GBW1	6620-01-391-2998	INDICATOR, FUEL FLOW	AMETEK
8DJ71GAB	6620-00-551-2631	INDICATOR, FUEL FLOW	AMETEK
8DJ71GAB1	6620-00-551-2631	INDICATOR, FUEL FLOW	AMETEK
8DJ71GAK2	6620-00-621-2903	INDICATOR, FUEL FLOW	AMETEK
8DJ81CAA1	6620-00-621-0143	INDICATOR, ELECTRICAL TACHOMETER	AMETEK
8DJ81CAA2	6620-00-969-3972	INDICATOR, ELECTRICAL TACHOMETER	AMETEK

8DJ81CAA4	6680-00-663-4207	INDICATOR, ELECTRICAL TACHOMETER	AMETEK
8DJ81CAN1		INDICATOR, ELECTRICAL TACHOMETER	AMETEK
8DJ81CAN2	6620-00-543-2534	INDICATOR, ELECTRICAL TACHOMETER	AMETEK
8DJ81CAN4	6620-00-148-8307	INDICATOR, ELECTRICAL TACHOMETER	AMETEK
8DJ81CBD4	6620-01-157-9266	INDICATOR, ELECTRICAL TACHOMETER	AMETEK
8DJ81CDR4		INDICATOR, ELECTRICAL TACHOMETER	AMETEK
8DJ81CDS4		INDICATOR, ELECTRICAL TACHOMETER	AMETEK
8DJ81CDW4		INDICATOR, ELECTRICAL TACHOMETER	AMETEK
8DJ81CDX4		INDICATOR, ELECTRICAL TACHOMETER	AMETEK
8DJ81CDZ4		INDICATOR, ELECTRICAL TACHOMETER	AMETEK
8TJ39AAM	6610-00-800-5569	TRANSMITTER, POSITION	AMETEK
8TJ39AAM2	6610-00-800-5569	TRANSMITTER, POSITION	AMETEK
8TJ50GAB1		TRANSMITTER, FLOWMETER	AMETEK
8TJ50GAB3		TRANSMITTER, FLOWMETER	AMETEK
8TJ50GAS4	6620-00-726-8153	TRANSMITTER, FLOWMETER	AMETEK
8TJ50GAS5	6620-00-720-3223	TRANSMITTER, FLOWMETER	AMETEK
8TJ50GBM5	6620-00-621-2902	TRANSMITTER, FLOWMETER	AMETEK
8TJ51GAA5	6130-00-772-8567	POWER SUPPLY, FLOWMETER	AMETEK
8TJ51GBB5	6130-00-754-2950	POWER SUPPLY, FUEL FLOW	AMETEK
8TJ64GAL	6620-00-020-3211	TRANSMITTER, FUEL FLOW	AMETEK
8TJ64GAL1	6620-00-020-3211	TRANSMITTER, FUEL FLOW	AMETEK
8TJ88GAD1	6125-01-098-2961	POWER SUPPLY, FUEL FLOW	AMETEK
8TJ88GAD3	6130-01-314-0886	POWER SUPPLY, FUEL FLOW	AMETEK
8TJ88GAD4	6130-01-314-0886	POWER SUPPLY, FUEL FLOW	AMETEK
8TJ88GADI	6130-01-314-0886	POWER SUPPLY, FUEL FLOW	AMETEK
8TJ88GAH1	6130-00-906-9917	POWER SUPPLY, FUEL FLOW	AMETEK
8TJ88GAH3	6130-01-227-4291	POWER SUPPLY, FUEL FLOW	AMETEK
8TJ88GAP1		POWER SUPPLY, FUEL FLOW	AMETEK
8TJ88GAR1	6120-01-118-6644	POWER SUPPLY, FUEL FLOW	AMETEK
8TJ88GAT1	6130-00-250-9270	POWER SUPPLY, FUEL FLOW	AMETEK
8TJ88GAV1		POWER SUPPLY, FUEL FLOW	AMETEK
8TJ95GAA4	6130-01-328-4653	POWER SUPPLY, FLOWMETER	AMETEK
8TJ95GAB4		POWER SUPPLY, FLOWMETER	AMETEK
8TJ95GAC4	6130-01-411-9171	POWER SUPPLY, FLOWMETER	AMETEK
90007105-000	6685-01-119-6546	THERMOSTAT, FLOW CONTROL	DNE TECHNOLOGIES
9000WB	5965-00-755-4643	MICROPHONE, DYNAMIC	ACOUSTICOM
90050-3	5998-MD-031-7652	PANEL, FAILURE WARNING	LEACH
90-10072-1	1650-01-063-8814	SNUBBER ASSEMBLY, ENTRY DOOR	BOEING
90-10072-2	1650-01-005-2760	SNUBBER ASSEMBLY, ENTRY DOOR	BOEING
901574-3	1650-00-821-4051	CYLINDER ASSEMBLY, ACTUATING, LINEAR	LOCKHEED MARTIN
902607-1	1650-00-887-4305	CYLINDER ASSEMBLY, ACTUATING, LINEAR	LOCKHEED MARTIN
907-74	6625-01-412-3365	METER, ELECTRICAL FREQUENCY	LOCKHEED MARTIN
913G-1		CONTROL PANEL, TACAN, TRANSCEIVER	ROCKWELL COLLINS
913G-2		CONTROL PANEL, TACAN, TRANSCEIVER	ROCKWELL COLLINS
913G-4		CONTROL PANEL, TACAN, TRANSCEIVER	ROCKWELL COLLINS
915-38106-001	6130-01-217-5880	POWER SUPPLY, AIRSPEED INDICATOR	KOLLSMAN
917108-1	4140-01-041-4886	FAN, VANE, AXIAL	LITTON
918918-1	1560-00-821-5126	TANK, ENGINE OIL	LOCKHEED MARTIN
918918-101	1560-00-821-5126	TANK, ENGINE OIL	LOCKHEED MARTIN
918918-103	2840-00-883-2743	TANK, ENGINE OIL	LOCKHEED MARTIN
918918-111	2840-00-883-2743	TANK, ENGINE OIL	LOCKHEED MARTIN
925659-02	6645-00-076-3050	CLOCK, MECHANICAL, PANEL	LOCKHEED MARTIN
925659-04	6645-00-076-3050	CLOCK, MECHANICAL, PANEL	RAYTHEON

927451-0118	5965-00-755-4643	MICROPHONE, DYNAMIC	NORTHROP GRUMMAN SYSTEMS
931-0001	6340-00-304-5556	DETECTOR, ICE	NORTHERN TELECOM
93-A152-16	5895-01-128-7267	CONTROL, AMPLIFIER	L3 AVIATION PRODUCTS
942-021031	5826-00-505-3580	INDICATOR, BEARING	KOLLSMAN
947F310-3	6110-01-552-9513	GENERATOR CONTROL UNIT	LOCKHEED MARTIN
9550616-1	1630-01-094-1104	WHEEL, MAIN LANDING GEAR	MEGGITT AIRCRAFT BRAKING SYSTEMS
9560569-1	1630-01-009-8475	BRAKE, MULTIPLE DISK	MEGGITT AIRCRAFT BRAKING SYSTEMS
9560685-1	1630-01-500-1903	BRAKE, MULTIPLE DISK	MEGGITT AIRCRAFT BRAKING SYSTEMS
95797-39	6680-01-058-5863	INDICATOR, FUEL QUANTITY	HONEYWELL INTERNATIONAL
95990000-000	6680-01-170-8405	TRANSMITTER, LIQUID QUANTITY	DNE TECHNOLOGIES
962194-101	1680-01-011-3856	INTERCONNECTING BOX	LOCKHEED MARTIN
975.26.10.108	6680-01-397-6175	GENERATOR, TACHOMETER	PILATUS AIRCRAFT
9-755-2	4820-00-855-8411	VALVE, HYDRAULIC PRESSURE SHUTOFF	PARKER-HANNIFIN
976J198-1	6130-00-958-9796	POWER SUPPLY, DC	HAMILTON SUNDSTRAND
98700000-02	6610-01-395-3510	INDICATOR, VERTICAL VELOCITY	MOOG
98B3900	6685-01-119-6546	THERMOSTAT, FLOW CONTROL	EDEL ENGINEERING DEVELOPMENT
9901-300	2915-00-464-6946	CONTROL, SENSITIVE, SPEED	WOODWARD
9901-301	2915-00-464-6946	CONTROL, SENSITIVE, SPEED	WOODWARD
991M-1	5975-01-060-9629	MOUNTING BASE, TACAN, TRANSCEIVER	ROCKWELL COLLINS
991M-2		MOUNTING BASE, TACAN, TRANSCEIVER	ROCKWELL COLLINS
991N-1		MOUNTING BASE, TACAN, TRANSCEIVER	ROCKWELL COLLINS
991N-2		MOUNTING BASE, TACAN, TRANSCEIVER	ROCKWELL COLLINS
991N-3		MOUNTING BASE, TACAN, TRANSCEIVER	ROCKWELL COLLINS
991N-4	5975-01-037-6649	MOUNTING BASE, TACAN, TRANSCEIVER	ROCKWELL COLLINS
991N-5	5975-01-039-7621	MOUNTING BASE, TACAN, TRANSCEIVER	ROCKWELL COLLINS
992C-2		TRAY, ELECTRONIC, MOUNTING	ROCKWELL COLLINS
992F-1	5975-01-066-9462	MOUNTING BASE, TACAN, TRANSCEIVER	ROCKWELL COLLINS
992L-2		MOUNTING BASE, TACAN, TRANSCEIVER	ROCKWELL COLLINS
993N-1		MOUNTING BASE, TACAN, TRANSCEIVER	ROCKWELL COLLINS
993R-1	5975-01-120-7047	MOUNTING BASE, TACAN, TRANSCEIVER	ROCKWELL COLLINS
993W-1	5975-01-152-1266	MOUNTING BASE, TACAN, TRANSCEIVER	ROCKWELL COLLINS
995-2	7310-00-905-6212	OVEN, WARMING, ELECTRIC	PIASECKI AIRCRAFT
995G-2	5975-01-242-9549	MOUNTING BASE, TACAN, TRANSCEIVER	ROCKWELL COLLINS
998J-1	5826-01-066-2662	ADAPTER, TACAN, TRANSCEIVER	ROCKWELL COLLINS
999W-2	5820-01-308-2377	ADAPTER, RADIO, HIGH FREQUENCY	ROCKWELL COLLINS
999W-2A	5820-01-210-2008	ADAPTER, RADIO, HIGH FREQUENCY	ROCKWELL COLLINS
9A1100	6620-01-206-5748	INDICATOR, TORQUEMETER	ROCKWELL COLLINS
9A1300	6620-01-242-7236	INDICATOR, TORQUEMETER	TRANSICOIL
9A2100	6620-01-264-8685	INDICATOR, TORQUEMETER	TRANSICOIL
9A324	6680-00-753-8932	INDICATOR, LIQUID QUANTITY	TRANSICOIL
9A375	6685-00-148-8247	INDICATOR, THERMOCOUPLE, TEMPERATURE	TRANSICOIL
9A-375	6685-00-148-8247	INDICATOR, THERMOCOUPLE, TEMPERATURE	TRANSICOIL
9A400	6685-00-183-0351	INDICATOR, THERMOCOUPLE, TEMPERATURE	TRANSICOIL
9A-400	6685-00-183-0351	INDICATOR, THERMOCOUPLE, TEMPERATURE	TRANSICOIL
9A550	6685-01-506-8079	INDICATOR, THERMOCOUPLE, TEMPERATURE	TRANSICOIL
9A-550	6685-01-506-8079	INDICATOR, THERMOCOUPLE, TEMPERATURE	TRANSICOIL
9D-84073-1	7025-MD-036-3550	PANEL DISPLAY	ISS
A06		TRANSMITTER, EMERGENCY LOCATOR (ELT)	ISS
A06T		TRANSMITTER, EMERGENCY LOCATOR (ELT)	ELTA
A-11	6645-00-950-8599	CLOCK, MECHANICAL, PANEL	LONGINES-WITTMANER WATCH
A13A1	6645-00-950-8599	CLOCK, MECHANICAL, PANEL	WALTHAM AIRCRAFT CLOCK
A13A2	6645-00-880-5927	CLOCK, MECHANICAL, PANEL	WALTHAM AIRCRAFT CLOCK
A-13A-2	6645-01-633-0303	CLOCK, MECHANICAL, PANEL	WALTHAM AIRCRAFT CLOCK



A20112-02	1560-01-551-2217	POWER SUPPLY, AIRCRAFT	MACROLINK
A2850-1	6615-00-857-0828	GYROSCOPE, RATE OF TURN	KELLY MANUFACTURING
A2850-5	6615-00-869-0825	GYROSCOPE, RATE OF TURN	KELLY MANUFACTURING
A3-06-2749-1		TRANSMITTER, EMERGENCY LOCATOR (ELT)	ARTEX
A3-06-2796-8		TRANSMITTER, EMERGENCY LOCATOR (ELT)	ARTEX
A3-06-2796-9		TRANSMITTER, EMERGENCY LOCATOR (ELT)	ARTEX
A3-06-2880		TRANSMITTER, EMERGENCY LOCATOR (ELT)	ARTEX
A364	5895-00-168-8277	CONVERTER, SIGNAL DATA	LOCKHEED MARTIN
A40A1750	6110-00-500-0391	REGULATOR, VOLTAGE	WESTINGHOUSE ELECTRIC
A40A1750-2	6110-00-483-9247	REGULATOR, VOLTAGE	HAMILTON SUNDSTRAND
A4132210015	6610-01-016-1583	ALTIMETER, SERVO CONTROLLED	KOLLSMAN
A41322-10-015	6610-01-035-0673	ALTIMETER, SERVO CONTROLLED	KOLLSMAN
A487-3	1680-00-705-9996	ACTUATOR, ELECTRO-MECHANICAL, LINEAR	KILGORE FLARES
A487-4	1680-00-705-9997	ACTUATOR, ELECTRO-MECHANICAL, LINEAR	KILGORE FLARES
A489-3	1680-00-672-8931	ACTUATOR, ELEVATOR TRIM TAB, ROTARY	LUNDY ELECTRONICS & SYSTEMS
A489-4	1680-00-672-8931	ACTUATOR, ELEVATOR TRIM TAB, ROTARY	LUNDY ELECTRONICS & SYSTEMS
A489-5	1680-01-013-3229	ACTUATOR, ELEVATOR TRIM TAB, ROTARY	LUNDY ELECTRONICS & SYSTEMS
A6881-2C	1680-00-782-5861	SEAT, AIRCRAFT, TROOPS	C. R. DANIELS
A6881-2L	1680-00-913-4840	SEAT, AIRCRAFT, TROOPS	C. R. DANIELS
A6881-2R	1680-00-913-4841	SEAT, AIRCRAFT, TROOPS	C. R. DANIELS
A6897-1L	1680-00-671-3837	SEAT, AIRCRAFT, TROOPS	C. R. DANIELS
A6897-1R	1680-00-671-2101	SEAT, AIRCRAFT, TROOPS	C. R. DANIELS
A81-12	5831-00-872-6835	STATION, INTERCOMMUNICATION SET	ANDREA SYSTEMS
A81-13	5831-00-809-3180	CONTROL, INTERCOMMUNICATION SET	ANDREA SYSTEMS
A81-16	5831-00-901-3781	CONTROL, INTERCOMMUNICATION SET	ANDREA SYSTEMS
A81-2	5831-00-809-3180	CONTROL, INTERCOMMUNICATION SET	ANDREA SYSTEMS
A81-49	5831-00-880-2834	CONTROL, INTERCOMMUNICATION SET	ANDREA SYSTEMS
A81-4PS	5831-00-808-9796	CONTROL, INTERCOMMUNICATION SET	ANDREA SYSTEMS
A81-59	5831-00-539-1471	CONTROL, INTERCOMMUNICATION SET	ANDREA SYSTEMS
A81-6	5996-00-623-2912	AMPLIFIER, INTERCOMMUNICATION SET	ANDREA SYSTEMS
A81-91	5831-00-523-5328	CONTROL, INTERCOMMUNICATION SET	ANDREA SYSTEMS
A-825	5945-00-522-6886	RELAY, HYBRID	TE CONNECTIVITY
A-846	2925-00-328-0738	RELAY, HYBRID	TE CONNECTIVITY
A-846-1	5945-00-346-3642	RELAY, HYBRID	TE CONNECTIVITY
A-846-2	5945-00-607-3478	RELAY, HYBRID	TE CONNECTIVITY
A-846-5	5945-01-061-2266	RELAY, HYBRID	TE CONNECTIVITY
A-846-6	5945-00-628-6484	RELAY, HYBRID	TE CONNECTIVITY
A-902-3		RELAY, HYBRID	TE CONNECTIVITY
AAF224225	6685-00-514-5061	INDICATOR, PRESSURE	AEROSONIC
AAU-21/A	6610-00-405-6461	ALTIMETER, ENCODER	KOLLSMAN
AAU21A	6610-00-405-6461	ALTIMETER, ENCODER	KOLLSMAN
AAU-27/A	6610-00-160-3226	ALTIMETER PRESSURE	AEROSONIC
AAU27A	6610-00-160-3226	ALTIMETER PRESSURE	AEROSONIC
AAU-28/A	6610-00-459-4578	ALTIMETER, PRESSURE	KOLLSMAN
AAU28A	6610-00-459-4578	ALTIMETER, PRESSURE	KOLLSMAN
AAU-34/A	6610-01-016-1583	ALTIMETER, SERVO CONTROLLED	KOLLSMAN
AAU34A	6610-01-016-1583	ALTIMETER, SERVO CONTROLLED	KOLLSMAN
AAU-3A/A	6685-00-226-5700	ALTIMETER, CABIN	AEROSONIC
ABU11A	6645-00-076-3050	CLOCK, MECHANICAL, PANEL	WALTHAM AIRCRAFT CLOCK
ABU-8A/A	6610-01-391-9062	ACCELEROMETER, MECHANICAL	Q.E.D.
ABU8AA	6610-01-391-9062	ACCELEROMETER, MECHANICAL	Q.E.D.
ABU9A	6645-00-588-7611	CLOCK, MECHANICAL, PANEL	WAKMANN WATCH
ABU9A1	6645-00-793-5794	CLOCK, MECHANICAL, PANEL	WALTHAM AIRCRAFT CLOCK

AC1061P	6685-00-514-5061	INDICATOR, PRESSURE	STRUBE
AC106-1P	6685-00-514-5061	INDICATOR, PRESSURE	STRUBE
AC106IP	6685-00-514-5061	INDICATOR, PRESSURE	STRUBE
AC25C	6130-01-539-5316	CONDITIONER, CHARGER	MULTI POWER PRODUCTS
ACA3101-1L	1680-00-671-3837	SEAT, AIRCRAFT, TROOPS	ORO MANUFACTURING
ACA3101-1R	1680-00-671-2101	SEAT, AIRCRAFT, TROOPS	ORO MANUFACTURING
ACA3101-20	1680-00-782-5861	SEAT, AIRCRAFT, TROOPS	ORO MANUFACTURING
ACA3101-20L	1680-00-913-4840	SEAT, AIRCRAFT, TROOPS	ORO MANUFACTURING
ACA3101-20R	1680-00-913-4841	SEAT, AIRCRAFT, TROOPS	ORO MANUFACTURING
ADC-81A		AIR DATA COMPUTER	ROCKWELL COLLINS
ADC-82A	6610-01-345-1256	AIR DATA COMPUTER	ROCKWELL COLLINS
ADC-82C	7021-MD-017-8134	AIR DATA COMPUTER	ROCKWELL COLLINS
ADC-82L		AIR DATA COMPUTER	ROCKWELL COLLINS
ADF-60A		RECEIVER, ADF	ROCKWELL COLLINS
ADF-60B	5826-01-125-1023	RECEIVER, ADF	ROCKWELL COLLINS
ADI-55V		INDICATOR, ATTITUDE DIRECTOR	ROCKWELL COLLINS
AE111-002-99	5945-00-628-6484	RELAY, HYBRID	DARE ELECTRONICS
AE149-016-99	1660-01-130-4645	CONTROL BOX, TEMPERATURE	DARE ELECTRONICS
AEU-13/A	6620-01-172-6946	INDICATOR, TORQUEMETER	PARKER-HANNIFIN
AF200	6685-00-514-5061	INDICATOR, PRESSURE	AEROSONIC
AF200A	6685-00-514-5061	INDICATOR, PRESSURE	AEROSONIC
AF200AW	6685-00-514-5061	INDICATOR, PRESSURE	AEROSONIC
AF200AW1	6685-00-514-5061	INDICATOR, PRESSURE	AEROSONIC
AHC-85	5895-01-289-5799	COMPUTER, HEADING	ROCKWELL COLLINS
ALT-55B	5841-01-272-2715	ALTIMETER SET, ELECTRONIC	ROCKWELL COLLINS
ALU-8521	2925-01-482-5966	ALTERNATOR, CURRENT	HARTZELL ENGINE TECHNOLOGIES
ALU-8521LS	2925-MD-003-3416	ALTERNATOR, CURRENT (24V 70A)	HARTZELL ENGINE TECHNOLOGIES
ALU-8521R	2925-01-482-5967	ALTERNATOR, CURRENT	HARTZELL ENGINE TECHNOLOGIES
ALU-8521RS	2925-MD-003-3416	ALTERNATOR, CURRENT	HARTZELL ENGINE TECHNOLOGIES
AM1963	5996-00-623-2912	AMPLIFIER, INTERCOMMUNICATION SET	ANDREA SYSTEMS
AM-1963	5996-00-623-2912	AMPLIFIER, INTERCOMMUNICATION SET	ANDREA SYSTEMS
AM1963/AIC	5996-00-623-2912	AMPLIFIER, INTERCOMMUNICATION SET	ANDREA SYSTEMS
AM-1963/AIC	5996-00-623-2912	AMPLIFIER, INTERCOMMUNICATION SET	ANDREA SYSTEMS
AM1963/AIC18	5996-00-623-2912	AMPLIFIER, INTERCOMMUNICATION SET	ANDREA SYSTEMS
AM1963/AIC-18	5996-00-623-2912	AMPLIFIER, INTERCOMMUNICATION SET	ANDREA SYSTEMS
AM-1963/AIC-18	5996-00-623-2912	AMPLIFIER, INTERCOMMUNICATION SET	ANDREA SYSTEMS
AM1963AIC	5996-00-623-2912	AMPLIFIER, INTERCOMMUNICATION SET	ANDREA SYSTEMS
AM1963AIC18	5996-00-623-2912	AMPLIFIER, INTERCOMMUNICATION SET	ANDREA SYSTEMS
AM-203/ARA-19	5996-00-546-4902	AMPLIFIER, ELECTRONIC CONTROL	JOINT ELECTRONICS
AM-203/ARA-19NA	5996-00-610-2055	AMPLIFIER, ELECTRONIC CONTROL	JOINT ELECTRONICS
AM-203A/ARA-19	5996-00-556-2479	AMPLIFIER, ELECTRONIC CONTROL	JOINT ELECTRONICS
AM203AARA19	5996-00-556-2479	AMPLIFIER, ELECTRONIC CONTROL	JOINT ELECTRONICS
AM203ARA19	5996-00-546-4902	AMPLIFIER, ELECTRONIC CONTROL	JOINT ELECTRONICS
AM203ARA19NA	5996-00-610-2055	AMPLIFIER, ELECTRONIC CONTROL	JOINT ELECTRONICS
AM-203B/ARA-19	5996-00-505-1016	AMPLIFIER, ELECTRONIC CONTROL	JOINT ELECTRONICS
AM203BARA19	5996-00-505-1016	AMPLIFIER, ELECTRONIC CONTROL	JOINT ELECTRONICS
AM-203C/ARA-19	5996-00-507-1381	AMPLIFIER, ELECTRONIC CONTROL	JOINT ELECTRONICS
AM203CARA19	5996-00-507-1381	AMPLIFIER, ELECTRONIC CONTROL	JOINT ELECTRONICS
AM2B6-6	2910-01-143-0195	PUMP, FUEL, ELECTRICAL	PARKER HANNIFIN
AM-4535/ASQ-81(V)	5895-00-168-3590	AMPLIFIER, POWER SUPPLY	RAYTHEON
AM4923/A	5996-00-358-1724	AMPLIFIER, ELECTRONIC CONTROL	KEARFOTT
AM-4923/A	5996-00-358-1724	AMPLIFIER, ELECTRONIC CONTROL	KEARFOTT
AM4923A	5996-00-358-1724	AMPLIFIER, ELECTRONIC CONTROL	KEARFOTT

AM-53/APN59	5996-00-805-7621	AMPLIFIER, ELECTRONIC CONTROL, RADAR	NORTHROP GRUMMAN SYSTEMS
AM853/APN59	5996-00-346-4744	AMPLIFIER, ELECTRONIC CONTROL, RADAR	NORTHROP GRUMMAN SYSTEMS
AM-853/APN-59	5996-00-346-4744	AMPLIFIER, ELECTRONIC CONTROL, RADAR	NORTHROP GRUMMAN SYSTEMS
AM-944/AIC-13	5996-00-543-1423	AMPLIFIER, AUDIO FREQUENCY	RANDAM ELECTRONICS
AN/AIC-13	5831-00-116-6502	PUBLIC ADDRESS SET AN/AIC-13	RANDAM ELECTRONICS
AN/APN-141(V)	5841-00-192-2831	ALTIMETER SET, ELECTRONIC	ALLIED SIGNAL
AN/APN-59E(V)	5841-01-053-5763	RADAR SET	NORTHROP GRUMMAN SYSTEMS
AN/APN59EV	5841-01-053-5763	RADAR SET	NORTHROP GRUMMAN SYSTEMS
AN/APQ107	5841-00-900-8081	WARNING SET, RADIO ALTIMETER (RAWS)	PRECISION AEROSPACE
AN/APX-72	5841-00-089-7179	TRANSCEIVER, RADAR	RAYTHEON
AN/ARC159	5821-00-100-7931	TRANSCEIVER, UHF, RADIO	ROCKWELL COLLINS
AN/PRC-90	5820-00-782-5308	RADIO SET	GENERAL DYNAMICS MISSION SYSTEMS
AN3089-10	5850-00-729-1595	LIGHT, SIGNAL	GRIMES AEROSPACE
AN3203V30	6625-00-235-4782	VOLTMETER, D/C	WESTON ELECTRICAL INSTRUMENT
AN5547-2		GENERATOR, TACHOMETER	AMETEK
AN5732-1		COMPASS, MAGNETIC, MOUNTED	KOLLSMAN
AN5733-1	6605-00-239-8206	COMPASS, MAGNETIC, MOUNTED	HONEYWELL AEROSPATIALE
AN5733-2	6605-00-239-8205	COMPASS, MAGNETIC, MOUNTED	KOLLSMAN
AN5733T2	6605-00-663-8514	COMPASS, GYROMAGNETIC	AIRPATH
AN5743-1A	6645-00-950-8599	CLOCK, MECHANICAL, PANEL	WALTHAM AIRCRAFT CLOCK
AN5743T1A	6645-00-950-8599	CLOCK, MECHANICAL, PANEL	WALTHAM AIRCRAFT CLOCK
AN5760L4B	6610-00-663-7740	ALTIMETER, PRESSURE	KOLLSMAN
AN5766-2	6605-00-514-5746	COMPASS, MAGNETIC, MOUNTED	HONEYWELL INTERNATIONAL
AN5766-4	6605-00-526-7252	COMPASS, MAGNETIC, MOUNTED	KOLLSMAN
AN5766T4	6605-00-551-8187	COMPASS, MAGNETIC, MOUNTED	HONEYWELL INTERNATIONAL
AN5773-1	6620-00-189-2381	INDICATOR, TRIPLE	LIFTEC
AN5787-1	6610-00-530-0961	TRANSMITTER, POSITION	SIMMONDS PRECISION PRODUCTS
AN5791-1	6685-00-557-0372	INDICATOR, TEMPERATURE, ELECTRICAL RESISTANCE	HORIZON AEROSPACE
AN5839-1	6695-00-628-8990	INDICATOR, POSITION	AMETEK
AN5839-2	6695-00-628-8990	INDICATOR, POSITION	AMETEK
AN6011-2	6685-00-854-8362	INDICATOR, OXYGEN, PRESSURE	AMETEK
AN6281-8-10	1650-00-815-2499	FUSE, HYDRAULIC SYSTEM	PARKER-HANNIFIN
ANT-1T		TRANSCEIVER, WEATHER, RADAR	HONEYWELL INTERNATIONAL
ANT-1TB		ANTENNA, WEATHER, RADAR	HONEYWELL INTERNATIONAL
ANT-1TB(M)		ANTENNA, WEATHER, RADAR	HONEYWELL INTERNATIONAL
ANT-60A		ANTENNA, ADF	ROCKWELL COLLINS
ANT-60B		ANTENNA, ADF	ROCKWELL COLLINS
APP-85		SELECT PANEL, AUTO-PILOT MODE	ROCKWELL COLLINS
APP-85A		SELECT PANEL, AUTO-PILOT MODE	ROCKWELL COLLINS
APP-85D		SELECT PANEL, AUTO-PILOT MODE	ROCKWELL COLLINS
AQU-2/A	6605-00-034-2500	INDICATOR, HORIZONTAL SITUATION	ASTRONAUTICS
AQU-3/A	6605-00-815-1903	COMPASS, MAGNETIC	G T A
ART-2000		RADAR, WEATHER	HONEYWELL INTERNATIONAL
ARU-2B/A	6610-00-068-3464	INDICATOR, ATTITUDE DIRECTOR	GE AVIATION SYSTEMS
ARU-42/A-1	6610-00-200-8832	INDICATOR, VERTICAL VELOCITY	L3 AVIATION PRODUCTS
ARU-50/A	6610-01-092-9846	INDICATOR, ATTITUDE DIRECTOR	MOOG
ARU-56/A	6610-01-040-4430	INDICATOR, ANGLE OF ATTACK	PARKER-HANNIFIN
AS-1199B/APN-59	5985-01-282-7892	ANTENNA, RADAR	NORTHROP GRUMMAN SYSTEMS
AS1199BAPN59	5985-01-282-7892	ANTENNA, RADAR	NORTHROP GRUMMAN SYSTEMS
AS-1863/ARN-83	5985-00-985-9173	ANTENNA, LOOP, ADF	ROCKWELL COLLINS
AS1863ARN83	5985-00-985-9173	ANTENNA, LOOP, ADF	ROCKWELL COLLINS
AS-313A/ARN-6	5985-00-217-0463	ANTENNA, LOOP	KEARFOTT
AS313AARN6	5985-00-217-0463	ANTENNA, LOOP	KEARFOTT

AS-313B/ARN-6	5985-00-149-1451	ANTENNA, LOOP	KEARFOTT
AS313BARN6	5985-00-149-1451	ANTENNA, LOOP	KEARFOTT
AS-3440/APS-133V	5985-01-089-0737	ANTENNA, WEATHER, RADAR	HONEYWELL INTERNATIONAL
AS-3440A/APS-133(V)	5985-01-194-2321	ANTENNA, WEATHER, RADAR	HONEYWELL INTERNATIONAL
AS5604	6605-00-551-8187	COMPASS, MAGNETIC, MOUNTED	HONEYWELL INTERNATIONAL
AT-256A/ARC	5985-00-217-0457	ANTENNA, UHF, BLADE	EDO
AT256AARC	5985-01-522-7880	ANTENNA, UHF, BLADE	EDO
AT-740/A	5985-00-673-5831	ANTENNA, DME/TACAN, BEACON	L3 TECHNOLOGIES
AT741B/A	5985-00-106-0906	ANTENNA	EDO
AT-741B/A	5985-00-106-0906	ANTENNA	EDO
AT741B/B	5985-00-106-0906	ANTENNA	EDO
AT-741B/B	5985-00-106-0906	ANTENNA	EDO
ATC2000	5895-12-322-8156	TRANSCEIVER, IFF	BECKER AVIONICS
AV16B1450D	2915-00-632-7932	VALVE, FUEL SYSTEM, GATE	ITT AEROSPACE CONTROLS
AV16B-1450D	2915-00-632-7932	VALVE, FUEL SYSTEM, GATE	ITT AEROSPACE CONTROLS
AV16B1467D	2915-00-632-7932	VALVE, FUEL SYSTEM, GATE	ITT AEROSPACE CONTROLS
AV16B-1467D	2915-00-632-7932	VALVE, FUEL SYSTEM, GATE	ITT AEROSPACE CONTROLS
AV16B1824	2915-00-983-9306	VALVE, FUEL SYSTEM, GATE	ITT AEROSPACE CONTROLS
AV16B-1824	2915-00-983-9306	VALVE, FUEL SYSTEM, GATE	ITT AEROSPACE CONTROLS
AV16B1873C	4810-01-015-1979	VALVE, FUEL SYSTEM, GATE	ITT AEROSPACE CONTROLS
AV16B-1873C	4810-01-015-1979	VALVE, FUEL SYSTEM, GATE	ITT AEROSPACE CONTROLS
AV16B1874D	4810-01-015-1980	VALVE, FUEL SYSTEM, GATE	ITT AEROSPACE CONTROLS
AV16B-1874D	4810-01-015-1980	VALVE, FUEL SYSTEM, GATE	ITT AEROSPACE CONTROLS
AV16E1131B	2915-00-887-1904	VALVE, FUEL SYSTEM, GATE	ITT AEROSPACE CONTROLS
AV16E-1131B	2915-00-887-1904	VALVE, FUEL SYSTEM, GATE	ITT AEROSPACE CONTROLS
AV19E1003-1	4810-01-123-7254	VALVE, FLUID PRESSURE, REGULATING	ITT AEROSPACE CONTROLS
AV8A	5975-01-242-9549	MOUNTING BASE, TACAN, TRANSCEIVER	ROCKWELL COLLINS
AV8C	5975-01-256-7216	MOUNTING BASE, TACAN, TRANSCEIVER	ROCKWELL COLLINS
AVK-13/A24G-9	6610-00-991-0770	INDICATOR, TRUE AIR SPEED	HONEYWELL INTERNATIONAL
AVU-8B/A	6610-01-109-4841	INDICATOR, MACH AND TRUE AIR SPEED	CARLETON LIFE SUPPORT SYSTEMS
AVU-8C/A	6610-01-263-2409	INDICATOR, AIRSPEED/MACH	AEROSONIC
AW-1-7/8-27-E	6685-00-854-8362	INDICATOR, OXYGEN, PRESSURE	AMETEK
AW-1-7/8-27-E4	6685-00-854-8362	INDICATOR, OXYGEN, PRESSURE	AMETEK
AW17-8-14EL	6685-00-726-2538	GAGE, PRESSURE, DIAL INDICATING	AMETEK
AW-1-7-8-27-E	6685-00-854-8362	INDICATOR, OXYGEN, PRESSURE	AMETEK
AW-1-7-8-27-E4	6685-00-854-8362	INDICATOR, OXYGEN, PRESSURE	AMETEK
AW1833AB01	6685-00-514-5061	INDICATOR, PRESSURE	AMETEK
AW1833AC01	6685-00-514-5061	INDICATOR, PRESSURE	AMETEK
AW2017AC07	6685-00-387-4325	GAGE, PRESSURE, DIAL INDICATING	AMETEK
AW2-33A1	6685-00-887-6812	GAGE, DIFFERENTIAL, DIAL INDICATING	AMETEK
AXIMAX3-1140YH	4140-01-041-4886	FAN, VANE, AXIAL	ROTRON
AXIMAX3-1140YS	4140-01-041-4886	FAN, VANE, AXIAL	ROTRON
AXIMMAX3-1140YS	4140-01-041-4886	FAN, VANE, AXIAL	AMETEK ROTRON
AYLF50677	1660-00-595-7773	SENSOR, CABIN TEMPERATURE	GE AVIATION SYSTEMS
AYLF50679	1660-00-583-7106	SENSOR, DUCT, OVERHEAT	GE AVIATION SYSTEMS
B-00368-5	6110-01-217-7932	CONTROL, ALTERNATOR, VOLTAGE	LAMAR TECHNOLOGIES
B123B	5945-00-675-7413	RELAY, ELECTROMAGNETIC	TE CONNECTIVITY
B-123B	5945-00-675-7413	RELAY, ELECTROMAGNETIC	TE CONNECTIVITY
B123J	5945-00-675-7413	RELAY, ELECTROMAGNETIC	TE CONNECTIVITY
B-123J	5945-00-675-7413	RELAY, ELECTROMAGNETIC	TE CONNECTIVITY
B123JA	5945-01-250-9675	RELAY, ELECTROMAGNETIC	TE CONNECTIVITY
B-123JA	5945-01-250-9675	RELAY, ELECTROMAGNETIC	TE CONNECTIVITY
B-124C		RELAY, ELECTROMAGNETIC	TE CONNECTIVITY

B-124K	5945-00-675-7412	RELAY, ELECTROMAGNETIC	TE CONNECTIVITY
B13		CLOCK, MECHANICAL, PANEL	THOMMEN AIRCRAFT EQUIPMENT
B-16		COMPASS, MAGNETIC, MOUNTED	WAKMANN WATCH
B-17		COMPASS, MAGNETIC, MOUNTED	HONEYWELL AEROSPATIALE
B18		CLOCK, MECHANICAL, PANEL	THOMMEN AIRCRAFT EQUIPMENT
B2516B10	5850-00-729-1595	LIGHT, SIGNAL	GRIMES AEROSPACE
B-2516B-10	5850-00-729-1595	LIGHT, SIGNAL	GRIMES AEROSPACE
B2888-01	6615-00-857-0828	GYROSCOPE, RATE OF TURN	KELLY MANUFACTURING
B2888-02	6615-00-869-0825	GYROSCOPE, RATE OF TURN	KELLY MANUFACTURING
B2888-1	6615-00-857-0828	GYROSCOPE, RATE OF TURN	KELLY MANUFACTURING
B2888-2	6615-00-869-0825	GYROSCOPE, RATE OF TURN	KELLY MANUFACTURING
B4423210101	6610-00-459-4578	ALTIMETER, PRESSURE	KOLLSMAN
B45152-10-004		ALTIMETER, ENCODER	KOLLSMAN
B45152-10-005		ALTIMETER, ENCODER	KOLLSMAN
B45152-10-009	6610-01-107-2658	ALTIMETER, ENCODER	KOLLSMAN
B4515210102		ALTIMETER, PRESSURE	KOLLSMAN
B4515210103	6610-01-038-2122	ALTIMETER, PRESSURE	KOLLSMAN
B459	5945-01-384-4323	RELAY, ELECTROMAGNETIC	TE CONNECTIVITY
B-459	5945-01-384-4323	GENERATOR CONTACTOR/MECHANICAL	TE CONNECTIVITY
B459A	5945-01-250-9675	RELAY, ELECTROMAGNETIC	TE CONNECTIVITY
B-459A	5945-01-250-9675	GENERATOR CONTACTOR/MECHANICAL	TE CONNECTIVITY
B-460	5945-00-675-7412	RELAY, ELECTROMAGNETIC	TE CONNECTIVITY
B549-1	6610-00-515-4600	INDICATOR, FLAP, POSITION	SIMMONDS PRECISION PRODUCTS
B709-1	6620-00-075-5861	INDICATOR, TORQUEMETER	SIMMONDS PRECISION PRODUCTS
B709-4	6620-00-928-0216	INDICATOR, TORQUEMETER	SIMMONDS PRECISION PRODUCTS
B709-7	6620-00-151-5363	INDICATOR, TORQUEMETER	SIMMONDS PRECISION PRODUCTS
B709-7A	6620-00-151-5363	INDICATOR, TORQUEMETER	SIMMONDS PRECISION PRODUCTS
B709-7J	6620-00-148-7313	INDICATOR, TORQUEMETER	SIMMONDS PRECISION PRODUCTS
BB-620/URT-26(V)	6130-00-927-0415	BATTERY, POWER SUPPLY	DRS TECHNOLOGIES
BTI600-102A-1		INDICATOR, BATTERY TEMPERATURE	TRAMM
BTI600-105A	6625-01-314-6239	INDICATOR, BATTERY TEMPERATURE	TRAMM
BTI600-200A	5996-01-304-3714	INDICATOR, BATTERY TEMPERATURE	TRAMM
BTI600-200A-1	6685-01-473-8187	INDICATOR, BATTERY TEMPERATURE	TRAMM
BTI600-202	6685-01-307-2580	INDICATOR, BATTERY TEMPERATURE	TRAMM
BTI600-202M	6685-01-356-7401	INDICATOR, BATTERY TEMPERATURE	TRAMM
BTI600-202M-1	6685-01-356-7401	INDICATOR, BATTERY TEMPERATURE	TRAMM
BTI600-2A	6685-01-097-6324	INDICATOR, BATTERY TEMPERATURE	TRAMM
BTI600-3A	6685-01-157-0423	INDICATOR, BATTERY TEMPERATURE	TRAMM
BTI600-4A	6685-01-204-8987	INDICATOR, BATTERY TEMPERATURE	TRAMM
BYLB50494-10	4810-01-082-7207	VALVE, BUTTERFLY	GE AVIATION SYSTEMS
BYLB50494-11	4810-01-152-5662	VALVE, BUTTERFLY	GE AVIATION SYSTEMS
BYLB50495	4810-01-082-7208	VALVE, BUTTERFLY	GE AVIATION SYSTEMS
BYLB50495-1	4810-01-142-8229	VALVE, BUTTERFLY	GE AVIATION SYSTEMS
BYLB50496	4810-01-085-7038	VALVE, BUTTERFLY	GE AVIATION SYSTEMS
BYLB51044	4810-01-218-2643	VALVE, TEMPERATURE CONTROL, BUTTERFLY	GE AVIATION SYSTEMS
BYLB51045	4810-01-219-3417	VALVE, TEMPERATURE CONTROL, BUTTERFLY	GE AVIATION SYSTEMS
BYLB7520	4810-00-566-0332	VALVE, CROSS, SOLENOID	GE AVIATION SYSTEMS
BYLB7520-1	4810-01-646-9761	VALVE, CROSS, SOLENOID	GE AVIATION SYSTEMS
C-10056/A	5895-01-012-1920	CONTROL PANEL, TACAN, TRANSCEIVER	ROCKWELL COLLINS
C-10057/A	5895-01-012-7084	CONTROL PANEL, TACAN, TRANSCEIVER	ROCKWELL COLLINS
C-10058/A	5895-01-012-7085	CONTROL PANEL, TACAN, TRANSCEIVER	ROCKWELL COLLINS
C10060/ARN	5895-01-079-7568	CONTROL PANEL, TACAN, TRANSCEIVER	ROCKWELL COLLINS
C-10061/A	5895-01-014-3656	CONTROL PANEL, TACAN, TRANSCEIVER	ROCKWELL COLLINS

C-10062/A	5895-01-018-3511	CONTROL PANEL, TACAN, TRANSCEIVER	ROCKWELL COLLINS
C-11840/ARN-118(V)	5826-01-251-1148	CONTROL PANEL, TACAN, TRANSCEIVER	ROCKWELL COLLINS
C1242/APN59	5841-00-804-7159	CONTROL PANEL, RADAR SET	NORTHROP GRUMMAN SYSTEMS
C-1242/APN-59	5841-00-804-7159	CONTROL PANEL, RADAR SET	NORTHROP GRUMMAN SYSTEMS
C-149/ARN-6	5895-00-247-3004	CONTROL BOX, RECEIVER	BAE SYSTEMS
C-149A/ARN-6	5895-00-228-3133	CONTROL BOX, RECEIVER	RAYTHEON
C149AARN6	5895-00-228-3133	CONTROL BOX, RECEIVER	RAYTHEON
C149ARN6	5895-00-247-3004	CONTROL BOX, RECEIVER	BAE SYSTEMS
C-1513/A	5826-00-535-6629	CONTROL PANEL, DIRECTION FINDER	PHILIPS ELECTRONIC INSTRUMENTS
C-1513/ARN-6	5826-00-535-6629	CONTROL PANEL, DIRECTION FINDER	PHILIPS ELECTRONIC INSTRUMENTS
C1513A	5826-00-535-6629	CONTROL PANEL, DIRECTION FINDER	PHILIPS ELECTRONIC INSTRUMENTS
C-1614/AIC13	5831-00-106-2733	CONTROL, PUBLIC ADDRESS SET	RANDAM ELECTRONICS
C19A513	4140-00-564-5980	FAN, CENTRIFUGAL	GLOBE MOTORS
C2105/AIC18	5831-00-872-6835	STATION, INTERCOMMUNICATION SET	ANDREA SYSTEMS
C-2105/AIC-18	5831-00-872-6835	STATION, INTERCOMMUNICATION SET	ANDREA SYSTEMS
C2105AIC18	5831-00-872-6835	STATION, INTERCOMMUNICATION SET	ANDREA SYSTEMS
C2106/AIC18	5831-00-809-3180	CONTROL, INTERCOMMUNICATION SET	ANDREA SYSTEMS
C2106/AIC-18	5831-00-809-3180	CONTROL, INTERCOMMUNICATION SET	ANDREA SYSTEMS
C-2106/AIC-18	5831-00-809-3180	CONTROL, INTERCOMMUNICATION SET	ANDREA SYSTEMS
C2300	6605-00-239-8209	COMPASS, GYROMAGNETIC	AIRPATH
C2300D	6605-00-239-8210	COMPASS, GYROMAGNETIC	AIRPATH
C2302/APN59	5841-00-659-4304	CONTROL PANEL, SYNCHRONIZER	NORTHROP GRUMMAN SYSTEMS
C-2302/APN-59	5841-00-659-4304	CONTROL PANEL, SYNCHRONIZER	NORTHROP GRUMMAN SYSTEMS
C2323/AIC	5831-00-808-9796	CONTROL, INTERCOMMUNICATION SET	ANDREA SYSTEMS
C-2323/AIC	5831-00-808-9796	CONTROL, INTERCOMMUNICATION SET	ANDREA SYSTEMS
C2323A/AIC	5831-00-901-3781	CONTROL, INTERCOMMUNICATION SET	ANDREA SYSTEMS
C-2323A/AIC	5831-00-901-3781	CONTROL, INTERCOMMUNICATION SET	ANDREA SYSTEMS
C2323A81-59-AIC	5831-00-539-1471	CONTROL, INTERCOMMUNICATION SET	ANDREA SYSTEMS
C2323AAIC	5831-00-901-3781	CONTROL, INTERCOMMUNICATION SET	ANDREA SYSTEMS
C2323AIC	5831-00-808-9796	CONTROL, INTERCOMMUNICATION SET	ANDREA SYSTEMS
C2350DL4CM	6605-01-141-7035	COMPASS, GYROMAGNETIC	AIRPATH
C2350L4-M23	6605-01-141-7035	COMPASS, GYROMAGNETIC	AIRPATH
C25C	6130-01-539-5316	CONDITIONER, CHARGER	LAMAR TECHNOLOGIES
C2A	6605-00-526-7251	COMPASS, MAGNETIC, MOUNTED	AMETEK
C2C	6605-00-857-9978	COMPASS, MAGNETIC, MOUNTED	AMETEK
C3236K13	6680-00-920-9213	GENERATOR, TACHOMETER	AMETEK
C3435210006	6610-01-046-4844	INDICATOR, MACH AND TRUE AIR SPEED	KOLLSMAN
C3814/ARC89(V)	5831-00-884-3604	CONTROL, INTERCOMMUNICATION SET	ANDREA SYSTEMS
C-3814/ARC-89(V)	5831-00-884-3604	CONTROL, INTERCOMMUNICATION SET	ANDREA SYSTEMS
C3814ARC89V	5831-00-884-3604	CONTROL, INTERCOMMUNICATION SET	ANDREA SYSTEMS
C3815/ARC89(V)	5831-00-884-3611	CONTROL, INTERCOMMUNICATION SET	ANDREA SYSTEMS
C-3815/ARC-89(V)	5831-00-884-3611	CONTROL, INTERCOMMUNICATION SET	ANDREA SYSTEMS
C3815ARC89V	5831-00-884-3611	CONTROL, INTERCOMMUNICATION SET	ANDREA SYSTEMS
C3939/APN59	6110-00-984-1438	CONTROL PANEL, GENERATOR	NORTHROP GRUMMAN SYSTEMS
C-3939/APN-59	6110-00-984-1438	CONTROL PANEL, GENERATOR	NORTHROP GRUMMAN SYSTEMS
C3942(P)/AIC18	5831-00-523-5328	CONTROL, INTERCOMMUNICATION SET	ANDREA SYSTEMS
C-3942(P)/AIC-18	5831-00-523-5328	CONTROL, INTERCOMMUNICATION SET	ANDREA SYSTEMS
C3942PAIC18	5831-00-523-5328	CONTROL, INTERCOMMUNICATION SET	ANDREA SYSTEMS
C3943(P)/AIC	5895-00-060-9857	CONTROL, INTERCOMMUNICATION SET	ANDREA SYSTEMS
C-3943(P)/AIC	5895-00-060-9857	CONTROL, INTERCOMMUNICATION SET	ANDREA SYSTEMS
C3943PAIC	5895-00-060-9857	CONTROL, INTERCOMMUNICATION SET	ANDREA SYSTEMS
C-4006(P)/APN-59	5985-01-371-9021	CONTROL PANEL, ANTENNA	NORTHROP GRUMMAN SYSTEMS
C-4006(P)/APN-59B	5985-01-371-9021	CONTROL PANEL, ANTENNA	NORTHROP GRUMMAN SYSTEMS

C4006P/APN59	5985-01-371-9021	CONTROL PANEL, ANTENNA	NORTHROP GRUMMAN SYSTEMS
C4006P/APN59B	5985-01-371-9021	CONTROL PANEL, ANTENNA	NORTHROP GRUMMAN SYSTEMS
C406-N	5821-01-561-9503	TRANSMITTER, EMERGENCY LOCATOR (ELT)	ARTEX
C406-NHM		TRANSMITTER, EMERGENCY LOCATOR (ELT)	ARTEX
C4154210003	6610-00-405-6461	ALTIMETER, ENCODER	KOLLSMAN
C52C22	4810-00-670-1111	VALVE, BUTTERFLY	GRIMES AEROSPACE
C6567/AIC25	5831-00-880-2834	CONTROL, INTERCOMMUNICATION SET	ANDREA ELECTRONICS
C-6567/AIC-25	5831-00-880-2834	CONTROL, INTERCOMMUNICATION SET	ANDREA ELECTRONICS
C661015-0102	6610-MD-016-3666	ACCELEROMETER, MECHANICAL	CESSNA
C7041-1	1680-00-088-6102	ACTUATOR, ELECTRO-MECHANICAL, LINEAR	CEF INDUSTRIES
C7041-2	1680-00-981-7652	ACTUATOR, ELECTRO-MECHANICAL, LINEAR	CEF INDUSTRIES
C7088-1A	1680-00-789-9345	GEAR BOX ASSYFLAP DRIVEMOTOR DRIVEN	CEF INDUSTRIES
C7157	5831-00-078-4971	CONTROL, INTERCOMMUNICATION SET	CEF INDUSTRIES
C-9603/A	5895-01-012-1919	CONTROL PANEL, TACAN, TRANSCEIVER	ROCKWELL COLLINS
CB1000	6605-00-239-8204	COMPASS, GYROMAGNETIC	AIRPATH
CB1100	6605-00-663-8514	COMPASS, GYROMAGNETIC	AIRPATH
CB2100	6605-00-663-8526	COMPASS, GYROMAGNETIC	AIRPATH
CB2100-2	6605-00-557-5673	COMPASS, GYROMAGNETIC	AIRPATH
CB2100-3	6605-00-663-5621	COMPASS, GYROMAGNETIC	AIRPATH
CB2100-4	6605-00-551-8187	COMPASS, GYROMAGNETIC	AIRPATH
CB2100M	6605-00-663-5619	COMPASS, GYROMAGNETIC	AIRPATH
CB2100T4	6605-00-663-5637	COMPASS, GYROMAGNETIC	AIRPATH
CB-2100-T4	6605-00-551-8187	COMPASS, GYROMAGNETIC	AIRPATH
CB2100T4A	6605-00-551-8187	COMPASS, GYROMAGNETIC	AIRPATH
CB-2100-T4A	6605-01-647-9175	COMPASS, GYROMAGNETIC	AIRPATH
CB-2100-T4-A	6605-00-551-8187	COMPASS, GYROMAGNETIC	AIRPATH
CB-2125-5	6605-00-815-1903	COMPASS, MAGNETIC	G T A
CB2125T5	6605-00-815-1903	COMPASS, MAGNETIC	G T A
CG12313	5930-00-965-7111	SWITCH, FUEL FILTER, PRESSURE	UNISON INDUSTRIES
CG12313A	5930-00-965-7111	SWITCH, FUEL FILTER, PRESSURE	UNISON INDUSTRIES
CG12313B	5930-00-965-7111	SWITCH, FUEL FILTER, PRESSURE	UNISON INDUSTRIES
CG12313C	5930-00-965-7111	SWITCH, FUEL FILTER, PRESSURE	UNISON INDUSTRIES
CG12313D	5930-00-965-7111	SWITCH, FUEL FILTER, PRESSURE	UNISON INDUSTRIES
CG12313E	5930-00-965-7111	SWITCH, FUEL FILTER, PRESSURE	UNISON INDUSTRIES
CG12313F	5930-00-965-7111	SWITCH, FUEL FILTER, PRESSURE	UNISON INDUSTRIES
CG12313G	5930-00-965-7111	SWITCH, FUEL FILTER, PRESSURE	UNISON INDUSTRIES
CH-26	5945-00-728-3191	RELAY, ELECTROMAGNETIC	TE CONNECTIVITY
CLABU9A1	6645-00-793-5794	CLOCK, MECHANICAL, PANEL	WALTHAM AIRCRAFT CLOCK
CN-1386/AJB-3A	6615-00-181-1879	GYROSCOPE, SWITCHING RATE	GE AVIATION SYSTEMS
CN221A/APN59	5841-00-845-4243	GENERATOR, RADAR, STABILIZATION DATA	NORTHROP GRUMMAN SYSTEMS
CN-221A/APN-59	5841-00-845-4243	GENERATOR, RADAR, STABILIZATION DATA	NORTHROP GRUMMAN SYSTEMS
CN-495A/AJB-3	6615-00-880-5033	GYROSCOPE, SWITCHING RATE	GE AVIATION SYSTEMS
CP1AAU3A12	6685-00-226-5700	ALTIMETER, CABIN	AEROSONIC
CP2323AD01	5821-MD-038-6393	CONTROL PANEL, AUDIO	TEAM
CP2367L02	5831-MD-010-3134	PANEL, AUDIO, SELECTOR	TEAM
CPK-28/A24G-9	6610-00-759-7170	COMPUTER, TRUE AIR SPEED	HONEYWELL INTERNATIONAL
CPK-281A24G-9	6610-00-759-7170	COMPUTER, TRUE AIR SPEED	HONEYWELL INTERNATIONAL
CPU-65/A	6610-00-763-2415	COMPUTER, FLIGHT DIRECTOR	ROCKWELL COLLINS
CU1658A	5985-00-852-0457	COUPLER, ANTENNA	ROCKWELL COLLINS
CU1669GRC	5985-00-939-7495	COUPLER, ANTENNA	ROCKWELL COLLINS
CU-2275(V)2	5985-01-151-5848	COUPLER, ANTENNA	ROCKWELL COLLINS
CU-65/ARN-6	5826-00-521-0571	COUPLING, ANTENNA	RAYTHEON
CU-65A/ARN-6	5826-00-342-1964	COUPLING, ANTENNA	RAYTHEON

CU65AARN6	5826-00-342-1964	COUPLING, ANTENNA	RAYTHEON
CU65ARN6	5826-00-521-0571	COUPLING, ANTENNA	RAYTHEON
CYLB51055	4820-00-006-5087	VALVE, ENGINE, BLEED AIR, CHECK	GE AVIATION SYSTEMS
D-12		COMPASS, MAGNETIC, MOUNTED	KILGORE
D125140HB-5	6105-00-683-0353	MOTOR, DIRECT CURRENT	HONEYWELL AEROSPATIALE
D125140HB-5A	6105-00-683-0353	MOTOR, DIRECT CURRENT	KILGORE
D2120-4	1680-01-070-1508	ACTUATOR, ELECTRO-MECHANICAL, ROTARY	EATON AEROSPACE
D3851-56280	6610-00-467-7152	TRANSMITTER, ANGLE OF ATTACK	RAYTHEON
D424D1	5826-00-611-0951	MOUNTING BASE	AEROSONIC
D5725	3010-00-635-4730	POWER UNIT & GEARCASE, LIGHT	SIMMONDS PRECISION PRODUCTS
DDA-42	5998-01-308-3066	ADAPTER, DME	ROCKWELL COLLINS
DL1326M11	1680-00-617-9128	ACTUATOR, ELECTRO-MECHANICAL, LINEAR	SIMMONDS PRECISION PRODUCTS
DL1326M39-4	1680-00-877-6385	ACTUATOR, ELECTRO-MECHANICAL, LINEAR	SIMMONDS PRECISION PRODUCTS
DL1326M39-5	1680-01-181-3218	ACTUATOR, ELECTRO-MECHANICAL, LINEAR	SIMMONDS PRECISION PRODUCTS
DL1326M40-1	1680-01-181-1374	ACTUATOR, ELECTRO-MECHANICAL, LINEAR	SIMMONDS PRECISION PRODUCTS
DL1326M40-4	1680-01-181-1374	ACTUATOR, ELECTRO-MECHANICAL, LINEAR	SIMMONDS PRECISION PRODUCTS
DME-42	5895-01-304-3814	INTERROGATOR SET	ROCKWELL COLLINS
DMN4-33-3	5985-01-433-9503	ANTENNA	EDO
DMNI50-2-2	5985-01-015-0737	ANTENNA	EDO
DMNI50-4-2	5985-01-324-6246	ANTENNA	EDO
DPU-86R	5821-01-333-9238	PROCESSOR UNIT, DISPLAY	ROCKWELL COLLINS
DST29-1	6685-00-066-4581	INDICATOR, THERMOCOUPLE, TEMPERATURE	CARLETON LIFE SUPPORT SYSTEMS
DST29-2	6685-00-066-4581	INDICATOR, THERMOCOUPLE, TEMPERATURE	CARLETON LIFE SUPPORT SYSTEMS
DST29-3	6685-00-933-7911	INDICATOR, THERMOCOUPLE, TEMPERATURE	CARLETON LIFE SUPPORT SYSTEMS
DYLZ3990		VALVE, ENVIRONMENTAL AIR ,FLOW CONTROL	GE AVIATION SYSTEMS
DYLZ3990-1	1660-00-672-4247	VALVE, ENVIRONMENTAL AIR ,FLOW CONTROL	GE AVIATION SYSTEMS
DYLZ3990-2	1660-00-832-3076	VALVE, ENVIRONMENTAL AIR ,FLOW CONTROL	GE AVIATION SYSTEMS
DYLZ3990-3	1660-00-690-6150	VALVE, ENVIRONMENTAL AIR ,FLOW CONTROL	GE AVIATION SYSTEMS
DYLZ3990A		VALVE, ENVIRONMENTAL AIR ,FLOW CONTROL	GE AVIATION SYSTEMS
DYLZ3991		VALVE, ENVIRONMENTAL AIR ,FLOW CONTROL	GE AVIATION SYSTEMS
DYLZ3991-1	4810-00-525-2445	VALVE, ENVIRONMENTAL AIR ,FLOW CONTROL	GE AVIATION SYSTEMS
DYLZ3991-2	4810-00-522-4595	VALVE, ENVIRONMENTAL AIR ,FLOW CONTROL	GE AVIATION SYSTEMS
DYLZ3991-3	4810-00-682-5374	VALVE, ENVIRONMENTAL AIR ,FLOW CONTROL	GE AVIATION SYSTEMS
DYLZ3991A		VALVE, ENVIRONMENTAL AIR ,FLOW CONTROL	GE AVIATION SYSTEMS
DYLZ5858-1	1660-00-818-7701	VALVE, BUTTERFLY	GE AVIATION
E0724104003	6610-00-585-1524	INDICATOR, AIR SPEED	KOLLSMAN
E07241-04-003	6610-00-585-1524	INDICATOR, AIR SPEED	KOLLSMAN
E072410004	6610-01-393-1139	INDICATOR, AIR SPEED	KOLLSMAN
E07241-10-004	6610-01-393-1139	INDICATOR, AIR SPEED	KOLLSMAN
E0724310002	6610-00-834-0713	INDICATOR, AIR SPEED	KOLLSMAN
E07243-10-002	6610-00-834-0713	INDICATOR, AIR SPEED	KOLLSMAN
E-29	6620-00-526-5003	INDICATOR, ELECTRICAL TACHOMETER	KOLLSMAN
E-323E	5945-00-628-6484	RELAY, HYBRID	TE CONNECTIVITY
E-323E-1	5945-00-628-6484	RELAY, HYBRID	TE CONNECTIVITY
E-323E-1A	5945-00-628-6484	RELAY, HYBRID	TE CONNECTIVITY
E-384	5945-00-628-6484	RELAY, HYBRID	TE CONNECTIVITY
E424B10	5826-00-969-9542	MOUNTING BASE ASSEMBLY	BAE SYSTEMS
E424C1	5895-00-247-3004	CONTROL BOX, RECEIVER	BAE SYSTEMS
E424E2	5826-00-505-3580	INDICATOR, BEARING	FAIRCHILD
E621052	5965-01-128-1410	HEADSET, MICROPHONE	RAYTHEON
E830023	6625-00-668-7818	METER, ELECTRICAL FREQUENCY	LOCKHEED MARTIN
EA100ANH144	6680-00-580-9557	INDICATOR, ENGINE OIL, QUANTITY	SIMMONDS PRECISION PRODUCTS
EA1045-037-2B	4320-00-949-6842	PUMP, HYDRAULIC, AUXILIARY	EATON AEROSPACE



EA1065A-1615	6680-00-472-6348	TRANSMITTER, OIL QUANTITY	SIMMONDS PRECISION PRODUCTS
EA1065AW1827	6680-00-740-7044	TRANSMITTER, OIL QUANTITY	STRUBE
EA1065AW-1827	6680-00-740-7044	TRANSMITTER, OIL QUANTITY	STRUBE
EA1065AW2315	6680-01-419-1995	TRANSMITTER, OIL QUANTITY	STRUBE
EA1065AW-2315	6680-01-419-1995	TRANSMITTER, OIL QUANTITY	STRUBE
EA1068A-2313		TRANSMITTER, OIL QUANTITY	STRUBE
EA1068A-2352	6680-00-319-1723	TRANSMITTER, OIL QUANTITY	STRUBE
EA321-16	6610-00-515-4600	INDICATOR, FLAP, POSITION	SIMMONDS PRECISION PRODUCTS
EA321-2	6610-00-515-4600	INDICATOR, FLAP, POSITION	SIMMONDS PRECISION PRODUCTS
EA326-15	6610-00-808-7038	INDICATOR, AILERON TRIM TAB, POSITION	SIMMONDS PRECISION PRODUCTS
EA326-15A	6610-00-808-7038	INDICATOR, AILERON TRIM TAB, POSITION	SIMMONDS PRECISION PRODUCTS
EA326-8	6610-00-580-9690	INDICATOR, AILERON TRIM TAB, POSITION	SIMMONDS PRECISION PRODUCTS
EA573-1	6610-00-530-0961	TRANSMITTER, POSITION	SIMMONDS PRECISION PRODUCTS
EA573A1	6610-00-530-0961	TRANSMITTER, POSITION	SIMMONDS PRECISION PRODUCTS
EA573A-1	6610-00-530-0961	TRANSMITTER, POSITION	SIMMONDS PRECISION PRODUCTS
EA573A11	6610-00-530-0961	TRANSMITTER, POSITION	SIMMONDS PRECISION PRODUCTS
EA573A6A	6610-00-800-5569	TRANSMITTER, POSITION	SIMMONDS PRECISION PRODUCTS
EA573C1A	6610-00-526-8232	TRANSMITTER, POSITION	SIMMONDS PRECISION PRODUCTS
EA573C2A	6610-00-526-8231	TRANSMITTER, POSITION	SIMMONDS PRECISION PRODUCTS
EA573D1	6610-00-678-9887	TRANSMITTER, POSITION	SIMMONDS PRECISION PRODUCTS
EA7722856	6680-00-869-9811	COMPENSATOR, FUEL QUANTITY	SIMMONDS PRECISION PRODUCTS
EA7722857	6680-00-869-9812	COMPENSATOR, FUEL QUANTITY	SIMMONDS PRECISION PRODUCTS
EA7722858	6680-00-869-9813	COMPENSATOR, FUEL QUANTITY	SIMMONDS PRECISION PRODUCTS
EA7722859	6680-00-869-9814	COMPENSATOR, FUEL QUANTITY	SIMMONDS PRECISION PRODUCTS
ECU-23/A	6130-00-958-9796	POWER SUPPLY, DC	HAMILTON SUNDSTRAND
ED101	5826-00-535-6629	CONTROL PANEL, DIRECTION FINDER	PHILIPS ELECTRONIC INSTRUMENTS
EE0141-X	6130-MD-013-7377	BATTERY, EMERGENCY	SFENA (THALES AVIONICS)
EFD-85		DISPLAY, OPTOELECTRONIC, EADI/EHSI	ROCKWELL COLLINS
EFD-85A		DISPLAY, OPTOELECTRONIC, EADI/EHSI	ROCKWELL COLLINS
EFD-85M		DISPLAY, OPTOELECTRONIC, EADI/EHSI	ROCKWELL COLLINS
EFD-86		DISPLAY, OPTOELECTRONIC, EADI/EHSI	ROCKWELL COLLINS
EFD-86A		DISPLAY, OPTOELECTRONIC, EADI/EHSI	ROCKWELL COLLINS
EFD-86S		DISPLAY, OPTOELECTRONIC, EADI/EHSI	ROCKWELL COLLINS
EFU-4/A	6620-00-581-5102	INDICATOR, FUEL FLOW	AMETEK
EHU-15A		INDICATOR, THERMOCOUPLE, TEMPERATURE	CARLETON LIFE SUPPORT SYSTEMS
EHU-15A/A		INDICATOR, THERMOCOUPLE, TEMPERATURE	TRANSICOIL
EHU15AA		INDICATOR, THERMOCOUPLE, TEMPERATURE	TRANSICOIL
EHU-15AA		INDICATOR, THERMOCOUPLE, TEMPERATURE	CARLETON LIFE SUPPORT SYSTEMS
EKCC18043	6685-00-692-8341	INDICATOR, ANTI-ICING	JEWELL INSTRUMENTS
EM8000		GENERATOR, TACHOMETER	ELECTROMECH TECHNOLOGIES
EM8000-1		GENERATOR, TACHOMETER	ELECTROMECH TECHNOLOGIES
EM8000-2		GENERATOR, TACHOMETER	ELECTROMECH TECHNOLOGIES
EM8000-3		GENERATOR, TACHOMETER	ELECTROMECH TECHNOLOGIES
EM8000-4		GENERATOR, TACHOMETER	ELECTROMECH TECHNOLOGIES
EM8000-5	6680-00-815-1905	GENERATOR, TACHOMETER	ELECTROMECH TECHNOLOGIES
EM8001	6680-01-308-3311	GENERATOR, TACHOMETER	ELECTROMECH TECHNOLOGIES
EM8001-1		GENERATOR, TACHOMETER	ELECTROMECH TECHNOLOGIES
EM8001-2		GENERATOR, TACHOMETER	ELECTROMECH TECHNOLOGIES
EM8001-3		GENERATOR, TACHOMETER	ELECTROMECH TECHNOLOGIES
EM8001-4	6680-01-394-1114	GENERATOR, TACHOMETER	ELECTROMECH TECHNOLOGIES
EM8001-5		GENERATOR, TACHOMETER	ELECTROMECH TECHNOLOGIES
EM8002		GENERATOR, TACHOMETER	ELECTROMECH TECHNOLOGIES
ERU-22/A	6620-01-060-3086	INDICATOR, ELECTRICAL, TACHOMETER	PARKER-HANNIFIN

ET-B4		AMPLIFIER, ELECTRONIC TEMPERATURE DATUM	HONEYWELL INTERNATIONAL
F0739310067	6610-00-929-1614	INDICATOR, AIR SPEED	KOLLSMAN
F1559710003	6620-00-543-2534	INDICATOR, ELECTRICAL TACHOMETER	KOLLSMAN
F15597-10-003	6620-00-543-2534	INDICATOR, ELECTRICAL TACHOMETER	KOLLSMAN
F60W0232	2915-00-349-2719	VALVE, FLOAT, FUEL TANK	PARKER HANNIFIN
F60W0232M1	2915-00-574-3227	VALVE, FLOAT, FUEL TANK	PARKER HANNIFIN
F60W0233	2915-00-357-2499	VALVE, FLOAT, FUEL TANK	PARKER HANNIFIN
F60W0233M1	2915-00-581-0477	VALVE, FLOAT, FUEL TANK	PARKER HANNIFIN
FCC-86D	6605-15-191-3981	COMPUTER, AP/FD	ROCKWELL COLLINS
FDU-70		VALVE, FLUX DETECTOR	ROCKWELL COLLINS
FG220A100	6680-00-585-0817	COMPENSATOR, FUEL QUANITY	HONEYWELL INTERNATIONAL
FG220A101	6680-00-585-1038	COMPENSATOR, FUEL QUANITY	HONEYWELL INTERNATIONAL
FG220A102	6680-00-585-0816	COMPENSATOR, FUEL QUANITY	HONEYWELL INTERNATIONAL
FG220A103	6680-00-585-9349	COMPENSATOR, FUEL QUANITY	HONEYWELL INTERNATIONAL
FG220A104	6680-00-585-815	COMPENSATOR, FUEL QUANITY	HONEYWELL INTERNATIONAL
FG220A105	6680-00-585-0814	COMPENSATOR, FUEL QUANITY	HONEYWELL INTERNATIONAL
FG220A106	6680-00-585-0813	COMPENSATOR, FUEL QUANITY	HONEYWELL INTERNATIONAL
FG220A107	6680-00-585-0812	COMPENSATOR, FUEL QUANITY	HONEYWELL INTERNATIONAL
FG220A108	6680-00-585-9350	COMPENSATOR, FUEL QUANITY	HONEYWELL INTERNATIONAL
FG220A109	6680-00-585-0811	COMPENSATOR, FUEL QUANITY	HONEYWELL INTERNATIONAL
FG220A110	6680-00-585-0820	COMPENSATOR, FUEL QUANITY	HONEYWELL INTERNATIONAL
FG220A111	6680-00-585-0821	COMPENSATOR, FUEL QUANITY	HONEYWELL INTERNATIONAL
FG220A112	6680-00-585-0822	COMPENSATOR, FUEL QUANITY	HONEYWELL INTERNATIONAL
FG220A113	6680-00-585-0823	COMPENSATOR, FUEL QUANITY	HONEYWELL INTERNATIONAL
FG220A114	6680-00-585-0824	COMPENSATOR, FUEL QUANITY	HONEYWELL INTERNATIONAL
FG220A115	6680-00-585-9351	COMPENSATOR, FUEL QUANITY	HONEYWELL INTERNATIONAL
FG220A155	6680-00-727-2156	COMPENSATOR, FUEL QUANITY	HONEYWELL INTERNATIONAL
FG220A156		COMPENSATOR, FUEL QUANITY	HONEYWELL INTERNATIONAL
FG220A175		COMPENSATOR, FUEL QUANITY	HONEYWELL INTERNATIONAL
FG220A176	6680-899-8661	COMPENSATOR, FUEL QUANITY	HONEYWELL INTERNATIONAL
FG220A177	6680-899-8662	COMPENSATOR, FUEL QUANITY	HONEYWELL INTERNATIONAL
FG220A178	6680-899-8663	COMPENSATOR, FUEL QUANITY	HONEYWELL INTERNATIONAL
FG220A179	6680-899-8664	COMPENSATOR, FUEL QUANITY	HONEYWELL INTERNATIONAL
FG220A192		COMPENSATOR, FUEL QUANITY	HONEYWELL INTERNATIONAL
FG220A193		COMPENSATOR, FUEL QUANITY	HONEYWELL INTERNATIONAL
FG220A194		COMPENSATOR, FUEL QUANITY	HONEYWELL INTERNATIONAL
FG220A195		COMPENSATOR, FUEL QUANITY	HONEYWELL INTERNATIONAL
FG220A196		COMPENSATOR, FUEL QUANITY	HONEYWELL INTERNATIONAL
FG220A197		COMPENSATOR, FUEL QUANITY	HONEYWELL INTERNATIONAL
FG220A198		COMPENSATOR, FUEL QUANITY	HONEYWELL INTERNATIONAL
FG220A199		COMPENSATOR, FUEL QUANITY	HONEYWELL INTERNATIONAL
FG220A200		COMPENSATOR, FUEL QUANITY	HONEYWELL INTERNATIONAL
FG220A201		COMPENSATOR, FUEL QUANITY	HONEYWELL INTERNATIONAL
FG220A202		COMPENSATOR, FUEL QUANITY	HONEYWELL INTERNATIONAL
FG220A203		COMPENSATOR, FUEL QUANITY	HONEYWELL INTERNATIONAL
FG220A204		COMPENSATOR, FUEL QUANITY	HONEYWELL INTERNATIONAL
FG220A205		COMPENSATOR, FUEL QUANITY	HONEYWELL INTERNATIONAL
FG220A206		COMPENSATOR, FUEL QUANITY	HONEYWELL INTERNATIONAL
FG220A207		COMPENSATOR, FUEL QUANITY	HONEYWELL INTERNATIONAL
FG220A208		COMPENSATOR, FUEL QUANITY	HONEYWELL INTERNATIONAL
FG220A209		COMPENSATOR, FUEL QUANITY	HONEYWELL INTERNATIONAL
FG220A210		COMPENSATOR, FUEL QUANITY	HONEYWELL INTERNATIONAL
FG220A211		COMPENSATOR, FUEL QUANITY	HONEYWELL INTERNATIONAL

FG220A212		COMPENSATOR, FUEL QUANITY	HONEYWELL INTERNATIONAL
FG220A213		COMPENSATOR, FUEL QUANITY	HONEYWELL INTERNATIONAL
FG220A214		COMPENSATOR, FUEL QUANITY	HONEYWELL INTERNATIONAL
FG220A215		COMPENSATOR, FUEL QUANITY	HONEYWELL INTERNATIONAL
FG220A216		COMPENSATOR, FUEL QUANITY	HONEYWELL INTERNATIONAL
FG220A237	6680-00-968-3225	COMPENSATOR, FUEL QUANITY	HONEYWELL INTERNATIONAL
FG220A238	6680-00-968-3226	COMPENSATOR, FUEL QUANITY	HONEYWELL INTERNATIONAL
FG220A239	6680-00-968-3227	COMPENSATOR, FUEL QUANITY	HONEYWELL INTERNATIONAL
FG220A240	6680-00-968-3228	COMPENSATOR, FUEL QUANITY	HONEYWELL INTERNATIONAL
FG220A241	6680-00-968-3229	COMPENSATOR, FUEL QUANITY	HONEYWELL INTERNATIONAL
FG220A242	6680-00-968-3230	COMPENSATOR, FUEL QUANITY	HONEYWELL INTERNATIONAL
FG220A243	6680-00-968-3242	COMPENSATOR, FUEL QUANITY	HONEYWELL INTERNATIONAL
FG220A244	6680-00-968-3243	COMPENSATOR, FUEL QUANITY	HONEYWELL INTERNATIONAL
FG220A245	6680-00-968-3244	COMPENSATOR, FUEL QUANITY	HONEYWELL INTERNATIONAL
FG220A246	6680-00-968-3251	COMPENSATOR, FUEL QUANITY	HONEYWELL INTERNATIONAL
FG220A247	6680-00-968-3252	COMPENSATOR, FUEL QUANITY	HONEYWELL INTERNATIONAL
FG220A248	6680-00-968-3255	COMPENSATOR, FUEL QUANITY	HONEYWELL INTERNATIONAL
FG220A249	6680-00-968-3258	COMPENSATOR, FUEL QUANITY	HONEYWELL INTERNATIONAL
FG220A250	6680-00-968-3260	COMPENSATOR, FUEL QUANITY	HONEYWELL INTERNATIONAL
FG220A251	6680-00-968-3261	COMPENSATOR, FUEL QUANITY	HONEYWELL INTERNATIONAL
FG220A252	6680-00-968-3263	COMPENSATOR, FUEL QUANITY	HONEYWELL INTERNATIONAL
FG220A253	6680-00-968-3266	COMPENSATOR, FUEL QUANITY	HONEYWELL INTERNATIONAL
FG220A254	6680-00-968-3269	COMPENSATOR, FUEL QUANITY	HONEYWELL INTERNATIONAL
FG220A255	6680-00-968-3270	COMPENSATOR, FUEL QUANITY	HONEYWELL INTERNATIONAL
FG220A256	6680-00-968-3271	COMPENSATOR, FUEL QUANITY	HONEYWELL INTERNATIONAL
FG220A257	6680-00-968-3253	COMPENSATOR, FUEL QUANITY	HONEYWELL INTERNATIONAL
FG220A258	6680-00-968-3197	COMPENSATOR, FUEL QUANITY	HONEYWELL INTERNATIONAL
FG220A259	6680-00-968-3212	COMPENSATOR, FUEL QUANITY	HONEYWELL INTERNATIONAL
FG220A260	6680-00-968-3213	COMPENSATOR, FUEL QUANITY	HONEYWELL INTERNATIONAL
FG220A261	6680-00-968-3223	COMPENSATOR, FUEL QUANITY	HONEYWELL INTERNATIONAL
FG220A60	6680-00-580-1054	COMPENSATOR, FUEL QUANITY	HONEYWELL INTERNATIONAL
FG220A61	6680-00-580-1055	COMPENSATOR, FUEL QUANITY	HONEYWELL INTERNATIONAL
FG220A62	6680-00-580-1056	COMPENSATOR, FUEL QUANITY	HONEYWELL INTERNATIONAL
FG220A63	6680-00-580-1057	COMPENSATOR, FUEL QUANITY	HONEYWELL INTERNATIONAL
FG220A64	6680-00-580-1058	COMPENSATOR, FUEL QUANITY	HONEYWELL INTERNATIONAL
FG220A65	6680-00-580-1059	COMPENSATOR, FUEL QUANITY	HONEYWELL INTERNATIONAL
FG220A66	6680-00-580-1062	COMPENSATOR, FUEL QUANITY	HONEYWELL INTERNATIONAL
FG220A67	6680-00-580-1060	COMPENSATOR, FUEL QUANITY	HONEYWELL INTERNATIONAL
FG220A68	6680-00-580-1061	COMPENSATOR, FUEL QUANITY	HONEYWELL INTERNATIONAL
FG220A75	6680-00-585-3083	COMPENSATOR, FUEL QUANITY	HONEYWELL INTERNATIONAL
FG220A76	6680-00-585-3081	COMPENSATOR, FUEL QUANITY	HONEYWELL INTERNATIONAL
FG220A83	6680-00-585-3082	COMPENSATOR, FUEL QUANITY	HONEYWELL INTERNATIONAL
FG220A95	6680-00-585-9352	COMPENSATOR, FUEL QUANITY	HONEYWELL INTERNATIONAL
FG220A96	6680-00-585-9353	COMPENSATOR, FUEL QUANITY	HONEYWELL INTERNATIONAL
FG220A97	6680-00-585-9354	COMPENSATOR, FUEL QUANITY	HONEYWELL INTERNATIONAL
FG220A98	6680-00-585-0825	COMPENSATOR, FUEL QUANITY	HONEYWELL INTERNATIONAL
FG220A99	6680-00-585-0826	COMPENSATOR, FUEL QUANITY	HONEYWELL INTERNATIONAL
FG250A42	6680-00-089-5300	COMPENSATOR, FUEL QUANITY	HONEYWELL INTERNATIONAL
FG250A43	6680-00-089-5299	COMPENSATOR, FUEL QUANITY	HONEYWELL INTERNATIONAL
FG250A44	6680-00-089-5298	COMPENSATOR, FUEL QUANITY	HONEYWELL INTERNATIONAL
FG250A51	6680-00-968-3277	COMPENSATOR, FUEL QUANITY	HONEYWELL INTERNATIONAL
FG250A53	6680-00-968-3281	COMPENSATOR, FUEL QUANITY	HONEYWELL INTERNATIONAL
FG250A6	6680-00-585-0827	COMPENSATOR, FUEL QUANITY	HONEYWELL INTERNATIONAL

FG250A7	6680-00-585-0828	COMPENSATOR, FUEL QUANITY	HONEYWELL INTERNATIONAL
FG250A8	6680-00-968-3281	COMPENSATOR, FUEL QUANITY	HONEYWELL INTERNATIONAL
FG450A51	6680-01-059-3387	COMPENSATOR, FUEL QUANITY	HONEYWELL INTERNATIONAL
FG450A53	6680-01-064-3231	COMPENSATOR, FUEL QUANITY	HONEYWELL INTERNATIONAL
FG6F1	6680-01-067-4552	COMPENSATOR, LIQUID QUANTITY GAGE	HONEYWELL INTERNATIONAL
FGA220A237		COMPENSATOR, FUEL QUANITY	HONEYWELL INTERNATIONAL
FGA220A238		COMPENSATOR, FUEL QUANITY	HONEYWELL INTERNATIONAL
FGA220A239		COMPENSATOR, FUEL QUANITY	HONEYWELL INTERNATIONAL
FGA220A240		COMPENSATOR, FUEL QUANITY	HONEYWELL INTERNATIONAL
FGA220A241		COMPENSATOR, FUEL QUANITY	HONEYWELL INTERNATIONAL
FGA220A242		COMPENSATOR, FUEL QUANITY	HONEYWELL INTERNATIONAL
FGA220A243		COMPENSATOR, FUEL QUANITY	HONEYWELL INTERNATIONAL
FGA220A244		COMPENSATOR, FUEL QUANITY	HONEYWELL INTERNATIONAL
FGA220A245		COMPENSATOR, FUEL QUANITY	HONEYWELL INTERNATIONAL
FGA220A246		COMPENSATOR, FUEL QUANITY	HONEYWELL INTERNATIONAL
FGA220A247		COMPENSATOR, FUEL QUANITY	HONEYWELL INTERNATIONAL
FGA220A248		COMPENSATOR, FUEL QUANITY	HONEYWELL INTERNATIONAL
FGA220A249		COMPENSATOR, FUEL QUANITY	HONEYWELL INTERNATIONAL
FGA220A250		COMPENSATOR, FUEL QUANITY	HONEYWELL INTERNATIONAL
FGA220A251		COMPENSATOR, FUEL QUANITY	HONEYWELL INTERNATIONAL
FGA220A252		COMPENSATOR, FUEL QUANITY	HONEYWELL INTERNATIONAL
FGA220A253		COMPENSATOR, FUEL QUANITY	HONEYWELL INTERNATIONAL
FGA220A254		COMPENSATOR, FUEL QUANITY	HONEYWELL INTERNATIONAL
FGA220A255		COMPENSATOR, FUEL QUANITY	HONEYWELL INTERNATIONAL
FGA220A256		COMPENSATOR, FUEL QUANITY	HONEYWELL INTERNATIONAL
FGA220A257		COMPENSATOR, FUEL QUANITY	HONEYWELL INTERNATIONAL
FGA430A237		COMPENSATOR, FUEL QUANITY	HONEYWELL INTERNATIONAL
FGA430A238		COMPENSATOR, FUEL QUANITY	HONEYWELL INTERNATIONAL
FGA430A239		COMPENSATOR, FUEL QUANITY	HONEYWELL INTERNATIONAL
FGA430A240		COMPENSATOR, FUEL QUANITY	HONEYWELL INTERNATIONAL
FGA430A241		COMPENSATOR, FUEL QUANITY	HONEYWELL INTERNATIONAL
FGA430A242		COMPENSATOR, FUEL QUANITY	HONEYWELL INTERNATIONAL
FGA430A243		COMPENSATOR, FUEL QUANITY	HONEYWELL INTERNATIONAL
FGA430A244		COMPENSATOR, FUEL QUANITY	HONEYWELL INTERNATIONAL
FGA430A245		COMPENSATOR, FUEL QUANITY	HONEYWELL INTERNATIONAL
FGA430A246		COMPENSATOR, FUEL QUANITY	HONEYWELL INTERNATIONAL
FGA430A247		COMPENSATOR, FUEL QUANITY	HONEYWELL INTERNATIONAL
FGA430A248		COMPENSATOR, FUEL QUANITY	HONEYWELL INTERNATIONAL
FGA430A249		COMPENSATOR, FUEL QUANITY	HONEYWELL INTERNATIONAL
FGA430A250		COMPENSATOR, FUEL QUANITY	HONEYWELL INTERNATIONAL
FGA430A251		COMPENSATOR, FUEL QUANITY	HONEYWELL INTERNATIONAL
FGA430A252		COMPENSATOR, FUEL QUANITY	HONEYWELL INTERNATIONAL
FGA430A253		COMPENSATOR, FUEL QUANITY	HONEYWELL INTERNATIONAL
FGA430A254		COMPENSATOR, FUEL QUANITY	HONEYWELL INTERNATIONAL
FGA430A255		COMPENSATOR, FUEL QUANITY	HONEYWELL INTERNATIONAL
FGA430A256		COMPENSATOR, FUEL QUANITY	HONEYWELL INTERNATIONAL
FGA430A257		COMPENSATOR, FUEL QUANITY	HONEYWELL INTERNATIONAL
FGA430A259	6680-01-067-4548	COMPENSATOR, FUEL QUANITY	HONEYWELL INTERNATIONAL
FLDXF20307A	6625-01-412-3365	METER, ELECTRICAL FREQUENCY	HONEYWELL INTERNATIONAL
G-1152-B460-C	5945-00-675-7412	RELAY, ELECTROMAGNETIC	TE CONNECTIVITY
G4020	6220-01-362-0390	CONTROL, ATC	GABLES ENGINEERING
G-5400-1	6220-00-299-4621	LIGHT, LANDING, AIRCRAFT	GRIMES AEROSPACE
G-5400-2		LIGHT, LANDING, AIRCRAFT	GRIMES AEROSPACE

G-5400-3	6220-00-299-4621	LIGHT, LANDING, AIRCRAFT	GRIMES AEROSPACE
G-5400-4		LIGHT, LANDING, AIRCRAFT	GRIMES AEROSPACE
G-5400-5	6220-00-893-8777	LIGHT, LANDING, AIRCRAFT	GRIMES AEROSPACE
G-6965-13	6220-00-548-0008	LIGHT, WARNING, NAVIGATION	GRIMES AEROSPACE
G-6965-15	6220-00-548-0008	LIGHT, WARNING, NAVIGATION	GRIMES AEROSPACE
G-6965-22	6220-00-346-6820	LIGHT, WARNING, NAVIGATION	GRIMES AEROSPACE
G-6965-34	6220-00-548-0008	LIGHT, WARNING, NAVIGATION	GRIMES AEROSPACE
G-6965-8	6220-00-421-9109	LIGHT, WARNING, NAVIGATION	GRIMES AEROSPACE
G-6965-9	6220-00-548-0008	LIGHT, WARNING, NAVIGATION	GRIMES AEROSPACE
G7300-02	1680-01-594-5284	CONTROL PANEL, ELECTRICAL-ELECTRONIC	ACSS
G8400A10-24		LIGHT, EMERGENCY, ROTATING	GRIMES AEROSPACE
G8400A11-24		LIGHT, EMERGENCY, ROTATING	GRIMES AEROSPACE
G8400A12		LIGHT, EMERGENCY, ROTATING	GRIMES AEROSPACE
G8400A12-12		LIGHT, EMERGENCY, ROTATING	GRIMES AEROSPACE
G8400A13-24		LIGHT, EMERGENCY, ROTATING	GRIMES AEROSPACE
G8400A14-24	6220-00-815-8194	LIGHT, EMERGENCY, ROTATING	GRIMES AEROSPACE
G8400A15-24		LIGHT, EMERGENCY, ROTATING	GRIMES AEROSPACE
G8400A21-24		LIGHT, EMERGENCY, ROTATING	GRIMES AEROSPACE
G8400A22-24		LIGHT, EMERGENCY, ROTATING	GRIMES AEROSPACE
G8400A23-24	6220-00-572-6413	LIGHT, EMERGENCY, ROTATING	GRIMES AEROSPACE
G8400A24		LIGHT, EMERGENCY, ROTATING	GRIMES AEROSPACE
G8400A24-24	6220-00-803-4610	LIGHT, EMERGENCY, ROTATING	GRIMES AEROSPACE
G8400A24-24L	6220-01-371-1791	LIGHT, EMERGENCY, ROTATING	GRIMES AEROSPACE
G8400A3-12		LIGHT, EMERGENCY, ROTATING	GRIMES AEROSPACE
G8400A31-24		LIGHT, EMERGENCY, ROTATING	GRIMES AEROSPACE
G8400A3-24	6220-01-439-4634	LIGHT, EMERGENCY, ROTATING	GRIMES AEROSPACE
G8400A36-24		LIGHT, EMERGENCY, ROTATING	GRIMES AEROSPACE
G8400A37-24		LIGHT, EMERGENCY, ROTATING	GRIMES AEROSPACE
G8400A39-24		LIGHT, EMERGENCY, ROTATING	GRIMES AEROSPACE
G8400A41-24		LIGHT, EMERGENCY, ROTATING	GRIMES AEROSPACE
G8400A41-24L		LIGHT, WARNING, ROTATING	GRIMES AEROSPACE
G8400A43-24		LIGHT, EMERGENCY, ROTATING	GRIMES AEROSPACE
G8400A45-12		LIGHT, EMERGENCY, ROTATING	GRIMES AEROSPACE
G8400A47-24		LIGHT, EMERGENCY, ROTATING	GRIMES AEROSPACE
G8400A49-24		LIGHT, EMERGENCY, ROTATING	GRIMES AEROSPACE
G8400A8-12		LIGHT, EMERGENCY, ROTATING	GRIMES AEROSPACE
G8400A8-24	6220-00-691-1189	LIGHT, EMERGENCY, ROTATING	GRIMES AEROSPACE
G8400A8-24S	6220-01-231-7601	LIGHT, EMERGENCY, ROTATING	GRIMES AEROSPACE
G8400A9-24		LIGHT, EMERGENCY, ROTATING	GRIMES AEROSPACE
G8895-1	6220-00-858-0915	LIGHT, AIRCRAFT, LANDING	GRIMES AEROSPACE
G-8895-1	6220-00-858-0915	LIGHT, AIRCRAFT, LANDING	GRIMES AEROSPACE
GA3090MS	6610-00-111-3159	INDICATOR, VERTICAL VELOCITY	AEROSONIC
GG2479AA01	6615-00-169-1564	GYROSCOPE, RATE OF TURN	HONEYWELL INTERNATIONAL
GG2479AB01	6615-00-137-6038	GYROSCOPE, RATE OF TURN	HONEYWELL INTERNATIONAL
GG2-79	6615-00-137-6038	GYROSCOPE, RATE OF TURN	HONEYWELL INTERNATIONAL
GHN10125-1	4810-00-761-6225	VALVE, LINEAR, DIRECTIONAL CONTROL	LOCKHEED MARTIN
GHN10255-1	1650-00-815-2499	FUSE, HYDRAULIC SYSTEM	PARKER-HANNIFIN
GMU-37/A	6680-00-753-8932	INDICATOR, LIQUID QUANTITY	TRANSICOIL
GMU37A	6680-00-753-8932	INDICATOR, LIQUID QUANTITY	TRANSICOIL
H-157/A1C	5965-01-128-1410	HEADSET, MICROPHONE	ASTROCOM ELECTRONICS
H-157A/A1C	5965-01-128-1410	HEADSET, MICROPHONE	ASTROCOM ELECTRONICS
H157A1C	5965-01-128-1410	HEADSET, MICROPHONE	ASTROCOM ELECTRONICS
H157AA1C	5965-01-128-1410	HEADSET, MICROPHONE	ASTROCOM ELECTRONICS

H157AAIC	5965-01-128-1410	HEADSET, MICROPHONE	ASTROCOM ELECTRONICS
H157AIC	5965-01-128-1410	HEADSET, MICROPHONE	ASTROCOM ELECTRONICS
H-158/AIC	5965-01-127-3890	HEADSET, MICROPHONE	ASTROCOM ELECTRONICS
H-158A/AIC	5965-01-127-3890	HEADSET, MICROPHONE	ASTROCOM ELECTRONICS
H158AAIC	5965-01-127-3890	HEADSET, MICROPHONE	ASTROCOM ELECTRONICS
H158AIC	5965-01-127-3890	HEADSET, MICROPHONE	ASTROCOM ELECTRONICS
HD150/APN59	4140-00-289-4277	FAN, VANE, AXIAL	NORTHROP GRUMMAN SYSTEMS
HD-150/APN-59	4140-00-289-4277	FAN, VANE, AXIAL	NORTHROP GRUMMAN SYSTEMS
HR-27A		MOUNT, DYNAFOCAL	LORD
HSI-45	6605-01-101-1883	INDICATOR, HORIZONTAL SITUATION	ROCKWELL COLLINS
ID-1103/ARN	5826-01-459-5969	INDICATOR, BEARING DISTANCE, HEADING	AIRCO
ID1103ARN	5826-00-032-7024	INDICATOR, BEARING-DISTANCE-HEADING	AIRCO
ID1768A/APN-194V	5841-00-110-4912	INDICATOR, HEIGHT	HONEYWELL INTERNATIONAL
ID1768AAPN194V	5841-00-110-4912	INDICATOR, HEIGHT	HONEYWELL INTERNATIONAL
ID-1768B/APN-194V	5841-01-082-7951	INDICATOR, HEIGHT	HONEYWELL INTERNATIONAL
ID1768BAPN194V	5841-01-082-7951	INDICATOR, HEIGHT	HONEYWELL INTERNATIONAL
ID-231/ARN-6	5826-00-612-6596	INDICATOR, BEARING	KOLLSMAN
ID-231A/ARN-6	5826-00-612-6597	INDICATOR, BEARING	KOLLSMAN
ID-231AARN-6	5826-00-612-6597	INDICATOR, BEARING	KOLLSMAN
ID231ARN6	5826-00-612-6596	INDICATOR, BEARING	KOLLSMAN
ID-231B/ARN-6	5826-00-188-5554	INDICATOR, BEARING	KOLLSMAN
ID231BARN6	5826-00-188-5554	INDICATOR, BEARING	KOLLSMAN
ID-250/ARN		INDICATOR, RADIO MAGNETIC	HONEYWELL INTERNATIONAL
ID-250A/ARN	5826-00-505-3094	INDICATOR, RADIO MAGNETIC	HONEYWELL INTERNATIONAL
ID-663C/U	5826-00-089-7912	INDICATOR, BEARING DISTANCE HEADING	ASTRONAUTICS
ID-663CU	5826-00-168-8308	INDICATOR, BEARING DISTANCE HEADING	ASTRONAUTICS
ID-90/ARN-6	5826-00-505-3580	INDICATOR, BEARING	KOLLSMAN
ID90A/ARN6	5826-00-090-3646	INDICATOR, BEARING	KEARFOTT
ID-90A/ARN-6	5826-00-090-3646	INDICATOR, BEARING	KEARFOTT
ID90AARN6	5826-00-090-3645	INDICATOR, BEARING	KEARFOTT
ID90ARN6	5826-00-505-3580	INDICATOR, BEARING	KOLLSMAN
ID-91A/ARN-6	5826-00-234-6315	INDICATOR, BEARING	KEARFOTT
ID91AARN6	5826-00-234-6315	INDICATOR, BEARING	KEARFOTT
ID-91B/ARN-6	5826-00-390-5744	INDICATOR, BEARING	KEARFOTT
ID91BARN6	5826-00-390-5744	INDICATOR, BEARING	KEARFOTT
ID-92/ARN-6	5826-00-505-0968	INDICATOR, BEARING	KOLLSMAN
ID92ARN6	5826-00-505-0968	INDICATOR, BEARING	KOLLSMAN
ID-938/APN-147(V)	5841-00-892-1070	INDICATOR, DRIFT ANGLE-GROUND SPEED	CMC ELECTRONIQUE
IND-40		INDICATOR, DME	ROCKWELL COLLINS
IND-40A		INDICATOR, DME	ROCKWELL COLLINS
IND-40B		INDICATOR, DME	ROCKWELL COLLINS
IND-40C		INDICATOR, DME	ROCKWELL COLLINS
IND-41		INDICATOR, DME	ROCKWELL COLLINS
IND-41A		INDICATOR, DME	ROCKWELL COLLINS
IND-41B		INDICATOR, DME	ROCKWELL COLLINS
IND-41C		INDICATOR, DME	ROCKWELL COLLINS
INTEGRA		TRANSMITTER, EMERGENCY LOCATOR (ELT)	KANNAD
IP-1374A/APS-133(V)	5841-01-193-6436	INDICATOR, WEATHER, RADAR	HONEYWELL INTERNATIONAL
IP239A/APN59	5841-00-805-7622	INDICATOR, RADAR, TARGET	NORTHROP GRUMMAN SYSTEMS
IP-239A/APN-59	5841-00-851-8029	INDICATOR, RADAR, TARGET	NORTHROP GRUMMAN SYSTEMS
IP239AAPN59	5841-00-690-5951	INDICATOR, RADAR, TARGET	NORTHROP GRUMMAN SYSTEMS
IP-239B/APN-59	5841-01-053-7874	INDICATOR, RADAR, TARGET	NORTHROP GRUMMAN SYSTEMS
IP268A/APN59	5841-01-053-7872	DISPLAY UNIT, RADAR	NORTHROP GRUMMAN SYSTEMS

IP-268A/APN-59	5841-01-053-7872	DISPLAY UNIT, RADAR	NORTHROP GRUMMAN SYSTEMS
J-4679-18		MOUNT, DYNAFOCAL	LORD
J-5216-SA		MOUNT, DYNAFOCAL	LORD
J-5924-1		MOUNT, DYNAFOCAL	LORD
J-6545-1		MOUNT, DYNAFOCAL	LORD
JG1073AB01	5841-00-110-4912	INDICATOR, HEIGHT	HONEYWELL INTERNATIONAL
JG1073CC01	5841-01-082-7951	INDICATOR, HEIGHT	HONEYWELL INTERNATIONAL
JG402A2	6680-00-580-1247	INDICATOR, FUEL QUANTITY	HONEYWELL INTERNATIONAL
JG402A-2	6680-00-580-1247	INDICATOR, FUEL QUANTITY	HONEYWELL INTERNATIONAL
JG402A3	6680-00-580-1246	INDICATOR, FUEL QUANTITY	HONEYWELL INTERNATIONAL
JG402A-3	6680-00-580-1246	INDICATOR, FUEL QUANTITY	HONEYWELL INTERNATIONAL
JG402A32	6680-00-866-5116	INDICATOR, FUEL QUANTITY	HONEYWELL INTERNATIONAL
JG402A-32	6680-00-866-5116	INDICATOR, FUEL QUANTITY	HONEYWELL INTERNATIONAL
JG402A4	6680-00-580-1248	INDICATOR, FUEL QUANTITY	HONEYWELL INTERNATIONAL
JG402A-4	6680-00-580-1248	INDICATOR, FUEL QUANTITY	HONEYWELL INTERNATIONAL
JG402A52	6680-01-056-1779	INDICATOR, FUEL QUANTITY	HONEYWELL INTERNATIONAL
JG402A-52	6680-01-056-1779	INDICATOR, FUEL QUANTITY	HONEYWELL INTERNATIONAL
JG402A53	6680-01-060-5228	INDICATOR, FUEL QUANTITY	HONEYWELL INTERNATIONAL
JG402A-53	6680-01-060-5228	INDICATOR, FUEL QUANTITY	HONEYWELL INTERNATIONAL
JG402A54	6680-01-058-5859	INDICATOR, FUEL QUANTITY	HONEYWELL INTERNATIONAL
JG402A-54	6680-01-058-5859	INDICATOR, FUEL QUANTITY	HONEYWELL INTERNATIONAL
JG402A55	6680-01-058-5860	INDICATOR, FUEL QUANTITY	HONEYWELL INTERNATIONAL
JG402A-55	6680-01-058-5860	INDICATOR, FUEL QUANTITY	HONEYWELL INTERNATIONAL
JG412A10	6680-00-849-7809	INDICATOR, FUEL QUANTITY	HONEYWELL INTERNATIONAL
JG412A-10	6680-00-849-7809	INDICATOR, FUEL QUANTITY	HONEYWELL INTERNATIONAL
JG412A2	6680-00-585-5859	INDICATOR, FUEL QUANTITY	HONEYWELL INTERNATIONAL
JG412A-2	6680-00-585-5859	INDICATOR, FUEL QUANTITY	HONEYWELL INTERNATIONAL
JG412A3	6680-00-585-5444	INDICATOR, FUEL QUANTITY	HONEYWELL INTERNATIONAL
JG412A-3	6680-00-585-5444	INDICATOR, FUEL QUANTITY	HONEYWELL INTERNATIONAL
JG412A4	6680-00-585-8600	INDICATOR, FUEL QUANTITY	HONEYWELL INTERNATIONAL
JG412A-4	6680-00-585-8600	INDICATOR, FUEL QUANTITY	HONEYWELL INTERNATIONAL
JG412A52	6680-01-063-0597	INDICATOR, FUEL QUANTITY	HONEYWELL INTERNATIONAL
JG412A-52	6680-01-063-0597	INDICATOR, FUEL QUANTITY	HONEYWELL INTERNATIONAL
JG412A53	6680-01-058-5861	INDICATOR, FUEL QUANTITY	HONEYWELL INTERNATIONAL
JG412A-53	6680-01-058-5861	INDICATOR, FUEL QUANTITY	HONEYWELL INTERNATIONAL
JG412A54	6680-01-058-5862	INDICATOR, FUEL QUANTITY	HONEYWELL INTERNATIONAL
JG412A-54	6680-01-058-5862	INDICATOR, FUEL QUANTITY	HONEYWELL INTERNATIONAL
JG412A55	6680-01-058-5863	INDICATOR, FUEL QUANTITY	HONEYWELL INTERNATIONAL
JG412A-55	6680-01-058-5863	INDICATOR, FUEL QUANTITY	HONEYWELL INTERNATIONAL
K300K001-01	5996-00-358-1724	AMPLIFIER, ELECTRONIC CONTROL	KEARFOTT
KEA-346		ALTIMETER, SERVO-ENCODER	BENDIX KING
KT-76A	5895-01-269-4441	TRANSCEIVER, ATC	HONEYWELL INTERNATIONAL
KY-96A	5821-MD-010-2079	TRANSCEIVER, RADIO	HONEYWELL INTERNATIONAL
L100206	5965-01-128-1410	HEADSET, MICROPHONE	REMLER
L16-107	1680-01-008-7442	ACTUATOR, ELECTRO-MECHANICAL, LINEAR	WHIPPANY ACTUATION SYSTEMS
L16-8	1680-00-687-4872	ACTUATOR, OIL COOLER DOOR, ELECTRO-MECHANICAL	WHIPPANY ACTUATION SYSTEMS
L16-8-1	1680-00-720-5810	ACTUATOR, OIL COOLER DOOR, ELECTRO-MECHANICAL	WHIPPANY ACTUATION SYSTEMS
L16-8-3	1680-00-720-5810	ACTUATOR, OIL COOLER DOOR, ELECTRO-MECHANICAL	WHIPPANY ACTUATION SYSTEMS
L16-8-5	1680-01-378-1631	ACTUATOR, OIL COOLER DOOR, ELECTRO-MECHANICAL	WHIPPANY ACTUATION SYSTEMS
L200261-1	5826-00-611-0951	MOUNTING BASE	RAYTHEON
L200355-1	5826-00-521-0571	COUPLING, ANTENNA	RAYTHEON
L8529935	2935-00-887-4267	COOLER, ENGINE OIL	LOCKHEED MARTIN
L95808-1	4810-01-206-6309	VALVE, SOLENOID, SHUT-OFF	LOCKHEED MARTIN

LAC624328-1	6685-00-561-9378	INDICATOR, FUEL FLOW	AMETEK
LM-102		MOUNT, DYNAFOCAL	LORD
LM-200D		MOUNT, DYNAFOCAL	LORD
LM-200G		MOUNT, DYNAFOCAL	LORD
LM-200H		MOUNT, DYNAFOCAL	LORD
LM-200K		MOUNT, DYNAFOCAL	LORD
LM-202		MOUNT, DYNAFOCAL	LORD
LM-204H		MOUNT, DYNAFOCAL	LORD
LM204SA19	2995-00-887-1963	MOUNT, DYNAFOCAL	LORD
LM-204-SA19	2995-00-887-1963	MOUNT, DYNAFOCAL	LORD
LM-204-SA21		MOUNT, DYNAFOCAL	LORD
LM-204-SA28		MOUNT, DYNAFOCAL	LORD
LM-204-SA30		MOUNT, DYNAFOCAL	LORD
LM-204-SA31		MOUNT, DYNAFOCAL	LORD
LM-204-SA8		MOUNT, DYNAFOCAL	LORD
LM-211A		MOUNT, DYNAFOCAL	LORD
LM211B		MOUNT, DYNAFOCAL	LORD
LM-303G		MOUNT, DYNAFOCAL	LORD
LM-307		MOUNT, DYNAFOCAL	LORD
LM-307A		MOUNT, DYNAFOCAL	LORD
LM-405C		MOUNT, DYNAFOCAL	LORD
LM-405D		MOUNT, DYNAFOCAL	LORD
LM-405-SA5		MOUNT, DYNAFOCAL	LORD
LM-405-SA6		MOUNT, DYNAFOCAL	LORD
LM-405-SA7		MOUNT, DYNAFOCAL	LORD
LM-405-SA8		MOUNT, DYNAFOCAL	LORD
LM-405-SA9		MOUNT, DYNAFOCAL	LORD
LM-406-SA2		MOUNT, DYNAFOCAL	LORD
LPE-22251-2		INDICATOR, AIR SPEED	CARLETON
LPE-22251-2M		INDICATOR, AIR SPEED	CARLETON
LPT-125G	5826-14-547-0474	RECEIVER PROCESSOR	ROCKWELL COLLINS
LS-211/AIC-13	5965-01-493-9721	LOUDSPEAKER, MAGNETIC	RANDAM ELECTRONICS
M200250-1	5826-00-090-3646	INDICATOR, BEARING	RAYTHEON
M25707/1-01	5985-00-673-5831	ANTENNA, DME/TACAN, BEACON	L3 TECHNOLOGIES
M25708/1-01	5985-00-106-0906	ANTENNA	EDO
M270-1	6605-00-551-8187	COMPASS, MAGNETIC, MOUNTED	HONEYWELL INTERNATIONAL
M5498-4	1650-00-877-6095	ACCUMULATOR ASSY, HYDRAULIC	PARKER-HANNIFIN
M5815/1-01	5985-00-217-0457	ANTENNA, UHF, BLADE	EDO
M-87/AIC	5965-00-755-4643	MICROPHONE, DYNAMIC	ASTROCOM ELECTRONICS
M87AIC	5965-00-755-4643	MICROPHONE, DYNAMIC	ASTROCOM ELECTRONICS
MA-1	6685-00-514-5061	INDICATOR, PRESSURE	AEROSONIC
MA7		INDICATOR, FUEL FLOW	AMETEK
MA-7	6620-00-551-2631	INDICATOR, FUEL FLOW	AMETEK
MA-7A	6620-01-391-2998	INDICATOR, FUEL FLOW	AMETEK
MC7545	6645-00-076-3050	CLOCK, MECHANICAL, PANEL	MACLEOD INSTRUMENT
MD-1		GYROSCOPE, DISPLACEMENT	GE AVIATION SYSTEMS
MF30-3913-25ZE5	1650-00-540-0162	MOTOR, HYDRAULIC	EATON AEROSPACE
MF30-3913-25ZE-S656-5	1650-00-954-1429	MOTOR, HYDRAULIC	EATON AEROSPACE
MF30-3913-30S159-2	1650-00-540-1773	MOTOR, HYDRAULIC	EATON AEROSPACE
MF30-3913-30ZE5	1650-00-204-1703	MOTOR, HYDRAULIC	EATON AEROSPACE
MF30-3913-30ZG-2		MOTOR, HYDRAULIC	EATON AEROSPACE
MF30-3913S228-2	1650-00-540-1773	MOTOR, HYDRAULIC	EATON AEROSPACE
MF-3913-2		MOTOR, HYDRAULIC	EATON AEROSPACE



MF-3913-5		MOTOR, HYDRAULIC	EATON AEROSPACE
MF42-3913S159-2		MOTOR, HYDRAULIC	EATON AEROSPACE
MF60-3913-30ZG5	1650-00-535-5878	MOTOR, HYDRAULIC	EATON AEROSPACE
MF60-3913-S215-2		MOTOR, HYDRAULIC	EATON AEROSPACE
MF88-913S395-5A	1650-00-651-2885	MOTOR, HYDRAULIC	EATON AEROSPACE
MF9-3911-30ZE	4320-01-224-9869	MOTOR, HYDRAULIC	EATON AEROSPACE
MF9-3911-30ZES473	1650-00-288-9632	MOTOR, HYDRAULIC	EATON AEROSPACE
MF9-3911-30ZS481	1650-00-815-9387	MOTOR, HYDRAULIC	EATON AEROSPACE
MFD-85		DISPLAY, MULTIFUNCTION	ROCKWELL COLLINS
MFD-85A		DISPLAY, MULTIFUNCTION	ROCKWELL COLLINS
MFD-85B	7025-01-476-7706	DISPLAY, MULTIFUNCTION	ROCKWELL COLLINS
MFD-85C		DISPLAY, MULTIFUNCTION	ROCKWELL COLLINS
MFD-85M		DISPLAY, MULTIFUNCTION	ROCKWELL COLLINS
MGE23-400	6125-00-020-3217	POWER CONVERTER, DC/AC	GE AVIATION SYSTEMS
MGE23-400A	6125-00-020-3217	POWER CONVERTER, DC/AC	GE AVIATION SYSTEMS
MGE23-500A	6125-01-503-8092	POWER CONVERTER, DC/AC	GE AVIATION SYSTEMS
MHB4016	2925-01-139-5144	STARTER, ENGINE	HARTZELL ENGINE TECHNOLOGIES
MIL-A-25707/1	5985-00-673-5831	ANTENNA, DME/TACAN, BEACON	L3 TECHNOLOGIES
MIL-A-25708/1	5985-00-106-0906	ANTENNA	EDO
MIL-A-25719	6610-00-007-1030	ACCELEROMETER, MECHANICAL	QED
MIL-A-25719 TYPE MA1		ACCELEROMETER, MECHANICAL	BURTON MEDICAL PRODUCTS
MIL-A-25933	6685-00-226-5700	ALTIMETER, CABIN	AEROSONIC
MIL-A-27261A	6610-01-391-9062	ACCELEROMETER, MECHANICAL	Q.E.D.
MILA5498	1650-00-395-2599	ACCUMULATOR ASSY, HYDRAULIC	HONEYWELL INTERNATIONAL
MIL-A-5498	1650-00-395-2599	ACCUMULATOR ASSY, HYDRAULIC	HONEYWELL INTERNATIONAL
MIL-A-5815/1	5985-00-217-0457	ANTENNA, UHF, BLADE	EDO
MILA83212	6610-00-160-3226	ALTIMETER PRESSURE	AEROSONIC
MIL-A-83212	6610-00-160-3226	ALTIMETER PRESSURE	AEROSONIC
MIL-A-83419	6610-01-016-1583	ALTIMETER, SERVO CONTROLLED	KOLLSMAN
MIL-C-27298 TYPE ABU9A	6645-00-793-5794	CLOCK, MECHANICAL, PANEL	WALTHAM AIRCRAFT CLOCK
MILC27298TYPEABU9A	6645-00-793-5794	CLOCK, MECHANICAL, PANEL	WALTHAM AIRCRAFT CLOCK
MILC38207	6645-00-076-3050	CLOCK, MECHANICAL, PANEL	WALTHAM AIRCRAFT CLOCK
MIL-C-38207	6645-00-076-3050	CLOCK, MECHANICAL, PANEL	WALTHAM AIRCRAFT CLOCK
MIL-C-38214	6605-00-815-1903	COMPASS, MAGNETIC	G T A
MILC38286	6610-00-763-2415	COMPUTER, FLIGHT DIRECTOR	ROCKWELL COLLINS
MIL-C-38286	6610-00-763-2415	COMPUTER, FLIGHT DIRECTOR	ROCKWELL COLLINS
MILC5604	6605-00-551-8187	COMPASS, MAGNETIC, MOUNTED	HONEYWELL INTERNATIONAL
MIL-C-5604	6605-00-551-8187	COMPASS, MAGNETIC, MOUNTED	HONEYWELL INTERNATIONAL
MILC6125	6605-00-239-8205	COMPASS, MAGNETIC, MOUNTED	KOLLSMAN
MIL-C-6125	6605-00-239-8205	COMPASS, MAGNETIC, MOUNTED	KOLLSMAN
MILC6126	6605-00-239-8206	COMPASS, MAGNETIC, MOUNTED	KOLLSMAN
MIL-C-6126	6605-00-239-8206	COMPASS, MAGNETIC, MOUNTED	KOLLSMAN
MIL-C-6499	6645-00-150-6526	CLOCK, MECHANICAL, PANEL	WALTHAM AIRCRAFT CLOCK
MIL-C-6499A	6645-00-150-6526	CLOCK, MECHANICAL, PANEL	WALTHAM AIRCRAFT CLOCK
MIL-C-6499A TYPE A13A	6645-00-950-8599	CLOCK, MECHANICAL, PANEL	WALTHAM AIRCRAFT CLOCK
MILC6499ATYPEA13A	6645-00-950-8599	CLOCK, MECHANICAL, PANEL	WALTHAM AIRCRAFT CLOCK
MIL-C-6499B	6645-00-150-6526	CLOCK, MECHANICAL, PANEL	WALTHAM AIRCRAFT CLOCK
MIL-C-6499C	6645-00-150-6526	CLOCK, MECHANICAL, PANEL	WALTHAM AIRCRAFT CLOCK
MIL-C-6499D	6645-00-150-6526	CLOCK, MECHANICAL, PANEL	WALTHAM AIRCRAFT CLOCK
MIL-C-6499E	6645-00-150-6526	CLOCK, MECHANICAL, PANEL	WALTHAM AIRCRAFT CLOCK
MIL-C-7115	6130-00-314-0050	POWER CONVERTER, AC/DC	COOPER INDUSTRIES
MIL-DTL-25707	5985-00-673-5831	ANTENNA, DME/TACAN, BEACON	L3 TECHNOLOGIES
MIL-DTL-25707/1	5985-00-673-5831	ANTENNA, DME/TACAN, BEACON	L3 TECHNOLOGIES

MIL-DTL-25708/1	5985-00-106-0906	ANTENNA	EDO
MIL-DTL-38394	6620-00-901-7848	TRANSMITTER PRESSURE	HONEYWELL INTERNATIONAL
MIL-DTL-6839		INDICATOR, POSITION	AMETEK
MIL-DTL-83511/2	5965-01-128-1410	HEADSET, MICROPHONE	ASTROCOM ELECTRONICS
MIL-DTL-83511/3	5965-01-127-3890	HEADSET, MICROPHONE	ASTROCOM ELECTRONICS
MILF8378	6625-00-668-7818	METER, ELECTRICAL FREQUENCY	AMETEK
MIL-F-8378	6625-00-668-7818	METER, ELECTRICAL FREQUENCY	AMETEK
MIL-G-25597		GYROSCOPE, DISPLACEMENT	GE AVIATION SYSTEMS
MILG5413		GENERATOR, TACHOMETER	AMETEK
MIL-G-5413		GENERATOR, TACHOMETER	AMETEK
MILH26312	5965-01-128-1410	HEADSET, MICROPHONE	ASTROCOM ELECTRONICS
MIL-H-26312	5965-01-128-1410	HEADSET, MICROPHONE	ASTROCOM ELECTRONICS
MILH26541	5965-01-128-1410	HEADSET, MICROPHONE	ASTROCOM ELECTRONICS
MIL-H-26541	5965-01-128-1410	HEADSET, MICROPHONE	ASTROCOM ELECTRONICS
MIL-H-83511/2	5965-01-128-1410	HEADSET, MICROPHONE	ASTROCOM ELECTRONICS
MIL-H-83511/3	5965-01-127-3890	HEADSET, MICROPHONE	ASTROCOM ELECTRONICS
MIL-I-18856A	6610-00-620-7888	INDICATOR, ANGLE OF ATTACK	AEROSONIC
MIL-I-25324		INDICATOR, FUEL FLOW	AMETEK
MILI25593	6610-00-557-3030	INDICATOR, ATTITUDE DIRECTOR	GE AVIATION SYSTEMS
MIL-I-25593	6610-00-557-3030	INDICATOR, ATTITUDE DIRECTOR	GE AVIATION SYSTEMS
MILI25623	6620-00-557-3023	INDICATOR, ELECTRICAL TACHOMETER	AMETEK
MIL-I-25623	6620-01-322-7678	INDICATOR, ELECTRICAL TACHOMETER	KELLY MANUFACTURING
MI-L-I25623	6620-00-557-3023	INDICATOR, ELECTRICAL TACHOMETER	AMETEK
MI-L-I25623 TYPE MU1	6620-00-557-3023	INDICATOR, ELECTRICAL TACHOMETER	AMETEK
MIL-I-26689	6605-00-034-2500	INDICATOR, HORIZONTAL SITUATION	ASTRONAUTICS
MIL-I-27197	6610-01-263-2409	INDICATOR, AIRSPEED/MACH	AEROSONIC
MIL-I-27209		INDICATOR, THERMOCOUPLE, TEMPERATURE	TRANSICOIL
MIL-I-27552		INDICATOR, THERMOCOUPLE, TEMPERATURE	CARLETON LIFE SUPPORT SYSTEMS
MIL-I-27882	6680-00-753-8932	INDICATOR, LIQUID QUANTITY	TRANSICOIL
MIL-I-5099	6685-00-514-5061	INDICATOR, PRESSURE	AEROSONIC
MIL-I-5184	6610-00-515-4600	INDICATOR, FLAP, POSITION	AMETEK
MIL-I-5392A	6610-00-006-5783	INDICATOR, MACH AND TRUE AIR SPEED	AEROSONIC
MILI6447	6610-00-514-5611	INDICATOR, AIR SPEED	KOLLSMAN
MIL-I-6447	6610-00-514-5611	INDICATOR, AIR SPEED	KOLLSMAN
MIL-I-6447 TYPE G-1		INDICATOR, AIR SPEED	KOLLSMAN
MIL-I-6447 TYPE M1		INDICATOR, AIR SPEED	KOLLSMAN
MIL-I-6447 TYPE M1A	6610-00-514-5612	INDICATOR, AIR SPEED	KOLLSMAN
MIL-I-6447A TYPE M1A	6610-00-585-1524	INDICATOR, AIR SPEED	KOLLSMAN
MILI6447TYPEG1		INDICATOR, AIR SPEED	KOLLSMAN
MILI6447TYPEM1		INDICATOR, AIR SPEED	KOLLSMAN
MILI6447TYPEM1A	6610-00-514-5612	INDICATOR, AIR SPEED	KOLLSMAN
MILI6533A	6685-00-553-4726	INDICATOR, TEMPERATURE, ELECTRICAL RESISTANCE	HORIZON AEROSPACE
MIL-I-6533A	6685-00-553-4726	INDICATOR, TEMPERATURE, ELECTRICAL RESISTANCE	HORIZON AEROSPACE
MIL-I-6669	6685-00-514-5327	INDICATOR, TEMPERATURE, ELECTRICAL RESISTANCE	HORIZON AEROSPACE
MIL-I-6681	6685-00-514-5328	INDICATOR, TEMPERATURE, ELECTRICAL RESISTANCE	HORIZON AEROSPACE
MIL-I-6839		INDICATOR, POSITION	AMETEK
MIL-I-7075	6685-00-557-0372	INDICATOR, TEMPERATURE, ELECTRICAL RESISTANCE	HORIZON AEROSPACE
MIL-I-7077	6685-00-557-0370	INDICATOR, TEMPERATURE, ELECTRICAL RESISTANCE	HORIZON AEROSPACE
MIL-I-7721	6610-00-530-0028	INDICATOR, VERTICAL VELOCITY	AEROSONIC
MIL-I-83392	6610-00-200-8832	INDICATOR, VERTICAL VELOCITY	L3 AVIATION PRODUCTS
MIL-I-87923	6620-01-172-6946	INDICATOR, TORQUEMETER	PARKER-HANNIFIN
MILI9343	6685-00-530-3614	INDICATOR, ANTI-ICING	HORIZON AEROSPACE
MIL-I-9343	6685-00-530-3614	INDICATOR, ANTI-ICING	HORIZON AEROSPACE

MIL-I-9443	6685-00-557-5910	INDICATOR, ENGINE EXHAUST, TEMPERATURE	HORIZON AEROSPACE
MIL I9443C	6685-00-557-5910	INDICATOR, ENGINE EXHAUST, TEMPERATURE	HORIZON AEROSPACE
MIL-L-6723	5850-00-729-1595	LIGHT, SIGNAL	GRIMES AEROSPACE
MILM22177AS	5965-00-755-4643	MICROPHONE, DYNAMIC	ASTROCOM ELECTRONICS
MIL-M-22177AS	5965-00-755-4643	MICROPHONE, DYNAMIC	ASTROCOM ELECTRONICS
MILM22179	5965-00-755-4643	MICROPHONE, DYNAMIC	ASTROCOM ELECTRONICS
MIL-M-22179	5965-00-755-4643	MICROPHONE, DYNAMIC	ASTROCOM ELECTRONICS
MIL-M-26542/2	5965-00-755-4643	MICROPHONE, DYNAMIC	ASTROCOM ELECTRONICS
MILM55233	5965-00-755-4643	MICROPHONE, DYNAMIC	ASTROCOM ELECTRONICS
MIL-M-55233	5965-00-755-4643	MICROPHONE, DYNAMIC	ASTROCOM ELECTRONICS
MIL-P-8422 TYPE MC-1	6130-01-178-7850	POWER SUPPLY	PACIFIC ELECTRONIC ENTERPRISES
MIL-PRF-38214	6605-00-815-1903	COMPASS, MAGNETIC	G T A
MIL-T-25307	6685-00-526-7864	TRANSMITTER, PRESSURE	AMETEK
MIL-T-25307D	6685-00-526-7864	TRANSMITTER, PRESSURE	AMETEK
MIL-T-25624	6620-01-067-8336	TRANSMITTER, PRESSURE	HONEYWELL INTERNATIONAL
MIL-T-25905	6620-00-621-2902	TRANSMITTER, FLOWMETER	AMETEK
MIL-T-27200	6615-01-059-7909	GYROSCOPE, RATE OF TURN	ATLANTIC INERTIAL SYSTEMS
MIL-T-38394	6620-00-901-7848	TRANSMITTER PRESSURE	HONEYWELL INTERNATIONAL
MIL-T-5583	6610-00-678-9887	TRANSMITTER, POSITION	SIMMONDS PRECISION PRODUCTS
MIL-T-5882D	6620-00-553-8988	TRANSMITTER, PRESSURE	HONEYWELL INTERNATIONAL
MIL-T-7748	6620-00-999-2222	TRANSMITTER, PRESSURE	HONEYWELL INTERNATIONAL
MIL-T-8249	6620-00-557-0259	TRANSMITTER, FLOWMETER	AMETEK
MJ1	6685-00-530-3614	INDICATOR, ENGINE EXHAUST, TEMPERATURE	HORIZON AEROSPACE
MJ-1	6685-00-530-3614	INDICATOR, ANTI-ICING	HORIZON AEROSPACE
MJ2	6685-00-557-5910	INDICATOR, ENGINE EXHAUST, TEMPERATURE	HORIZON AEROSPACE
MJ3	6625-00-578-5584	INDICATOR, ENGINE EXHAUST, TEMPERATURE	HORIZON AEROSPACE
MJ6		INDICATOR, ENGINE EXHAUST, TEMPERATURE	HORIZON AEROSPACE
ML-1	6605-00-111-3645	TRANSMITTER, INDUCTION COMPASS	HONEYWELL INTERNATIONAL
MM4	6610-00-557-3030	INDICATOR, ATTITUDE DIRECTOR	GE AVIATION SYSTEMS
MM-4	6610-00-557-3030	INDICATOR, ATTITUDE DIRECTOR	GE AVIATION SYSTEMS
MM4A	6610-00-866-3234	INDICATOR, ATTITUDE DIRECTOR	GE AVIATION SYSTEMS
MM-4A	6610-00-866-3234	INDICATOR, ATTITUDE DIRECTOR	GE AVIATION SYSTEMS
MN95A	5985-00-149-1451	ANTENNA, LOOP	RAYTHEON
MODEL 833		AMMETER	WESTON ELECTRICAL INSTRUMENT
MPEV3-032-2	4320-00-174-5811	PUMP, AUXILIAR	EATON AEROSPACE
MPEV3-032-2A	4320-00-174-5811	PUMP, AUXILIAR	EATON AEROSPACE
MPU-86R	5821-01-333-9239	PROCESSOR UNIT, MULTI	ROCKWELL COLLINS
MR-26		MOUNT, DYNAFOCAL	LORD
MR-27B		MOUNT, DYNAFOCAL	LORD
MR-27C		MOUNT, DYNAFOCAL	LORD
MR-27D		MOUNT, DYNAFOCAL	LORD
MR-27E		MOUNT, DYNAFOCAL	LORD
MR-27F		MOUNT, DYNAFOCAL	LORD
MR-36		MOUNT, DYNAFOCAL	LORD
MR-36E		MOUNT, DYNAFOCAL	LORD
MR-36F		MOUNT, DYNAFOCAL	LORD
MR-36H		MOUNT, DYNAFOCAL	LORD
MR-36J		MOUNT, DYNAFOCAL	LORD
MR-36K		MOUNT, DYNAFOCAL	LORD
MR-36M		MOUNT, DYNAFOCAL	LORD
MR-36P		MOUNT, DYNAFOCAL	LORD
MR-36T		MOUNT, DYNAFOCAL	LORD
MR-37		MOUNT, DYNAFOCAL	LORD

MR-40B1		MOUNT, DYNAFOCAL	LORD
MR-40D1		MOUNT, DYNAFOCAL	LORD
MR-40D2		MOUNT, DYNAFOCAL	LORD
MR-40H		MOUNT, DYNAFOCAL	LORD
MR-40J		MOUNT, DYNAFOCAL	LORD
MR-43		MOUNT, DYNAFOCAL	LORD
MR-43E		MOUNT, DYNAFOCAL	LORD
MR-43F		MOUNT, DYNAFOCAL	LORD
MR-43G		MOUNT, DYNAFOCAL	LORD
MR-43H		MOUNT, DYNAFOCAL	LORD
MR-50		MOUNT, DYNAFOCAL	LORD
MR-50A		MOUNT, DYNAFOCAL	LORD
MR-50B		MOUNT, DYNAFOCAL	LORD
MR-50C		MOUNT, DYNAFOCAL	LORD
MRC-H87AIC	5965-00-755-4643	MICROPHONE, DYNAMIC	ASTROCOM ELECTRONICS
MS17399-1	6615-00-181-1879	GYROSCOPE, SWITCHING RATE	GE AVIATION SYSTEMS
MS17404-2	6125-00-020-3217	POWER CONVERTER, DC/AC	GE AVIATION SYSTEMS
MS17983-02	6605-00-551-8187	COMPASS, MAGNETIC, MOUNTED	HONEYWELL INTERNATIONAL
MS17983-2	6605-00-551-8187	COMPASS, MAGNETIC, MOUNTED	HONEYWELL INTERNATIONAL
MS21971-1		INDICATOR, ELECTRICAL TACHOMETER	AMETEK
MS21971-2		INDICATOR, ELECTRICAL TACHOMETER	AEROSONIC
MS24569-1	6685-00-183-0351	INDICATOR, THERMOCOUPLE, TEMPERATURE	TRANSICOIL
MS25038-2		GENERATOR, TACHOMETER	AMETEK
MS25038-4	6680-00-553-8892	GENERATOR, TACHOMETER	AMETEK
MS25277-1	6220-00-803-4610	LIGHT, EMERGENCY, ROTATING	GRIMES AEROSPACE
MS25396	6605-00-833-5087	TRANSMITTER, INDUCTION COMPASS	HONEYWELL INTERNATIONAL
MS25396-1	6605-00-833-5087	TRANSMITTER, INDUCTION COMPASS	HONEYWELL INTERNATIONAL
MS25470-7	6685-00-868-5858	INDICATOR, PRESSURE	HONEYWELL INTERNATIONAL
MS27403-2		INDICATOR, POSITION	AMETEK
MS28000-1	6620-00-515-4541	INDICATOR, ELECTRICAL TACHOMETER	AMETEK
MS28004-2	6685-00-514-5328	INDICATOR, TEMPERATURE, ELECTRICAL RESISTANCE	HORIZON AEROSPACE
MS28005-1	6620-00-553-8988	TRANSMITTER, PRESSURE	HONEYWELL INTERNATIONAL
MS28005-5	6685-00-526-7864	TRANSMITTER, PRESSURE	AMETEK
MS28005-8	6685-00-526-7864	TRANSMITTER, PRESSURE	AMETEK
MS28008-1	6685-00-557-0372	INDICATOR, TEMPERATURE, ELECTRICAL RESISTANCE	HORIZON AEROSPACE
MS28009-1	6685-00-557-0370	INDICATOR, TEMPERATURE, ELECTRICAL RESISTANCE	HORIZON AEROSPACE
MS28009-2	6685-00-514-5327	INDICATOR, TEMPERATURE, ELECTRICAL RESISTANCE	HORIZON AEROSPACE
MS28009-4	6685-00-514-5327	INDICATOR, TEMPERATURE, ELECTRICAL RESISTANCE	HORIZON AEROSPACE
MS28010-1	6620-00-514-5334	INDICATOR, PRESSURE	HONEYWELL INTERNATIONAL
MS28023-1	6610-00-515-4600	INDICATOR, FLAP, POSITION	AMETEK
MS28027-1	5826-00-505-3094	INDICATOR, RADIO MAGNETIC	HONEYWELL INTERNATIONAL
MS28036-1		INDICATOR, AIR SPEED	KOLLSMAN
MS28049-1	6610-00-530-0028	INDICATOR, VERTICAL VELOCITY	AEROSONIC
MS28066-30	6610-00-719-6882	TRANSMITTER, ANGLE OF ATTACK	AEROSONIC
MS28067-2	6610-00-620-7888	INDICATOR, ANGLE OF ATTACK	AEROSONIC
MS28075-1	6610-00-473-5046	INDICATOR, VERTICAL VELOCITY	AEROSONIC
MS28075-1B	6610-00-473-5046	INDICATOR, VERTICAL VELOCITY	AEROSONIC
MS28130-4	6685-00-851-1824	TRANSMITTER, PRESSURE	HONEYWELL INTERNATIONAL
MS28131-10T	6620-00-065-3235	TRANSMITTER, PRESSURE	HONEYWELL INTERNATIONAL
MS28131-12T	6620-00-999-2425	TRANSMITTER, PRESSURE	HONEYWELL INTERNATIONAL
MS28131-14T	6620-00-115-2501	TRANSMITTER, PRESSURE	HONEYWELL INTERNATIONAL
MS28131-6T	6620-00-999-2222	TRANSMITTER, PRESSURE	HONEYWELL INTERNATIONAL
MS28131-8T	6620-00-999-2424	TRANSMITTER, PRESSURE	HONEYWELL INTERNATIONAL

MS28132-1	6130-00-566-0347	POWER CONVERTER, AC/DC	COOPER INDUSTRIES
MS28132-2	6130-00-164-4224	POWER CONVERTER, AC/DC	COOPER INDUSTRIES
MS28700-4	1650-00-640-8486	ACCUMULATOR ASSY, HYDRAULIC	HONEYWELL INTERNATIONAL
MS28925-9	5850-00-729-1595	LIGHT, SIGNAL	GRIMES AEROSPACE
MS3370-1	6130-00-314-0050	POWER CONVERTER, AC/DC	COOPER INDUSTRIES
MS42-3913S159-2A	1650-00-720-0093	MOTOR, HYDRAULIC	EATON AEROSPACE
MS42-3913S159-2C		MOTOR, HYDRAULIC	EATON AEROSPACE
MS90323-6	6620-00-151-5363	INDICATOR, TORQUEMETER	SIMMONDS PRECISION PRODUCTS
MS90325-4	6110-01-017-5428	REGULATOR, VOLTAGE	HONEYWELL INTERNATIONAL
MSP-85		SELECT PANEL, AUTO-PILOT MODE	ROCKWELL COLLINS
MT-273/ARN-6	5340-00-612-1246	MOUNTING BASE ASSEMBLY	RAYTHEON
MT-273A/ARN-6	5826-00-969-9543	MOUNTING BASE ASSEMBLY	RAYTHEON
MT273AARN6	5826-00-969-9543	MOUNTING BASE ASSEMBLY	RAYTHEON
MT273ARN6	5340-00-612-1246	MOUNTING BASE ASSEMBLY	RAYTHEON
MT-273B/ARN-6	5826-00-969-9542	MOUNTING BASE ASSEMBLY	RAYTHEON
MT273BARN6	5826-00-969-9542	MOUNTING BASE ASSEMBLY	RAYTHEON
MT-273C/ARN-6	5826-00-969-9542	MOUNTING BASE ASSEMBLY	RAYTHEON
MT273CARN6	5826-00-969-9542	MOUNTING BASE ASSEMBLY	RAYTHEON
MT-273D/ARN-6	5826-00-333-9867	MOUNTING BASE ASSEMBLY	RAYTHEON
MT273DARN6	5826-00-333-9867	MOUNTING BASE ASSEMBLY	RAYTHEON
MT-273E/ARN-6	5826-00-522-3428	MOUNTING BASE ASSEMBLY	RAYTHEON
MT273EARN6	5826-00-522-3428	MOUNTING BASE ASSEMBLY	RAYTHEON
MT-273F/ARN-6	5826-00-629-8309	MOUNTING BASE ASSEMBLY	RAYTHEON
MT273FARN6	5826-00-629-8309	MOUNTING BASE ASSEMBLY	RAYTHEON
MT-275/ARN-6	5826-00-611-0951	MOUNTING BASE	RAYTHEON
MT275ARN6	5826-00-611-0951	MOUNTING BASE	RAYTHEON
MT-4680/A	5975-01-013-0861	MOUNTING BASE, TACAN, TRANSCEIVER	ROCKWELL COLLINS
MT-4680A/A	5975-01-045-6683	MOUNTING BASE, TACAN, TRANSCEIVER	ROCKWELL COLLINS
MT-4681/A	5975-01-013-0862	MOUNTING BASE, TACAN, TRANSCEIVER	ROCKWELL COLLINS
MT-4682/A	5975-01-012-1857	MOUNTING BASE, TACAN, TRANSCEIVER	ROCKWELL COLLINS
MT-4682A/A	5975-01-034-5477	MOUNTING BASE, TACAN, TRANSCEIVER	ROCKWELL COLLINS
MT-4842/A	5975-01-151-9680	MOUNTING BASE, TACAN, TRANSCEIVER	ROCKWELL COLLINS
MT-4915/A	5975-01-041-2044	MOUNTING BASE, TACAN, TRANSCEIVER	ROCKWELL COLLINS
MT-6019/ARN	5975-01-062-5189	MOUNTING BASE, TACAN, TRANSCEIVER	ROCKWELL COLLINS
MT-6230/ARN-118(V)	5975-01-136-2750	MOUNTING BASE, TACAN, TRANSCEIVER	ROCKWELL COLLINS
MT-6487/ARN-118(V)	5975-01-208-8418	MOUNTING BASE, TACAN, TRANSCEIVER	ROCKWELL COLLINS
MT-6527/ARN-118(V)	5975-01-249-5920	MOUNTING BASE, TACAN, TRANSCEIVER	ROCKWELL COLLINS
MTK-14/A24G-9	6610-00-887-9422	MOUNT ASSY, COMPUTER RESILIENT	HONEYWELL INTERNATIONAL
MU1	6620-00-557-3023	INDICATOR, ELECTRICAL TACHOMETER	AMETEK
MU-1	6620-00-557-3023	INDICATOR, ELECTRICAL TACHOMETER	AMETEK
MX-10384/ARN-118(V)	5826-01-132-7214	MOUNTING BASE, TACAN, TRANSCEIVER	ROCKWELL COLLINS
MX-9577/A	5826-01-012-4864	ADAPTER, TACAN, TRANSCEIVER	ROCKWELL COLLINS
N200250-2	5826-00-234-6315	INDICATOR, BEARING	RAYTHEON
N212254-1	5985-00-149-1451	ANTENNA, LOOP	RAYTHEON
N212254-2	5985-00-149-1451	ANTENNA, LOOP	RAYTHEON
N400-4B-3	6105-00-683-0351	MOTOR,ALTERNATING CURRENT	ALLIANT DEFENSE
N400-4B-4	6105-00-683-0351	MOTOR,ALTERNATING CURRENT	ALLIANT DEFENSE
NA126D2	5841-00-464-0335	DECODER	MOTOROLLA
NA5-8218-3	4820-00-810-2061	VALVE, FLUID, REGULATING	BOEING
NAB017	6645-12-146-1628	CLOCK, MECHANICAL, PANEL	SINN SPEZIALUHHREN
OA-8697/ARD	5826-01-008-4097	DIRECTION FINDER SET	ROCKWELL COLLINS
P16M-3	5930-00-615-7340	SWITCH, PRESSURE	UNITED ELECTRIC CONTROLS
P46D-18	5930-00-615-7340	SWITCH, PRESSURE	UNITED ELECTRIC CONTROLS

PE22251-5	6610-00-263-3076	INDICATOR, AIR SPEED	CARLETON
PP1073C/APN59	6130-01-056-8665	POWER SUPPLY, RADAR	NORTHROP GRUMMAN SYSTEMS
PP-1073C/APN-59	6130-01-056-8665	POWER SUPPLY, RADAR	NORTHROP GRUMMAN SYSTEMS
PP1073CAPN59	6130-01-056-8665	POWER SUPPLY, RADAR	NORTHROP GRUMMAN SYSTEMS
PPI-1T	6210-01-408-7389	INDICATOR, RADAR, LIGHT	HONEYWELL INTERNATIONAL
PPI-1TB(M)		TRANSCEIVER, WEATHER, RADAR	HONEYWELL INTERNATIONAL
PS309407-02	6615-01-450-2720	SELECT PANEL, AUTO-PILOT MODE	CAE
PS309442-02	6610-01-460-1385	DISPLAY, OPTOELECTRONIC, EADI/EHSI	CAE
PS-835D	6130-01-219-8285	POWER SUPPLY, BATTERY	L3 AVIATION PRODUCTS
PSS12270	6130-01-431-9742	POWER SUPPLY, VDC/DDC	BRANDT ELECTRONICS
PWR-230	5996-01-306-4529	AMPLIFIER, ELECTRONIC CONTROL	ROCKWELL COLLINS
PYLB51239	4810-01-237-5974	VALVE, OIL COOLER, AUGMENTATION	GE AVIATION SYSTEMS
PYLB51239-1	4810-01-619-3259	VALVE, OIL COOLER, AUGMENTATION	GE AVIATION SYSTEMS
PYLB51239-2	4810-01-237-5974	VALVE, OIL COOLER, AUGMENTATION	GE AVIATION SYSTEMS
R-101/ARN-6	5826-00-543-0829	TRANSCEIVER, RADIO COMPASS	RAYTHEON
R-101A/ARN6	5826-00-241-1011	TRANSCEIVER, RADIO COMPASS	RAYTHEON
R-101A/ARN6-2	5826-00-241-1011	TRANSCEIVER, RADIO COMPASS	RAYTHEON
R101AARN6	5826-00-241-1011	TRANSCEIVER, RADIO COMPASS	RAYTHEON
R101AARN6-2	5826-00-241-1011	TRANSCEIVER, RADIO COMPASS	RAYTHEON
R101ARN6	5826-00-543-0829	TRANSCEIVER, RADIO COMPASS	RAYTHEON
R-101B/ARN-6	5826-00-505-0793	TRANSCEIVER, RADIO COMPASS	RAYTHEON
R101BARN6	5826-00-505-0793	TRANSCEIVER, RADIO COMPASS	RAYTHEON
R-101C/ARN-6	5826-00-625-9201	TRANSCEIVER, RADIO COMPASS	RAYTHEON
R101CARN6	5826-00-625-9201	TRANSCEIVER, RADIO COMPASS	RAYTHEON
R1596M5	1680-00-887-1911	ACTUATOR, ELECTRO-MECHANICAL, LINEAR	WHIPPANY ACTUATION SYSTEMS
R200260-1	5895-00-228-3133	CONTROL BOX, RECEIVER	RAYTHEON
R-2217/ARN-140	5826-01-486-8271	RECEIVER, RADIO NAVIGATION	ROCKWELL COLLINS
R-27A		MOUNT, DYNAFOCAL	LORD
R-27B		MOUNT, DYNAFOCAL	LORD
R-27E		MOUNT, DYNAFOCAL	LORD
R-27F		MOUNT, DYNAFOCAL	LORD
R-27J		MOUNT, DYNAFOCAL	LORD
R-27K		MOUNT, DYNAFOCAL	LORD
R5170M34-2	1680-00-804-5756	ACTUATOR, APU DOOR, ELECTRO-MECHANICAL	ROCKWELL COLLINS
R5170M34-3	1680-00-474-3300	ACTUATOR, APU DOOR, ELECTRO-MECHANICAL	WHIPPANY ACTUATION SYSTEMS
R5170M34-4	1680-00-426-5616	ACTUATOR, APU DOOR, ELECTRO-MECHANICAL	WHIPPANY ACTUATION SYSTEMS
R6607-2-14	5930-00-615-7340	SWITCH, PRESSURE	EATON AEROSPACE
R88-C-783		COMPASS, MAGNETIC, MOUNTED	AEROSONIC
R88-C-800		COMPASS, MAGNETIC, MOUNTED	HONEYWELL AEROSPATIALE
R88-C-845		COMPASS, MAGNETIC, MOUNTED	HONEYWELL AEROSPATIALE
RC-15D2		MOUNT, DYNAFOCAL	LORD
RC-27L		MOUNT, DYNAFOCAL	LORD
RC-27P		MOUNT, DYNAFOCAL	LORD
RC60	6610-00-530-0028	INDICATOR, VERTICAL VELOCITY	HONEYWELL AEROSPATIALE
RC-60	6610-00-530-0028	INDICATOR, VERTICAL VELOCITY	AEROSONIC
RC60MS	6610-00-111-3159	INDICATOR, VERTICAL VELOCITY	AEROSONIC
RC-60MS	6610-00-111-3159	INDICATOR, VERTICAL VELOCITY	AEROSONIC
RC60MS10-3	6610-00-951-4451	INDICATOR, VERTICAL VELOCITY	AEROSONIC
RC-60MS-10-3	6610-00-951-4451	INDICATOR, VERTICAL VELOCITY	AEROSONIC
RCA40-02		INDICATOR, ELECTRICAL TACHOMETER	AEROSONIC
RCA40-03		INDICATOR, ELECTRICAL TACHOMETER	KELLY MANUFACTURING
RCA40-05		INDICATOR, ELECTRICAL TACHOMETER	KELLY MANUFACTURING
RCA40-06		INDICATOR, ELECTRICAL TACHOMETER	KELLY MANUFACTURING

RCA40-07		INDICATOR, ELECTRICAL TACHOMETER	KELLY MANUFACTURING
RCA40-09		INDICATOR, ELECTRICAL TACHOMETER	KELLY MANUFACTURING
RCA40A-10		INDICATOR, ELECTRICAL TACHOMETER	KELLY MANUFACTURING
RCA40A-11		INDICATOR, ELECTRICAL TACHOMETER	KELLY MANUFACTURING
RCA40AB		INDICATOR, ELECTRICAL TACHOMETER	KELLY MANUFACTURING
RCA41-09	6680-01-313-3450	INDICATOR, ELECTRICAL TACHOMETER	KELLY MANUFACTURING
RCA41-11A	6680-00-944-3117	INDICATOR, ELECTRICAL TACHOMETER	KELLY MANUFACTURING
RCA41A-07	6620-01-322-7678	INDICATOR, ELECTRICAL TACHOMETER	KELLY MANUFACTURING
RCA41A-09	6680-01-313-3450	INDICATOR, ELECTRICAL TACHOMETER	KELLY MANUFACTURING
RCA41AB		INDICATOR, ELECTRICAL TACHOMETER	KELLY MANUFACTURING
RCA42		INDICATOR, ELECTRICAL TACHOMETER	KELLY MANUFACTURING
RCA42A		INDICATOR, ELECTRICAL TACHOMETER	KELLY MANUFACTURING
RCB40B-01	5841-00-189-9436	INDICATOR, ELECTRICAL TACHOMETER	KELLY MANUFACTURING
RCB40B-02		INDICATOR, ELECTRICAL TACHOMETER	KELLY MANUFACTURING
RCB40B-03		INDICATOR, ELECTRICAL TACHOMETER	KELLY MANUFACTURING
RCB40B-04		INDICATOR, ELECTRICAL TACHOMETER	KELLY MANUFACTURING
RCB40B-05		INDICATOR, ELECTRICAL TACHOMETER	KELLY MANUFACTURING
RCB40B-07		INDICATOR, ELECTRICAL TACHOMETER	KELLY MANUFACTURING
RCB40B-08		INDICATOR, ELECTRICAL TACHOMETER	KELLY MANUFACTURING
RCB40B-09		INDICATOR, ELECTRICAL TACHOMETER	KELLY MANUFACTURING
RCB40B-10		INDICATOR, ELECTRICAL TACHOMETER	KELLY MANUFACTURING
RCB40B-11		INDICATOR, ELECTRICAL TACHOMETER	KELLY MANUFACTURING
RCB40B-12		INDICATOR, ELECTRICAL TACHOMETER	KELLY MANUFACTURING
RCB41B		INDICATOR, ELECTRICAL TACHOMETER	KELLY MANUFACTURING
RCB42B		INDICATOR, ELECTRICAL TACHOMETER	KELLY MANUFACTURING
RCS60-1L	6610-00-473-5046	INDICATOR, VERTICAL VELOCITY	KELLY MANUFACTURING
RG14D3	6680-00-653-1139	INDICATOR, FUEL QUANTITY, TOTALIZER	HONEYWELL INTERNATIONAL
RG14D7	6680-00-860-6390	INDICATOR, FUEL QUANTITY, TOTALIZER	HONEYWELL INTERNATIONAL
RG-3-11		GYROSCOPE, ROTATING	ROCKWELL COLLINS
RG-3-21		GYROSCOPE, ROTATING	ROCKWELL COLLINS
RG9080J6A	2915-MD-003-2382	PUMP, FUEL	CRANE
RL-15D2		MOUNT, DYNAFOCAL	LORD
RL-15D5		MOUNT, DYNAFOCAL	LORD
RL-15D8		MOUNT, DYNAFOCAL	LORD
RL-15E		MOUNT, DYNAFOCAL	LORD
RL-15F		MOUNT, DYNAFOCAL	LORD
RL-25		MOUNT, DYNAFOCAL	LORD
RL30P	6610-00-729-4292	TRANSMITTER, ANGLE OF ATTACK	ROCKWELL COLLINS
RL50	6610-00-467-7152	TRANSMITTER, ANGLE OF ATTACK	AEROSONIC
RL50P	6610-00-720-3237	TRANSMITTER, ANGLE OF ATTACK	AEROSONIC
RL50PE	6610-00-719-6882	TRANSMITTER, ANGLE OF ATTACK	AEROSONIC
RS-40F		MOUNT, DYNAFOCAL	LORD
RS-40G		MOUNT, DYNAFOCAL	LORD
RS-40H		MOUNT, DYNAFOCAL	LORD
RT1159/ARN-118	5826-01-012-1938	TRANSCEIVER, TACAN	ROCKWELL COLLINS
RT-1250A/ARC-182	5821-01-203-3480	TRANSCEIVER, RADIO AM/FM	ROCKWELL COLLINS
RT-1338/APS-133(V)	5841-01-091-8929	TRANSCEIVER, WEATHER, RADAR	HONEYWELL INTERNATIONAL
RT-1338A/APS-133(V)	5841-01-194-2452	TRANSCEIVER, WEATHER, RADAR	HONEYWELL INTERNATIONAL
RT-1341(V)3/ARC-190	5821-01-258-7579	TRANSCEIVER, RADIO	ROCKWELL COLLINS
RT-1397/ARC-197	5821-01-140-7767	TRANSCEIVER, VHF, RADIO	ROCKWELL COLLINS
RT-1438/APN-232(V)	5841-01-301-4588	TRANSCEIVER, CARA	NAVCOM DEFENSE ELECTRONICS
RT1438APN232V	5841-01-301-4588	TRANSCEIVER, CARA	NAVCOM DEFENSE ELECTRONICS
RT-1692/APN-232(V)	5841-01-349-9175	TRANSCEIVER, CARA	NAVCOM DEFENSE ELECTRONICS

RT1692APN232V	5841-01-349-9175	TRANSCEIVER, CARA	NAVCOM DEFENSE ELECTRONICS
RT289G/APN59	5841-01-282-7093	TRANSCEIVER, RADAR	NORTHROP GRUMMAN SYSTEMS
RT-289G/APN-59	5841-01-282-7093	TRANSCEIVER, RADAR	NORTHROP GRUMMAN SYSTEMS
RT-474/ARC-72	5821-00-893-0193	TRANSCEIVER, RADIO	ROCKWELL COLLINS
RT-5048/ARC-511(V)	5821-01-038-7301	TRANSCEIVER, VHF, RADIO	ROCKWELL COLLINS
RT-5048D/ARC-511(V)	5820-01-517-3020	TRANSCEIVER, VHF, RADIO	ROCKWELL COLLINS
RT-648/ARC-94	5821-00-893-2906	TRANSCEIVER, RADIO	ROCKWELL COLLINS
RT-698/ARC-102	5821-00-604-3307	TRANSCEIVER, RADIO	ROCKWELL COLLINS
RT831A/APN59C	5841-01-053-7894	TRANSCEIVER, RADAR	NORTHROP GRUMMAN SYSTEMS
RT-831A/APN-59C	5841-01-053-7894	TRANSCEIVER, RADAR	NORTHROP GRUMMAN SYSTEMS
RT832A/APN59D	5841-01-053-5762	TRANSCEIVER, RADAR	NORTHROP GRUMMAN SYSTEMS
RT-832A/APN-59D	5841-01-053-5762	TRANSCEIVER, RADAR	NORTHROP GRUMMAN SYSTEMS
RT859A/APX-72	5841-00-089-7179	TRANSCEIVER, RADAR	RAYTHEON
RTA-1FB	5841-01-305-1921	TRANSCEIVER, WEATHER, RADAR	HONEYWELL INTERNATIONAL
RTA-1FB(M)	5841-01-314-9947	TRANSCEIVER, WEATHER, RADAR	HONEYWELL
RTA-842		TRANSCEIVER, WEATHER, RADAR	ROCKWELL COLLINS
RYLC51047	1680-01-221-8261	ACTUATOR, ELECTRO-MECHANICAL, LINEAR	GE AVIATION SYSTEMS
RYLC51047-1	1680-01-221-8261	ACTUATOR, ELECTRO-MECHANICAL, LINEAR	GE AVIATION SYSTEMS
S1660-60034-8	5985-00-852-0457	COUPLER, ANTENNA	ROCKWELL COLLINS
S1820502-01		TRANSMITTER, EMERGENCY LOCATOR (ELT)	KANNAD
S1820502-02		TRANSMITTER, EMERGENCY LOCATOR (ELT)	KANNAD
S1820502-04		TRANSMITTER, EMERGENCY LOCATOR (ELT)	KANNAD
S1821502-01		TRANSMITTER, EMERGENCY LOCATOR (ELT)	KANNAD
S1821502-02		TRANSMITTER, EMERGENCY LOCATOR (ELT)	KANNAD
S1821502-06		TRANSMITTER, EMERGENCY LOCATOR (ELT)	KANNAD
S1822502-01		TRANSMITTER, EMERGENCY LOCATOR (ELT)	KANNAD
S1822502-02		TRANSMITTER, EMERGENCY LOCATOR (ELT)	KANNAD
S1823502-01		TRANSMITTER, EMERGENCY LOCATOR (ELT)	KANNAD
S1823502-02		TRANSMITTER, EMERGENCY LOCATOR (ELT)	KANNAD
S1823502-03		ELT,KANNAD 406 AS-TNC	KANNAD
S1823502-05		TRANSMITTER, EMERGENCY LOCATOR (ELT)	KANNAD
S1824502-01		TRANSMITTER, EMERGENCY LOCATOR (ELT)	KANNAD
S1824502-02		TRANSMITTER, EMERGENCY LOCATOR (ELT)	KANNAD
S1840501-01		ELT,KANNAD 406 AF-COMPACT	KANNAD
S1840501-02		TRANSMITTER, EMERGENCY LOCATOR (ELT)	KANNAD
S1850501-01		TRANSMITTER, EMERGENCY LOCATOR (ELT)	KANNAD
S1850501-02		TRANSMITTER, EMERGENCY LOCATOR (ELT)	KANNAD
S1850501-03		TRANSMITTER, EMERGENCY LOCATOR (ELT)	KANNAD
S1851501-01		ELT, AF INTEGRA	KANNAD
S1851501-02		TRANSMITTER, EMERGENCY LOCATOR (ELT)	KANNAD
S1851501-03		TRANSMITTER, EMERGENCY LOCATOR (ELT)	KANNAD
S1852501-01		TRANSMITTER, EMERGENCY LOCATOR (ELT)	KANNAD
S1852501-02		TRANSMITTER, EMERGENCY LOCATOR (ELT)	KANNAD
S1852501-03		TRANSMITTER, EMERGENCY LOCATOR (ELT)	KANNAD
S1854501-01		TRANSMITTER, EMERGENCY LOCATOR (ELT)	KANNAD
S1854501-02		TRANSMITTER, EMERGENCY LOCATOR (ELT)	KANNAD
S1854501-03		TRANSMITTER, EMERGENCY LOCATOR (ELT)	KANNAD
S2204-105	6220-00-370-5447	LIGHT, EMERGENCY EXIT	SODERBERG
S2320-101	6220-01-438-3488	LIGHT, EMERGENCY	SODERBERG
S3698	6645-00-887-0122	TIMER, SEQUENTIAL	AI-TEK INSTRUMENTS
S-513-100-2	1650-00-640-8486	ACCUMULATOR ASSY, HYDRAULIC	TELEDYNE
S513-100-2T	1650-00-516-6893	ACCUMULATOR ASSY, HYDRAULIC	TELEDYNE
S85-AVU-8C/A	6610-01-263-2409	INDICATOR, AIRSPEED/MACH	AEROSONIC



SA103-18	6695-00-628-8990	INDICATOR, POSITION	PENN KEYSTONE
SC2253A		SELCAL, DECODER	TEAM
SC-B-76347	6250-00-299-5129	INDICATOR, TEMPERATURE, ELECTRICAL RESISTANCE	HORIZON AEROSPACE
SCD10175	6685-00-526-7864	TRANSMITTER, PRESSURE	CELTECH
SG461/APN59B	5841-00-983-8393	GENERATOR, ELECTRONIC MARKER, RADAR	NORTHROP GRUMMAN SYSTEMS
SG-461/APN-59B	5841-00-983-8393	GENERATOR, ELECTRONIC MARKER, RADAR	NORTHROP GRUMMAN SYSTEMS
SG461A/APN59B	5841-00-983-8393	GENERATOR, ELECTRONIC MARKER, RADAR	NORTHROP GRUMMAN SYSTEMS
SG-461A/APN-59B	5841-00-983-8393	GENERATOR, ELECTRONIC MARKER, RADAR	NORTHROP GRUMMAN SYSTEMS
SK40LC1	6610-01-109-5105	INDICATOR, MACH AND TRUE AIR SPEED	AEROSONIC
SLZ2226A		TRANSMITTER, ANGLE OF ATTACK	AEROSONIC
SLZ2481	6610-00-729-4292	TRANSMITTER, ANGLE OF ATTACK	AEROSONIC
SLZ2482	6610-00-720-3237	TRANSMITTER, ANGLE OF ATTACK	AEROSONIC
SLZ2501	6610-00-719-6882	TRANSMITTER, ANGLE OF ATTACK	AEROSONIC
SLZ9028	6610-00-557-5832	INDICATOR, ANGLE OF ATTACK	AEROSONIC
SLZ9028D	6610-00-527-8356	INDICATOR, ANGLE OF ATTACK	AEROSONIC
SLZ9028E	6610-00-620-7888	INDICATOR, ANGLE OF ATTACK	AEROSONIC
SLZ9028G	6610-00-811-6070	INDICATOR, ANGLE OF ATTACK	AEROSONIC
SLZ9034		INDICATOR, ANGLE OF ATTACK	AEROSONIC
SLZ9695-3	6610-01-222-6439	TRANSMITTER, ANGLE OF ATTACK	AEROSONIC
SLZ9696	6610-01-004-5856	INDICATOR, ANGLE OF ATTACK	AEROSONIC
SN198B/APN59	5895-01-053-3579	SYNCHRONIZER, ELECTRICAL	NORTHROP GRUMMAN SYSTEMS
SN-198B/APN-59	5895-01-053-3579	SYNCHRONIZER, ELECTRICAL	NORTHROP GRUMMAN SYSTEMS
SP9509	1650-00-204-1703	MOTOR, HYDRAULIC	EATON AEROSPACE
SR14-1	4110-00-015-7627	REFRIGERATOR, MECHANICAL	GOODRICH
SR14-101	4110-00-015-7627	REFRIGERATOR, MECHANICAL	GOODRICH
SR18B		INDICATOR, CONDENSOR DOOR POSITION	AMETEK
SR-18B		INDICATOR, CONDENSOR DOOR POSITION	AMETEK
SR18C		INDICATOR, CONDENSOR DOOR POSITION	AMETEK
SR-18C		INDICATOR, CONDENSOR DOOR POSITION	AMETEK
SR3J	6685-00-887-6815	INDICATOR, FUEL CROSS FEED PRESSURE	AMETEK
SR-3J	6685-00-887-6815	INDICATOR, FUEL CROSS FEED PRESSURE	AMETEK
SR-4J		INDICATOR, OIL COOLER FLAP, POSITION	AMETEK
SR4K		INDICATOR, ENGINE OIL PRESSURE	AMETEK
SR-4K		INDICATOR, ENGINE OIL PRESSURE	AMETEK
SR4M		INDICATOR, REDUCTION GEAR OIL PRESSURE	AMETEK
SR-4M		INDICATOR, REDUCTION GEAR OIL PRESSURE	AMETEK
SR-4U		INDICATOR, WING FLAP, POSITION	AMETEK
SR5E	6685-00-887-6813	INDICATOR, BLEED MANIFOLD PRESSURE	AMETEK
SR-5E	6685-00-887-6813	INDICATOR, BLEED MANIFOLD PRESSURE	AMETEK
SR5F		INDICATOR, FREON CONDENSOR PRESSURE	AMETEK
SR-5F		INDICATOR, FREON CONDENSOR PRESSURE	AMETEK
SR5G		INDICATOR, FREON COMPRESSOR PRESSURE	AMETEK
SR-5G		INDICATOR, FREON COMPRESSOR PRESSURE	AMETEK
SR6A	6620-00-514-5334	INDICATOR, PRESSURE	AMETEK
SR-6A	6620-00-514-5334	INDICATOR, PRESSURE	AMETEK
ST104A	6620-00-526-7917	TRANSMITTER, PRESSURE	AMETEK
ST-104A	6620-00-526-7917	TRANSMITTER, PRESSURE	AMETEK
ST109C	6685-00-887-1971	TRANSMITTER, PRESSURE	AMETEK
ST-109C	6685-00-887-1971	TRANSMITTER, PRESSURE	AMETEK
ST207A	6685-00-526-7864	TRANSMITTER, PRESSURE	AMETEK
ST-207A	6685-00-526-7864	TRANSMITTER, PRESSURE	AMETEK
ST4F	6620-00-553-8988	TRANSMITTER, PRESSURE	AMETEK
ST-4F	6620-00-553-8988	TRANSMITTER, PRESSURE	AMETEK

ST6B	6620-00-553-8988	TRANSMITTER, PRESSURE	AMETEK
ST-6B	6620-00-553-8988	TRANSMITTER, PRESSURE	AMETEK
ST6C	6620-00-553-8988	TRANSMITTER, PRESSURE	AMETEK
ST-6C	6620-00-553-8988	TRANSMITTER, PRESSURE	AMETEK
ST7A	6685-00-526-7864	TRANSMITTER, PRESSURE	AMETEK
ST-7A	6685-00-526-7864	TRANSMITTER, PRESSURE	AMETEK
ST7B	6685-00-526-7864	TRANSMITTER, PRESSURE	AMETEK
ST-7B	6685-00-526-7864	TRANSMITTER, PRESSURE	AMETEK
ST7C	6685-00-526-7864	TRANSMITTER, PRESSURE	AMETEK
ST-7C	6685-00-526-7864	TRANSMITTER, PRESSURE	AMETEK
ST7D	6685-00-526-7864	TRANSMITTER, PRESSURE	AMETEK
ST-7D	6685-00-526-7864	TRANSMITTER, PRESSURE	AMETEK
SYLZ50683-1	1660-01-126-1784	CONTROL BOX, AIRCRAFT AIR TEMPERATURE	GE AVIATION SYSTEMS
SYLZ50684	1660-01-121-7386	CONTROL BOX, AIRCRAFT AIR TEMPERATURE	GE AVIATION SYSTEMS
SYLZ50685	1660-01-021-4981	CONTROL BOX, TEMPERATURE	GE AVIATION SYSTEMS
T16-311-350M001	6610-MD-030-7102	INDICATOR, AIR SPEED	JAEGER (THALES AVIONICS)
T700A3420008000	6605-14-489-2230	COMPASS, GYROMAGNETIC	SOCATA
TG255-001		GENERATOR, TACHOMETER	ADVANCED POWER
TG255-002	6680-00-445-1246	GENERATOR, TACHOMETER	ADVANCED POWER
TG255-003	6680-00-920-9213	GENERATOR, TACHOMETER	ADVANCED POWER
TG255-004		GENERATOR, TACHOMETER	ADVANCED POWER
TG255-005		GENERATOR, TACHOMETER	ADVANCED POWER
TG255-006		GENERATOR, TACHOMETER	ADVANCED POWER
TG255-007	6680-00-923-8466	GENERATOR TACHOMETER	ADVANCE POWER
TG255-008		GENERATOR, TACHOMETER	ADVANCED POWER
TMC49-4	5965-00-755-4643	MICROPHONE, DYNAMIC	ELNO
TRK-46/A24G-9	6685-00-887-1966	PROBE,TEMPERATURE	HONEYWELL INTERNATIONAL
TRK-56/A27J-1	6685-00-526-7864	TRANSMITTER, PRESSURE	AMETEK
TRU-2A/A	6615-01-059-7909	GYROSCOPE, RATE OF TURN	KELLY MANUFACTURING
TRU-7/A	6620-00-621-2902	TRANSMITTER, FLOWMETER	AMETEK
TRU-80/A3A	6620-01-067-8336	TRANSMITTER, PRESSURE	HONEYWELL INTERNATIONAL
TRU-81/A	6620-00-901-7848	TRANSMITTER, PRESSURE	HONEYWELL INTERNATIONAL
TRU81A	6620-00-901-7848	TRANSMITTER PRESSURE	HONEYWELL INTERNATIONAL
TS-2046/AIC	4920-00-986-7642	TEST SET, INTERCOMMUNICATION	TRAYTHEON
TSG421-106	6130-12-148-2278	INVERTER,POWER,STATIC	DIEHL
TYPE11A	6645-14-401-6084	CLOCK, STOP	ANODE
TYPE500-12		TRANSMITTER, PERSONAL LOCATOR (PLT/PLB)	TECHTEST
TYPE500-16		TRANSMITTER, PERSONAL LOCATOR (PLT/PLB)	TECHTEST
TYPE500-27		TRANSMITTER, PERSONAL LOCATOR (PLT/PLB)	TECHTEST
U521251-1	2935-00-887-1969	COOLER, LUBRICATING OIL	TRIUMPH THERMAL SYSTEMS
VHF-21A		TRANSCEIVER, VHF, RADIO	ROCKWELL COLLINS
VHF-21B		TRANSCEIVER, VHF, RADIO	ROCKWELL COLLINS
VHF-21C		TRANSCEIVER, VHF, RADIO	ROCKWELL COLLINS
VHF-21D		TRANSCEIVER, VHF, RADIO	ROCKWELL COLLINS
VHF-22D		TRANSCEIVER, VHF, RADIO	ROCKWELL COLLINS
VIR-30		RECEIVER, RADIO NAVIGATION	ROCKWELL COLLINS
VIR-30A		RECEIVER, RADIO NAVIGATION	ROCKWELL COLLINS
VIR-30M		RECEIVER, RADIO NAVIGATION	ROCKWELL COLLINS
VIR-31		RECEIVER, RADIO NAVIGATION	ROCKWELL COLLINS
VIR-31A		RECEIVER, RADIO NAVIGATION	ROCKWELL COLLINS
VIR-31H		RECEIVER, RADIO NAVIGATION	ROCKWELL COLLINS
VIR-32	5821-01-450-6351	RECEIVER, RADIO NAVIGATION	ROCKWELL COLLINS
VIR-33		RECEIVER, RADIO NAVIGATION	ROCKWELL COLLINS

W1121F8-9-0	4820-00-810-2061	VALVE, FLUID, REGULATING	ROCKWELL COLLINS
W33-7540	6645-00-950-8599	CLOCK, MECHANICAL, PANEL	WAKMANN WATCH COMPANY
W33-7545-10	6645-00-089-7903	CLOCK, MECHANICAL, PANEL	WALTHAM AIRCRAFT CLOCK
W33-7545-4	6645-00-089-7903	CLOCK, MECHANICAL, PANEL	WALTHAM AIRCRAFT CLOCK
W33-7590-1	6645-00-588-7611	CLOCK, MECHANICAL, PANEL	WAKMANN WATCH
W33-7590-10A	6645-00-588-7611	CLOCK, MECHANICAL, PANEL	WAKMANN WATCH
WXA-1000	5895-MD-035-4227	WEATHER RADAR ADAPTER	ROCKWELL COLLINS
WXT-250B		TRANSCEIVER, RADAR	ROCKWELL COLLINS
X702-361	4140-00-887-6787	FAN, VANE, AXIAL	HAMILTON SUNDSTRAND
XD708054	5826-00-342-1964	COUPLING, ANTENNA	RAYTHEON
XW20058M1	6105-00-630-5828	MOTOR, WINDSHIELD, DIRECT CURRENT	EMERSON ELECTRIC
XW20345-318-46	1680-00-712-0716	ACTUATOR, LINEAR	ROSEMOUNT AEROSPACE
Y5485-1	5826-00-090-3646	INDICATOR, BEARING	KEARFOTT
Z00.N6002377222	6605-01-141-7035	COMPASS, GYROMAGNETIC	SOCATA
Z00.N6018157226	2910-01-143-0195	PUMP, FUEL, ELECTRICAL	SOCATA